SanDisk SDMX26-008G-G46G

SanDisk Clip Jam MP3 Player User Manual

Model: SDMX26-008G-G46G

1. Overview

The SanDisk Clip Jam MP3 Player is a compact and lightweight digital music player designed for on-the-go listening. It features 8GB of internal storage, expandable via a microSD card slot, and includes an FM radio tuner. Its intuitive interface and clip-on design make it ideal for active users.



Front view of the SanDisk Clip Jam MP3 Player, highlighting its compact design, bright green color, and intuitive button layout for music navigation.

Your browser does not support the video tag.

Official SanDisk promotional video showcasing the features and portability of the Clip Jam MP3 Player, including its clip design, storage capacity, and sound quality.

2. What's in the Box

The following items are included with your SanDisk Clip Jam MP3 Player:

- SanDisk Clip Jam Sport MP3 Player
- USB 2.0 transfer cable
- Earphones
- Quick start guide



The retail packaging for the SanDisk Clip Jam MP3 Player, illustrating the device, included earphones, and highlighting features such as 8GB storage, up to 2000 songs capacity, microSD card slot, and 18-hour battery life.

3. Setup

3.1 Charging the Device

Before first use, fully charge your SanDisk Clip Jam MP3 Player. Connect the included USB 2.0 transfer cable to the player's port and the other end to a powered USB port on your computer or a USB wall adapter (not included). The battery indicator on the screen will show charging status. A full charge provides up to 18 hours of continuous playback.

3.2 Transferring Music and Files

The Clip Jam MP3 Player functions as a mass storage device, allowing for easy drag-and-drop file transfer.

1. Connect the Clip Jam to your computer using the USB cable.
2. The device will appear as a removable drive (e.g., 'SanDisk Clip Jam') on your computer.
3. Open the device folder. You can drag and drop audio files (MP3, WMA (no DRM), AAC (DRM free iTunes), Audible (DRM only)) directly into the 'Music' folder.
4. Once files are transferred, safely eject the device from your computer before disconnecting the USB cable.

3.3 Inserting a microSD Card

To expand the storage capacity beyond the internal 8GB, you can insert a microSD card (sold separately).

1. Locate the microSD card slot on the side of the Clip Jam player.
2. Gently insert the microSD card into the slot until it clicks into place. Ensure the card is oriented correctly.
3. To remove, gently push the card inward until it clicks, then release to allow it to spring out.

4. Operating Instructions

4.1 Power On/Off

- **To Power On:** Press and hold the central 'Select' button (often the Play/Pause button) until the screen illuminates.
- **To Power Off:** Press and hold the central 'Select' button until the screen turns off.

4.2 Navigation and Controls

The Clip Jam features a 1-inch screen and large navigation buttons:

- **Central 'Select' Button:** Play/Pause, confirm selection.
- **Left/Right Arrows:** Navigate menus, skip tracks (short press), fast forward/rewind (long press).
- **Up/Down Arrows:** Adjust volume.
- **Back Button (Curved Arrow):** Return to the previous menu or screen.
- **Menu Button (Three Horizontal Lines):** Access options within a specific mode (e.g., shuffle, repeat).

4.3 Playing Music

1. From the main menu, select 'Music'.
2. Browse by Artist, Album, Song, Genre, or Playlists.
3. Use the arrow buttons to navigate and the central 'Select' button to choose.
4. Press the central 'Select' button to play a selected track or album.

4.4 Using the FM Radio

1. From the main menu, select 'FM Radio'.
2. Ensure earphones are connected as they act as the antenna.
3. Use the Left/Right arrows to tune to a station.
4. Press the Menu button to access options like auto-scan for stations or saving presets.

4.5 Creating Playlists

Playlists can be created on your computer and transferred to the Clip Jam, or directly on the device if supported by its firmware. Refer to the quick start guide for detailed instructions on device-specific playlist creation.

5. Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the device. Avoid abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid exposing the device to extreme temperatures. Charge the device regularly, even if not in frequent use. The battery is not user-replaceable.
- **Storage:** Store the player in a cool, dry place when not in use.

6. Troubleshooting

Issue	Possible Solution
Device does not turn on.	Ensure the battery is charged. Connect to a USB power source and try again.
Computer does not recognize the device.	Try a different USB port or cable. Ensure the device is powered on when connected. Restart your computer.
No sound from earphones.	Check earphone connection. Ensure volume is not muted or too low. Try different earphones.
Files not playing.	Verify the file format is supported (MP3, WMA (no DRM), AAC (DRM free iTunes), Audible (DRM only)). Ensure files are not corrupted.
FM Radio static or poor reception.	Ensure earphones are fully plugged in as they act as the antenna. Try moving to an area with better signal.

7. Specifications

Model Name: Clip Jam

Model Number: SDMX26-008G-G46G

Brand: SanDisk

Memory Storage Capacity: 8GB (internal)

Expandable Storage: Micro SD card slot (card not included)

Battery: 1 Lithium Ion battery (included, non-replaceable)

Battery Life: Up to 18 hours (based on 128 kbps MP3 playback)

Supported Audio Formats: MP3, WMA (no DRM), AAC (DRM free iTunes), Audible (DRM only)

Screen Size: 0.96 Inches (LCD)

Connectivity Technology: Aux (for earphones), USB 2.0 (for data transfer/charging)

Dimensions: 0.63 x 1.6 x 2.6 inches

Item Weight: 0.8 ounces

Color: Green

Manufacturer: Western Digital Technologies, Inc.

Date First Available: May 10, 2015

8. Warranty and Support

SanDisk products are manufactured to the highest standards and undergo rigorous testing. For detailed warranty information and technical support, please refer to the official SanDisk website or the warranty card included with your product.

You can visit the SanDisk Official Website for further assistance and product registration.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question