LG G4

LG G4 Smartphone User Manual

Introduction

This manual provides essential instructions for setting up, operating, and maintaining your LG G4 smartphone. Please read this guide thoroughly to ensure proper use and to maximize your device's features.

Product Overview

The LG G4 is a high-performance smartphone featuring a 5.5-inch IPS Quantum Display, a 16-MP camera, and powered by Android 5.1 (Lollipop). Its gently curved design is crafted for in-hand comfort.



Figure 1: Front view of the LG G4 smartphone, showcasing its display and overall design.

What's in the Box

Verify that all items are present in the product packaging:

- LG G4 Smartphone
- Pre-Installed SIM Card
- Wall Charger
- USB Cable

Setup

1. Inserting the SIM Card and Battery

The LG G4 comes with a pre-installed SIM card. To access the battery compartment, gently remove the back cover of the phone. Insert the battery, ensuring the contacts align correctly. Replace the back cover until it clicks into place.

2. Charging the Device

Connect the USB cable to the phone's charging port and the other end to the wall charger. Plug the wall charger into a power outlet. Allow the device to charge fully before initial use.

3. Powering On/Off

To power on, press and hold the Power/Lock key located on the back of the device until the LG logo appears. To power off, press and hold the Power/Lock key, then select "Power off" from the options.

Operating Instructions

Display and Navigation

The LG G4 features a 5.5-inch IPS Quantum Display with a resolution of 2560 x 1440. Navigate the interface using touch gestures. Swipe left or right to access different home screens, tap icons to open applications, and pinch to zoom.

Camera Features

The device is equipped with a 16-MP rear camera and an 8-MP front camera. The improved Laser Auto Focus allows for faster shooting. Use Gesture Shot with the front camera for easy selfies by making a fist.

Your browser does not support the video tag.

Video 1: Demonstrates the LG G4's camera features, including Laser Auto Focus and Gesture Shot for selfies.

Storage Expansion

The LG G4 includes a microSD™ Card Slot for expandable storage. This allows you to store additional photos, videos, and applications beyond the internal 32 GB memory. A microSD card is sold separately.



Figure 2: Side view of the LG G4, highlighting its gently curved design.

Maintenance

- Keep the device clean using a soft, dry cloth.
- Avoid exposing the phone to extreme temperatures or direct sunlight.
- Protect the screen with a screen protector and use a protective case to prevent physical damage.
- Regularly back up your data to prevent loss.

Troubleshooting

Common Issues and Solutions

- **Device not powering on:** Ensure the battery is charged. Connect the charger and wait a few minutes before

attempting to power on again.

- **Poor battery life:** Adjust screen brightness, disable unnecessary background apps, and turn off Wi-Fi/Bluetooth when not in use.
- **Apps crashing or freezing:** Close and restart the app. If the issue persists, clear the app's cache or reinstall it.
- **Camera focus issues:** Ensure the camera lens is clean and free from obstructions. Tap on the screen to manually focus.

Specifications

Feature	Detail
Brand	LG
Model Name	G4
Operating System	Android 5.1 (Lollipop)
CPU Speed	1.8 GHz
Memory Storage Capacity	32 GB
Screen Size	5.5 Inches
Display Type	IPS Quantum Display
Display Resolution Maximum	2560 x 1440
Rear Facing Camera	16 MP
Video Capture Resolution	1080p
Battery Capacity	3000 mAh
Wireless Carrier	Verizon
Cellular Technology	4G LTE
Connectivity Technology	Wi-Fi
Item Weight	0.33 Pounds
Item Dimensions	3 x 0.38 x 5.82 inches

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official LG website. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question