## Bosch BOSCH 621101#1

# Bosch Genuine TASSIMO Descaling Service T DISC Instruction Manual

Model: BOSCH 621101#1

### Introduction

The Bosch Genuine TASSIMO Descaling Service T DISC is designed for the effective removal of limescale deposits from your TASSIMO coffee machine. Regular descaling is crucial for maintaining optimal machine performance, ensuring consistent beverage quality, and extending the lifespan of your appliance. This disc works in conjunction with descaling tablets (sold separately) to facilitate the cleaning process.



Image: A Bosch TASSIMO coffee machine, illustrating the type of appliance this descaling disc is used with.

### Compatibility

## Compatibility

This descaling service T DISC is suitable for use with various Bosch TASSIMO coffee machine models. Please refer to your machine's user manual for specific descaling instructions and confirmation of compatibility. Compatible models include, but are not limited to:

- TAS1202GB/01, TAS1202GB/02, TAS1204/01, TAS1204/02, TAS1204CH/01, TAS1204CH/02, TAS1204EE/01, TAS1204EE/02, TAS1204GB/01, TAS1204GB/02
- TAS2001/01, TAS2001/02, TAS2001/03, TAS2001/04, TAS2001/05, TAS2001/06, TAS2001CH/01, TAS2001CH/02, TAS2001CH/03, TAS2001CH/04, TAS2001CH/05, TAS2001CH/06, TAS2001DE1/01, TAS2001EE/03, TAS2001EE/04, TAS2001EE/05, TAS2001EE/06, TAS2001GB/01, TAS2001GB/02, TAS2001GB/03, TAS2001GB/04, TAS2001GB/05, TAS2001GB/06, TAS2001KR/03, TAS2001KR/04, TAS2001UC/01, TAS2001UC/02, TAS2001UC8/02, TAS2001UC8/03, TAS2001UC8/04, TAS2001UC8/05, TAS2001UC8/06, TAS2002GB/02, TAS2002GB/03, TAS2002GB/04, TAS2002GB/05, TAS2002GB/06
- TAS4000GB/15, TAS4011/01, TAS4011/03, TAS4011/05, TAS4011/07, TAS4011/09, TAS4011/11, TAS4011/13, TAS4011/15, TAS4011AT1/01, TAS4011AT1/03, TAS4011AT1/05, TAS4011AT1/07, TAS4011AT1/09, TAS4011AT1/11, TAS4011AT1/13, TAS4011AT1/15, TAS4011CH/01, TAS4011CH/03, TAS4011CH/05, TAS4011CH/07, TAS4011CH/09, TAS4011CH/11, TAS4011CH/13, TAS4011CH/15, TAS4011CH1/01, TAS4011CH1/03, TAS4011CH1/05, TAS4011CH1/07, TAS4011DE/15, TAS4011DE1/01, TAS4011DE1/03, TAS4011DE1/05, TAS4011DE1/07, TAS4011DE1/09, TAS4011DE1/11, TAS4011DE1/13, TAS4011DE1/15, TAS4011DE2/05, TAS4011DE2/07, TAS4011DE2/09, TAS4011DE2/11, TAS4011DE2/13, TAS4011DE2/15, TAS4011EE/09, TAS4011EE/11, TAS4011EE/13, TAS4011EE/15, TAS4011ES1/05, TAS4011ES1/07, TAS4011ES1/09, TAS4011ES1/11, TAS4011ES1/13, TAS4011ES1/15, TAS4011FR1/01, TAS4011FR1/03, TAS4011FR1/05, TAS4011FR1/07, TAS4011FR2/05, TAS4011FR2/07, TAS4011FR2/09, TAS4011FR2/11, TAS4011FR2/13, TAS4011FR2/15, TAS4011GB/01, TAS4011GB/03, TAS4011GB/05, TAS4011GB/07, TAS4011GB/09, TAS4011GB/11, TAS4011GB/13, TAS4011GB/15, TAS4011MILKA00, TAS4012GB/01, TAS4012GB/03, TAS4012GB/05, TAS4012GB/07, TAS4012GB/09, TAS4012GB/11, TAS4012GB/13, TAS4012GB/15, TAS4013GB/03, TAS4013GB/05, TAS4013GB/07, TAS4013GB/09, TAS4013GB/11, TAS4013GB/13, TAS4013GB/15, TAS4211GB/09, TAS4211GB/11, TAS4211GB/13, TAS4211GB/15, TAS4212GB/09, TAS4212GB/11, TAS4212GB/13, TAS4212GB/15, TAS4213GB/09, TAS4213GB/11, TAS4213GB/13, TAS4213GB/15, TAS4615UC/03, TAS4615UC/05, TAS4615UC8/05, TAS4615UC8/06, TAS4616UC8/05, TAS4616UC8/06, TAS6515GB/01, TAS6515GB/03, TAS6515GB/05, TAS6515GB/07, TAS6515GB/09, TAS6515GB/11, TAS6515GB/13, TAS6515GB/15, TAS8520GB/05, TAS8520GB/07, TAS8520GB/09, TAS8520GB/11, TAS8520GB/13

## Usage Instructions: Descaling Process

Follow these general steps for descaling your TASSIMO machine using the Service T DISC. Always consult your specific machine's manual for detailed instructions, as procedures may vary slightly by model.

1. **Preparation:**
    - Ensure the water tank is empty.
    - Place 2 TASSIMO descaling tablets (not included with this service disc) into the empty water tank.
    - Fill the water tank with fresh water up to the descaling mark (usually indicated by a 'CALC' or 'DESCALING' line). Ensure the tablets fully dissolve.
    - Place a large container (minimum 500ml capacity) under the beverage outlet to collect the descaling solution.
2. **Initiate Descaling Cycle:**
    - Open the brewing unit of your TASSIMO machine.
    - Insert the yellow/orange TASSIMO Service T DISC into the brewing unit, ensuring the barcode faces down. Close the brewing unit firmly.

- Press and hold the start/stop button for approximately 3-5 seconds to begin the descaling cycle. The descaling indicator light will illuminate.
- The machine will run several cycles, dispensing the descaling solution into the container. This process can take 20-30 minutes. Do not interrupt the cycle.

3. **Rinsing Cycles:**
   - Once the descaling cycle is complete, the descaling indicator light may turn off or change color. Empty the container and the water tank.
   - Rinse the water tank thoroughly with fresh water and fill it to the 'MAX' mark.
   - Place the empty container back under the beverage outlet.
   - Press the start/stop button briefly to begin a rinsing cycle. The machine will dispense hot water.
   - Repeat the rinsing cycle at least 3-4 times, emptying the container after each cycle, until the descaling indicator light is completely off (if applicable) and no descaling solution remains.
4. **Completion:**
   - After the final rinsing cycle, open the brewing unit and remove the Service T DISC. Clean the Service T DISC under running water and store it in its designated compartment within your TASSIMO machine.
   - Your TASSIMO machine is now descaled and ready for use.

## Maintenance Tips

- Always use fresh, cold water in your TASSIMO machine.
- Clean the exterior of your machine regularly with a damp cloth.
- Empty and clean the drip tray and cup stand after each use.
- Follow the descaling instructions provided by your TASSIMO machine's manufacturer, typically every 3 months or when the descaling indicator light illuminates.

## Specifications

- **Item Model Number:** BOSCH 621101#1
- **Brand:** Bosch
- **Scent:** Unscented
- **Specific Uses For Product:** Coffee Maker (Descaling)
- **Unit Count:** 1.0 Count
- **Surface Recommendation:** Plastic

## Troubleshooting

If your TASSIMO machine is not functioning correctly after descaling, or if the descaling indicator light remains on, please refer to your machine's specific user manual for troubleshooting steps. Common issues may include:

- Incorrect placement of the Service T DISC.
- Insufficient water in the tank during cycles.
- Incomplete rinsing cycles.

For persistent issues, contact Bosch customer support.

## Warranty and Support

For information regarding product warranty or technical support, please refer to the documentation included with your TASSIMO machine or visit the official Bosch website. This descaling disc is a consumable accessory; its warranty is typically limited to manufacturing defects.

## Important Information

**Legal Disclaimer:** Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question