Electroline ME208COR

Electroline ME208COR Countertop Microwave Oven User Manual

Model: ME208COR

1. Introduction

Thank you for purchasing the Electroline ME208COR Countertop Microwave Oven. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read these instructions thoroughly before using the microwave oven and retain them for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Always ensure the appliance is properly grounded.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Only use utensils that are suitable for use in microwave ovens.
- The microwave oven is intended for heating food and beverages. Drying of clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.

3. Product Overview

Familiarize yourself with the components of your Electroline ME208COR microwave oven.



Front view of the Electroline ME208COR microwave oven, showing the control panel, door, and interior.

Main Components:

- **Control Panel:** Features touch controls for setting time, power level, and functions.
- **Oven Door:** Equipped with a safety lock system.
- **Glass Turntable:** Ensures even cooking by rotating food.
- **Turntable Support:** Holds the glass turntable in place.
- **Oven Cavity:** The interior cooking space.
- **Grill Rack:** Used for the grill function (ensure it is microwave-safe for combined use).

4. Setup

4.1 Unpacking

Carefully remove the microwave oven from its packaging. Remove all packing materials, including any protective film on the oven surfaces. Check the oven for any damage, such as dents or a misaligned door. If any damage is found, do not operate the oven and contact your retailer.

4.2 Placement

- Place the oven on a flat, stable surface that can support its weight and the heaviest food item likely to be cooked in it.
- Ensure there is adequate ventilation. Leave a minimum of 20 cm (8 inches) of space above the oven, 10 cm (4 inches) at the rear, and 5 cm (2 inches) on both sides.
- Do not block air vents.

- Keep the oven away from heat sources, steam, or splashing liquids.
- Do not place the oven near a radio or TV, as it may cause interference.

4.3 Electrical Connection

Plug the power cord into a standard grounded electrical outlet. Ensure the voltage and frequency match the specifications on the rating label of the oven.

5. Operating Instructions

The Electroline ME208COR features a touch control panel for various cooking functions.

5.1 Setting the Clock

1. Press the 'Clock' button.
2. Use the number pads to enter the current time (e.g., 12:30).
3. Press 'Clock' again to confirm.

5.2 Microwave Cooking

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. Press the 'Microwave' button.
4. Use the number pads to set the cooking time.
5. Press 'Power Level' repeatedly to select the desired power level (e.g., P100 for full power, P80 for 80% power).
6. Press 'Start' to begin cooking.

5.3 Grill Function

The grill function is ideal for browning and crisping food.

1. Place food on the grill rack (if provided and suitable for microwave use) or a heat-resistant dish.
2. Press the 'Grill' button.
3. Use the number pads to set the grilling time.
4. Press 'Start' to begin grilling.

5.4 Defrost Function

The defrost function allows you to thaw food by weight or time.

Defrost by Weight:

1. Place the frozen food in the oven.
2. Press the 'Defrost by Weight' button.
3. Use the number pads to enter the weight of the food in grams.
4. Press 'Start'. The oven will automatically calculate the defrosting time.

Defrost by Time:

1. Place the frozen food in the oven.

2. Press the 'Defrost by Time' button.
3. Use the number pads to enter the desired defrosting time.
4. Press 'Start'.

6. Maintenance and Cleaning

Regular cleaning helps maintain the performance and longevity of your microwave oven.

6.1 Cleaning the Oven Interior

- Always unplug the oven before cleaning.
- Wipe the interior cavity with a damp cloth after each use. For stubborn stains, use a mild detergent.
- To remove odors, boil a cup of water with lemon juice or vinegar in the oven for a few minutes, then wipe clean.
- The glass turntable and turntable support can be removed and washed in warm soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.

6.2 Cleaning the Oven Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners or harsh chemicals, as they can damage the finish.
- Clean the door seals and sealing surfaces regularly to ensure proper door closure.

7. Troubleshooting

If you encounter issues with your microwave oven, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close door firmly; Check household fuse or reset circuit breaker.
Food not heating	Incorrect cooking time or power level set; Door not closed properly.	Adjust cooking time and power level; Ensure door is fully closed.
Turntable not rotating	Turntable not properly placed; Obstruction under turntable.	Ensure turntable and support are correctly positioned; Remove any obstructions.
Unusual noise during operation	Food container touching oven walls; Turntable not seated correctly.	Reposition food container; Re-seat turntable and support.

If the problem persists after trying these solutions, please contact qualified service personnel.

8. Specifications

Feature	Specification
Brand	Electroline
Model Name	ME208COR
Capacity	20 Liters
Microwave Power	800 Watts
Internal Dimensions (L x D x H)	306 x 303.5 x 208.2 mm
Installation Type	Countertop
Control Type	Touch Control
Special Features	Grill Function, Turntable, Defrost Function
Material	Glass (for door/plate)
Color	White

9. Warranty and Support

This Electroline ME208COR microwave oven comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical support, service, or to inquire about replacement parts, please contact your retailer or the Electroline customer service department. Keep your proof of purchase for warranty claims.

© 2023 Electroline. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question