ION 5033

ION Snap Cam-Clip & Magnet Pack Instruction Manual

Model: 5033

1. Introduction

This instruction manual provides comprehensive guidance for the proper use and maintenance of your ION Snap Cam-Clip & Magnet Pack. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

2. Product Overview

The ION Snap Cam-Clip & Magnet Pack (Model 5033) is an accessory designed to provide versatile mounting options for compatible ION cameras. It includes two primary components: a cam-clip and a magnetic mount.



Figure 1: The ION Snap Cam-Clip and Magnet accessory. This image displays the two components of the ION Snap Cam-Clip & Magnet Pack. On the left is the clip mechanism, designed to attach to surfaces. On the right is the magnetic base, providing an alternative mounting option.

- **Cam-Clip:** A spring-loaded clip mechanism for attaching your camera to various objects or surfaces.
- **Magnetic Mount:** A strong magnetic base for securing your camera to metallic surfaces.

3. Setup and Installation

Before using the Cam-Clip or Magnetic Mount, ensure your ION camera is compatible and securely attached to the accessory.

3.1 Attaching to Camera

1. Identify the mounting point on your ION camera.
2. Align the Cam-Clip or Magnetic Mount with the camera's mounting point.
3. Securely fasten the accessory to the camera. Ensure it is tight and stable to prevent accidental detachment during use.

3.2 Using the Cam-Clip

1. Press the clip handles to open the jaws.
2. Position the clip onto a stable surface or object (e.g., backpack strap, hat brim, thin ledge).

3. Release the handles to allow the clip to grip the surface. Verify the clip has a firm hold before leaving the camera unattended.

3.3 Using the Magnetic Mount

1. Ensure the metallic surface is clean and free of debris.
2. Place the magnetic mount directly onto the metallic surface.
3. Test the strength of the magnetic hold by gently tugging on the camera. If the hold is weak, reposition the mount or choose a different metallic surface. Avoid using on painted or delicate surfaces where strong magnets could cause damage.

4. Operation and Best Practices

Proper operation ensures the safety of your camera and the quality of your recordings.

- Always ensure the mount (clip or magnet) is securely attached to both the camera and the chosen surface before recording.
- For the magnetic mount, select flat, ferrous metallic surfaces for the strongest hold. Avoid curved or uneven surfaces.
- When using the clip, ensure the object being clipped is robust enough to support the camera's weight and that the clip jaws have a full, secure grip.
- Avoid mounting the camera in locations where it may be subject to excessive vibration, strong impacts, or extreme weather conditions without additional securing measures.
- Regularly check the stability of the mount during extended use.

5. Maintenance

To maintain the performance and appearance of your Cam-Clip & Magnet Pack, follow these guidelines:

- **Cleaning:** Wipe the surfaces of the clip and magnet with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the accessories in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the clip mechanism for any signs of wear or damage. Ensure the magnet surface is free from scratches or embedded metallic particles that could reduce its holding strength or scratch surfaces.

6. Troubleshooting

If you encounter issues with your ION Snap Cam-Clip & Magnet Pack, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Magnetic mount does not hold securely.	◦ Surface is not ferrous metal. ◦ Surface is too thin or uneven. ◦ Magnet surface is dirty or damaged.	◦ Ensure the surface is made of iron, steel, or other magnetic materials. ◦ Choose a thicker, flat metallic surface. ◦ Clean the magnet surface. If damaged, consider replacement.

Problem	Possible Cause	Solution
Cam-Clip slips or detaches.	◦ Surface is too thick or thin for the clip. ◦ Surface is slippery or unstable. ◦ Clip mechanism is worn or damaged.	◦ Ensure the clip has a firm, full grip on the surface. ◦ Select a surface with better friction or stability. ◦ Inspect the clip for damage. If worn, replacement may be necessary.
Camera detaches from the accessory.	◦ Accessory not securely fastened to the camera. ◦ Mounting point on camera or accessory is damaged.	◦ Re-fasten the accessory to the camera, ensuring it is tight. ◦ Inspect both the camera's mounting point and the accessory for damage.

If the problem persists after attempting these solutions, please contact ION customer support.

7. Specifications

Feature	Detail
Product Dimensions	0.39 x 0.39 x 0.39 inches
Item Weight	0.704 ounces
Model Number	5033
ASIN	B00Z0D7P7I
Manufacturer	ION
Date First Available	September 10, 2015

8. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your original ION camera or visit the official ION website. You may also contact ION customer service directly for assistance with the Snap Cam-Clip & Magnet Pack.

Online Support: Visit the ION Store on Amazon

© 2026 ION. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question