Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Candy 91670102

Candy 91670102 Dishwasher Drain Hose Instruction Manual

Genuine Replacement Part

Introduction

This manual provides essential information for the safe and correct installation, function, maintenance, and troubleshooting of your Candy 91670102 Dishwasher Drain Hose. Please read these instructions carefully before proceeding with installation or any maintenance.

Safety Information

- **Always disconnect the dishwasher from the electrical power supply and water supply**before attempting any installation, repair, or maintenance.
- Wear appropriate personal protective equipment, such as gloves, during installation.
- Ensure all connections are secure and watertight to prevent leaks.
- Repairs involving gas equipment must only be carried out by a gas registered technician. This product is not for gas equipment.
- If you are unsure about any step, consult a qualified technician.

Product Overview

The Candy 91670102 Dishwasher Drain Hose is a genuine replacement part designed to effectively remove wastewater from your dishwasher during its cycle. It is a flexible, corrugated hose engineered for durability and proper fit within compatible dishwasher models.



This image displays the flexible corrugated hose, typically used for draining water from a dishwasher. It features connectors at both ends for attachment to the appliance and the drainage system.

Compatibility

This drain hose is compatible with a wide range of dishwashers from brands including Candy, Cylinda, Hoover, Iberna, Kelvinator, Otsein, Rosieres, and Zerowatt. For a comprehensive list of compatible models, please refer to the detailed product description where this item was purchased or consult your appliance's user manual.

Setup (Installation)

Follow these steps to install the replacement drain hose:

1. **Preparation:** Ensure the dishwasher is disconnected from power and water supplies. Position towels or a basin to catch any residual water.
2. **Access:** Carefully pull the dishwasher out from its cabinet or access the rear panel, depending on your model, to reach the existing drain hose connections.
3. **Disconnect Old Hose:** Loosen any clamps or fasteners securing the old drain hose to the dishwasher's drain pump outlet and the household drain connection (e.g., sink trap, standpipe). Carefully remove the old hose.
4. **Connect New Hose to Dishwasher:** Attach one end of the new Candy 91670102 drain hose to the dishwasher's drain pump outlet. Secure it firmly with a hose clamp (re-use the old one if in good condition, or use a new one).
5. **Connect New Hose to Household Drain:** Route the new hose to your household drain connection. Ensure the hose is not kinked or stretched. Connect it securely, again using a hose clamp.
6. **Secure Hose:** If necessary, use hose clips or ties to secure the drain hose to prevent it from kinking or becoming dislodged during operation. Ensure there is a high loop in the drain hose as per your dishwasher's installation requirements to prevent backflow.
7. **Test:** Restore water and power to the dishwasher. Run a short cycle and carefully check all connections for leaks.

Observe the drainage process to ensure water is flowing freely.

Function and Usage

The drain hose is a critical component of your dishwasher's plumbing system. Its primary function is to transport dirty water from the dishwasher tub to your household drainage system (e.g., sink drain, garbage disposal, or standpipe) at the end of each wash and rinse cycle. Proper installation ensures efficient water removal, preventing standing water in the tub and maintaining hygienic operation.
Ensure the drain hose is never kinked, crushed, or blocked, as this will impede drainage and can lead to dishwasher malfunctions or leaks.

Maintenance

Regular inspection of the drain hose can help prevent future issues:

- **Visual Inspection:** Periodically check the entire length of the drain hose for any signs of wear, cracks, kinks, or damage. Pay close attention to the connection points.
- **Leak Check:** After running a dishwasher cycle, visually inspect the area around the drain hose connections for any signs of water leaks.
- **Clear Obstructions:** If you notice slow drainage or standing water, the hose might be partially blocked. While the hose itself is generally resistant to blockages, ensure the connection points to the dishwasher and household drain are clear of food debris or other obstructions.
- **Hose Position:** Confirm the hose maintains its proper high loop and is not sagging or creating a trap that could hold water.

Troubleshooting

If you encounter issues related to drainage, consider the following:

Problem	Possible Cause	Solution
Dishwasher not draining	Kinked or blocked drain hose	Check the hose for kinks and straighten them. Disconnect and inspect for blockages.
Water leaking from hose connections	Loose clamps or damaged hose/gasket	Tighten hose clamps. Inspect the hose and connection points for damage. Replace if necessary.
Dishwasher draining slowly	Partial blockage in hose or drain	Inspect the hose and the household drain connection for partial blockages and clear them.

Specifications

- **Brand:** Candy
- **Model Number:** 91670102
- **Product Dimensions:** Approximately 21 x 17 x 14 cm (packaged)
- **Item Weight:** Approximately 120 g
- **Part Number:** 5054680096957
- **Manufacturer:** Candy

Warranty and Support

For warranty information regarding this genuine replacement part, please refer to the terms and conditions provided by the seller or manufacturer at the time of purchase. For technical support or further assistance, contact the authorized service center for your dishwasher brand or the retailer from whom the part was purchased.

© 2023 Candy. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00ZG7EQYI

More documents and user manuals: **https://manuals.plus/**