Everpure EV9617-11

Everpure EV9617-11 4CB5 Water Filter Cartridge Instruction Manual

Model: EV9617-11

Introduction

The Everpure EV9617-11 4CB5 water filter cartridge is a high-quality replacement filter designed for under-sink water filtration systems. This carbon block cartridge effectively reduces chlorine, unpleasant taste and odor, and sediment from your drinking water. With a 5-micron filtration capability and a 6,000-gallon capacity, it provides clean, clear, and great-tasting water for an extended period. This manual provides essential information for the proper installation, operation, and maintenance of your filter cartridge.

Product Specifications

Model Number	EV9617-11
Material	Carbon Block
Filtration Rating	5 Micron
Capacity	6,000 Gallons
Product Dimensions	3"D x 3"W x 14"H
Item Weight	1.95 pounds
Product Benefits	Reduces Chlorine, Taste & Odor, and Sediment
External Testing Certification	NSF
Compatible Water Purifier Models	Aarke Purifier (and other compatible systems)
UPC	807032970321

Setup and Installation

Installing the Everpure EV9617-11 4CB5 cartridge is a straightforward process. Always refer to your specific filtration system's manual for detailed instructions, as procedures may vary slightly. The following are general steps for replacement:

1. **Prepare for Installation:** Locate the existing filter housing. Ensure you have a bucket or towel ready to catch any residual water.
2. **Turn Off Water Supply:** Locate the cold water supply valve leading to your filtration system and turn it off completely.
3. **Relieve Pressure:** Open the filtered water faucet to release any pressure in the system. Allow water to drain until it stops.
4. **Remove Old Cartridge:** Depending on your system, twist the old cartridge counter-clockwise or follow the specific release mechanism to remove it from the filter head. Dispose of the old cartridge responsibly.
5. **Prepare New Cartridge:** Remove the protective cap from the new Everpure EV9617-11 4CB5 cartridge.
6. **Install New Cartridge:** Insert the new cartridge into the filter head. Align the cartridge correctly and twist it clockwise until it is securely seated. Do not overtighten.
7. **Restore Water Supply:** Slowly turn on the cold water supply valve. Check for any leaks around the filter head.
8. **Flush the System:** Open the filtered water faucet and allow water to run for at least 5 minutes (or as recommended by your system's manufacturer) to flush out any air and carbon fines. The water may appear cloudy initially; this is normal and will clear up.
9. **Check for Leaks:** After flushing, close the faucet and carefully inspect all connections for leaks.



An image showing the Everpure EV9617-11 4CB5 water filter cartridge, a cylindrical silver unit with a white conical end, designed for under-sink water filtration systems.

Operating Instructions

Once installed and flushed, the Everpure EV9617-11 4CB5 filter cartridge operates automatically as water flows through your filtration system. No further user interaction is required for its daily function. Simply use your filtered water faucet as needed.

- Ensure the water supply to the filter system remains open during use.
- If water flow significantly decreases, it may indicate that the filter is nearing the end of its life and requires replacement.

Maintenance

Regular maintenance of your Everpure EV9617-11 4CB5 filter cartridge primarily involves timely replacement to ensure continued performance and water quality.

- **Filter Replacement:** The cartridge has a rated capacity of 6,000 gallons. It is recommended to replace the filter cartridge every 6 to 12 months, or sooner if you notice a significant drop in water flow, or a return of chlorine taste or odor. Actual replacement frequency may vary based on water quality and usage.
- **Monitoring Water Quality:** Periodically taste and smell your filtered water. Any noticeable change in taste or odor suggests it's time for a filter replacement.
- **System Inspection:** During filter replacement, inspect the filter head and connections for any signs of wear or damage.

Troubleshooting

If you encounter issues with your Everpure EV9617-11 4CB5 filter cartridge, consider the following common troubleshooting steps:

- **Reduced Water Flow:**
  - Ensure the water supply valve is fully open.
  - Check if the filter cartridge is correctly seated and tightened.
  - A significant reduction in flow often indicates a clogged filter, meaning it's time for replacement.
- **Unpleasant Taste or Odor Returns:**
  - This is a strong indicator that the filter's capacity has been exhausted. Replace the cartridge.
  - Ensure the filter was properly flushed after installation.
- **Leaks Around Filter Head:**
  - Turn off the water supply immediately.
  - Ensure the cartridge is properly aligned and securely twisted into the filter head.
  - Check the O-rings on the filter head for any damage or misalignment.
  - If leaks persist, contact a qualified plumber or the manufacturer's support.

Warranty Information

Specific warranty details for the Everpure EV9617-11 4CB5 filter cartridge are not provided in this manual. For comprehensive warranty information, please refer to the documentation included with your original filtration system or visit the official Everpure website. Keep your purchase receipt as proof of purchase for any warranty claims.

Support

For technical assistance, product inquiries, or further support regarding your Everpure EV9617-11 4CB5 water filter cartridge or compatible filtration system, please contact Everpure customer service directly. You can typically find contact information on the Everpure website or on the packaging of your filtration system.
Everpure Official Website: Visit the Everpure Store on Amazon (for general brand information and product range)

© 2024 Everpure. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question