Gloria 728833.0000

Gloria Multi-Brush for Wood Surfaces (165mm) - Instruction Manual

Model: 728833.0000

1. Product Overview

The Gloria Multi-Brush for Wood Surfaces is a specialized nylon brush roller designed for effective cleaning and maintenance of various wood surfaces. This includes terraces, decking made from softwood, hardwood, and WPC/BPC materials. Its optimized brush profile ensures thorough cleaning, even in grooves and gaps, to achieve excellent results.

- **Compatibility:** Suitable for GLORIA MultiBrush and PowerBrush devices.
- **Material:** Durable nylon bristles.
- **Design:** Optimized brush profile for comprehensive cleaning.
- **Dimensions:** Diameter: 100 mm, Width: 165 mm.



Image 1.1: The Gloria Multi-Brush in use on a wooden deck, demonstrating its cleaning capability.

2. Setup and Installation

This brush is an accessory designed for use with compatible GLORIA MultiBrush and PowerBrush devices. Follow the instructions provided with your GLORIA MultiBrush or PowerBrush device for attaching accessories.

1. Ensure your GLORIA MultiBrush or PowerBrush device is turned off and unplugged from its power source before installation.
2. Refer to your device's manual for specific instructions on how to remove the existing brush (if any) and attach the new wood surface brush.
3. Carefully align the Gloria Multi-Brush for Wood Surfaces with the attachment mechanism of your device.
4. Securely fasten the brush according to your device's instructions. Ensure it is firmly in place before operation.



Image 2.1: Close-up view of the brush bristles engaging with a wooden surface.

3. Operating Instructions

Once the brush is securely attached to your GLORIA MultiBrush or PowerBrush device, you can begin cleaning your wood surfaces.

1. **Preparation:** Clear the area of any large debris, loose leaves, or furniture. For best results, lightly wet the wooden surface before cleaning.
2. **Power On:** Turn on your GLORIA MultiBrush or PowerBrush device.
3. **Cleaning Technique:** Guide the device slowly and steadily over the wooden surface. Apply gentle, even pressure. The optimized brush profile is designed to clean grooves and gaps effectively.
4. **Direction:** For optimal cleaning and to avoid streaking, move the brush along the grain of the wood.
5. **Rinsing:** After brushing, rinse the cleaned surface with water to remove loosened dirt and debris.
6. **Repeat:** For heavily soiled areas, a second pass or application of a suitable wood cleaner (following its instructions) may be necessary.



Image 3.1: Demonstration of the brush's bristle flexibility.

4. Maintenance and Care

Proper maintenance ensures the longevity and effectiveness of your Gloria Multi-Brush.

- **Cleaning the Brush:** After each use, remove the brush from the device and rinse it thoroughly with clean water to remove any dirt, wood particles, or cleaning solution residue.
- **Drying:** Allow the brush to air dry completely before storing. Do not store the brush while wet, as this can lead to mildew or damage to the bristles.
- **Storage:** Store the brush in a clean, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the bristles for wear or damage. Replace the brush if bristles become excessively worn, bent, or damaged, as this can reduce cleaning performance and potentially harm surfaces.

5. Troubleshooting

If you encounter issues with your Gloria Multi-Brush, consider the following common solutions:

Problem	Possible Cause	Solution
Poor cleaning performance	Worn or damaged bristles; insufficient pressure; surface not pre-wetted.	Inspect brush and replace if necessary. Apply gentle, even pressure. Pre-wet the surface.
Brush not rotating properly	Improper installation; debris lodged in mechanism; device malfunction.	Ensure brush is securely attached. Remove any debris. Consult your GLORIA device manual for troubleshooting.
Streaking on wood surface	Cleaning against the wood grain; insufficient rinsing.	Always clean along the wood grain. Rinse the surface thoroughly after brushing.

If problems persist, refer to the instruction manual for your GLORIA MultiBrush or PowerBrush device or contact customer support.

6. Specifications

Feature	Detail
Brand	Gloria
Model Number	728833.0000
Item Type Name	for wood surfaces
Material Type	Nylon
Product Dimensions (L x W x H)	6.69" x 4.33" x 4.33" (16.5 x 10.5 x 11 cm)
Item Weight	0.48 Kilograms
Surface Recommendation	Floor (Wood surfaces like terraces and decking)
Product Firmness	Hard
Included Components	Brush

7. Warranty and Support

For warranty information regarding your GLORIA MultiBrush or PowerBrush device and its accessories, please refer to the documentation provided with your main device. For product support, technical assistance, or to inquire about replacement parts, please contact Gloria customer service through their official website or the contact information provided with your GLORIA device.
EU Spare Part Availability Duration: 1 Year

© 2023 Gloria. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question