Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Makita 643890-4

Makita 643890-4 Key Instruction Manual

Original Equipment Manufacturer (OEM) Replacement Part

1. Product Overview

The Makita 643890-4 Key is an Original Equipment Manufacturer (OEM) authorized replacement part designed for use with various Makita power tools. This key serves as a critical component for activating or deactivating specific equipment, ensuring proper and safe operation.



Figure 1: The Makita 643890-4 Key. This image displays the Makita 643890-4 Key. It is a red, plastic key featuring a rectangular handle at the top and a shaped shaft designed for insertion into compatible Makita tools. The key is an essential component for operating certain Makita equipment.

Key Features:

- Genuine Makita OEM part.
- Designed for compatibility with various Makita models.
- Durable plastic construction.
- Part Number: 643890-4.

2. Installation and Setup

This key is typically used to enable the operation of Makita power tools, often as a safety or ignition key. Ensure the tool is powered off and disconnected from any power source before installation.

1. **Identify the Key Slot:** Locate the designated key slot on your Makita tool. Refer to your tool's specific instruction manual for the exact location.
2. **Insert the Key:** Align the Makita 643890-4 Key with the key slot. Gently push the key into the slot until it is fully seated. Do not force the key if it does not fit smoothly.
3. **Verify Engagement:** Once inserted, the key should sit securely in the slot. Some tools may require a slight turn or click to fully engage.

> **Important:** Always ensure the key is correctly inserted before attempting to operate the tool. An improperly inserted key may prevent the tool from functioning or could lead to damage.

3. Operating Instructions

The Makita 643890-4 Key enables the functionality of your compatible Makita tool. Its primary function is to complete an electrical circuit or disengage a safety mechanism, allowing the tool to be powered on.

1. **Key Insertion:** As described in Section 2, ensure the key is fully and correctly inserted into its designated slot.
2. **Power On:** With the key inserted, proceed to power on your Makita tool according to its specific operating instructions (e.g., pressing a power button, engaging a switch).
3. **Key Removal (Safety):** For safety, always remove the key when the tool is not in use, during maintenance, or when storing the tool. This prevents accidental startup.

4. Maintenance

The Makita 643890-4 Key requires minimal maintenance to ensure its longevity and proper function.

- **Cleaning:** Periodically wipe the key with a clean, dry cloth to remove dust, dirt, or debris. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the key in a dry, safe place away from extreme temperatures and direct sunlight when not in use.
- **Inspection:** Regularly inspect the key for any signs of wear, cracks, or damage. If the key appears damaged, replace it immediately with a genuine Makita 643890-4 Key to ensure safe operation.

5. Troubleshooting

If your Makita tool does not operate after inserting the 643890-4 Key, consider the following:

- **Incorrect Key:** Verify that you are using the correct key for your specific Makita tool model. The 643890-4 key is designed for particular models and may not be universally compatible. Consult your tool's manual for the correct part number.
- **Improper Insertion:** Ensure the key is fully and correctly seated in the key slot. A partial insertion may not activate the tool.
- **Tool Power:** Check if the tool is receiving power (e.g., battery charged, power cord connected, circuit breaker not tripped).
- **Key Damage:** Inspect the key for any visible damage, such as cracks or deformities, which could prevent proper contact or engagement.
- **Tool Malfunction:** If the key is confirmed to be correct and properly inserted, and the tool has power, there may be an issue with the tool itself. Refer to your tool's service manual or contact Makita customer support.

6. Specifications

Brand	Makita
Part Number	643890-4
Item Weight	0.64 ounces
Product Dimensions	1 x 1 x 1 inches
Power Source	Manual
Voltage	0.1 Volts (for circuit completion)
Item Package Quantity	1
Batteries Required?	No

7. Warranty and Support

Specific warranty information for the Makita 643890-4 Key is typically covered under the warranty of the Makita tool it is designed for, or as a replacement part. Please refer to the warranty documentation provided with your original Makita tool or contact Makita customer service for details regarding replacement part warranties.

For further assistance, technical support, or to inquire about other genuine Makita parts, please visit the officiaMakita Store or contact Makita customer service directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B010BHT20A

More documents and user manuals: **https://manuals.plus/**