Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TOTO THP3063

TOTO THP3063 Air Pump and Soap Dispenser User Manual

Model: THP3063 | Brand: TOTO

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your TOTO THP3063 Air Pump and Soap Dispenser. Please read this manual thoroughly before use to ensure proper function and longevity of the product.

The TOTO THP3063 is designed to provide convenient and hygienic dispensing of soap and efficient air pumping for various applications. Its compact design makes it suitable for a range of environments.

2. Safety Information

- **Read all instructions:** Before operating the device, carefully read and understand all instructions in this manual.
- **Keep away from water:** Do not immerse the device in water or expose it to excessive moisture.
- **Use appropriate liquids:** Only use liquids recommended for soap dispensers. Avoid corrosive or abrasive substances.
- **Children and pets:** Keep the device out of reach of children and pets to prevent accidental ingestion of soap or misuse.
- **Power source:** If applicable, ensure the power source matches the device's requirements.
- **Maintenance:** Perform maintenance as described in this manual. Do not attempt to repair the device yourself. Contact qualified service personnel.

3. Package Contents

Verify that all components are present in the package:

- 1 x TOTO THP3063 Air Pump
- 1 x TOTO THP3063 Soap Dispenser
- 1 x User Manual (this document)
- Any additional mounting hardware (if applicable, not specified in product data)

4. Setup and Installation

The TOTO THP3063 is designed for easy setup. Follow these steps for proper installation:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Placement:** Choose a stable, flat surface for the dispenser and air pump. Ensure it is away from direct water spray and heat sources.
3. **Soap Dispenser Refill:**
    - Open the soap reservoir cap.
    - Pour liquid hand soap into the reservoir, being careful not to overfill.
    - Securely close the cap.
4. **Air Pump Connection (if applicable):** If the air pump requires external connection, follow the specific instructions provided with the air pump component. Ensure all connections are secure.
5. **Power Connection (if applicable):** If the device is battery-operated, insert the required batteries (not included, type not specified). If it is corded, plug the power adapter into a suitable electrical outlet.

5. Operating Instructions

5.1. Using the Soap Dispenser

1. Place your hand under the dispenser nozzle.
2. The dispenser will automatically dispense a measured amount of soap.
3. Remove your hand once soap is dispensed.

5.2. Using the Air Pump

1. Connect the appropriate nozzle or hose to the air pump outlet.
2. Activate the air pump (e.g., press a button, turn a switch).
3. Monitor the inflation process.
4. Deactivate the air pump once the desired pressure or inflation is achieved.

6. Maintenance

6.1. Cleaning

- Wipe the exterior of the device with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- For the soap dispenser, periodically clean the nozzle to prevent clogging.

6.2. Soap Refill

- When the soap level is low, refill the reservoir as described in the "Setup and Installation" section.
- Avoid mixing different types of soap without thoroughly cleaning the reservoir first.

7. Troubleshooting

Problem	Possible Cause	Solution
Soap not dispensing	Empty reservoir, clogged nozzle, low battery (if applicable)	Refill soap, clean nozzle, replace batteries.

Problem	Possible Cause	Solution
Air pump not working	No power, blocked intake/outlet, low battery (if applicable)	Check power connection, clear blockages, replace batteries.
Device leaks	Improperly closed cap, damaged seal	Ensure cap is tight, contact support if seal is damaged.

8. Specifications

- **Brand:** TOTO
- **Model Number:** THP3063
- **Included Components:** Air Pump, Soap Dispenser
- **Item Weight:** 6.4 ounces (0.4 Pounds)
- **Product Dimensions:** 10 x 4.38 x 3.63 inches
- **Material:** Plastic
- **UPC:** 739268273467

9. Warranty and Support

For warranty information, please refer to the manufacturer's official warranty statement. Details are typically available on the TOTO official website or included with your purchase documentation.

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact TOTO customer support through their official channels. Provide your model number (THP3063) and purchase date when contacting support.
Online Support: www.totousa.com/support (Example link, actual link may vary)

© 2025 TOTO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B010C6U60K

More documents and user manuals: **https://manuals.plus/**