Samsung SM-T710NZDEXAR

Samsung Galaxy Tab S2 8.0 SM-T710NZDEXAR User Manual

Model: SM-T710NZDEXAR

1. Introduction

This manual provides instructions for the Samsung Galaxy Tab S2 8.0 (model SM-T710NZDEXAR). This device is a thin and lightweight tablet designed for various tasks including viewing photos, movies, and documents. It features a Super AMOLED display and expandable memory. This guide covers initial setup, basic operation, maintenance, and troubleshooting.

Package Contents

- Samsung Galaxy Tab S2 8.0 Tablet
- USB Charging Cable
- Power Adapter
- Quick Start Guide (not this document)

2. Device Layout

Familiarize yourself with the physical components of your Samsung Galaxy Tab S2 8.0.



Image 2.1: Front view of the Samsung Galaxy Tab S2 8.0 tablet. The screen is visible, along with the front-facing camera and home button.

- **Front-facing Camera:** Located above the display, used for video calls and selfies.
- **Display:** 8.0-inch Super AMOLED touchscreen.
- **Home Button/Fingerprint Scanner:** Located below the display, used to return to the home screen and for biometric authentication.
- **Recent Apps Key:** Touch-sensitive button to the left of the Home button, displays recently used applications.
- **Back Key:** Touch-sensitive button to the right of the Home button, returns to the previous screen.
- **Power/Lock Button:** Located on the side, used to turn the device on/off or lock/unlock the screen.
- **Volume Buttons:** Located on the side, used to adjust media and notification volume.
- **Micro USB Port:** Located on the bottom, used for charging and data transfer.
- **Headphone Jack:** Located on the bottom, for connecting wired headphones.
- **MicroSD Card Slot:** Located on the side, for expanding storage capacity.
- **Rear-facing Camera:** Located on the back, used for taking photos and videos.

3. Initial Setup

Follow these steps for the first-time setup of your tablet.

1. **Charge the Device:** Connect the USB cable to the tablet's Micro USB port and the power adapter, then plug the adapter into a wall outlet. Allow the tablet to charge fully before first use.
2. **Power On:** Press and hold the Power/Lock button until the Samsung logo appears.
3. **Language Selection:** Follow the on-screen prompts to select your preferred language.
4. **Connect to Wi-Fi:** Select your Wi-Fi network from the list and enter the password if required. This is necessary for internet access and software updates.
5. **Google Account Setup:** Sign in with an existing Google account or create a new one. This account is essential for downloading apps from the Google Play Store and syncing data.
6. **Samsung Account (Optional):** You may be prompted to sign in or create a Samsung account for additional features and services.
7. **Fingerprint Setup (Optional):** Configure the fingerprint scanner for enhanced security.
8. **Complete Setup:** Follow any remaining on-screen instructions to finalize the setup process.

4. Operating Instructions

Basic Navigation

- **Touch Gestures:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** The central hub for your apps and widgets. Swipe left or right to access additional home screens.
- **Notification Panel:** Swipe down from the top of the screen to access notifications and quick settings.
- **App Drawer:** Access all installed applications by tapping the Apps icon on the home screen or swiping up from the bottom.

Connectivity

- **Wi-Fi:** To connect or manage Wi-Fi networks, go to *Settings > Connections > Wi-Fi*.
- **Bluetooth:** To pair with Bluetooth devices, go to *Settings > Connections > Bluetooth*.

Camera Usage

The tablet is equipped with both front and rear cameras.

1. **Open Camera App:** Tap the Camera icon on your home screen or in the App Drawer.
2. **Switch Cameras:** Tap the camera switch icon to toggle between the front and rear cameras.
3. **Take Photo/Record Video:** Tap the Shutter button to take a photo or the Record button to start/stop video recording.

5. Maintenance and Care

Cleaning

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.

Software Updates

Regularly check for and install software updates to ensure optimal performance and security. Go to *Settings > Software update > Download and install*.

Battery Care

- Use only Samsung-approved chargers and cables.
- Avoid exposing the tablet to extreme temperatures.
- For optimal battery longevity, avoid fully discharging the battery frequently.

6. Troubleshooting

This section addresses common issues you might encounter.

Tablet Does Not Turn On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power/Lock button for at least 10 seconds to perform a forced restart.

Screen Is Unresponsive

- Restart the tablet by holding the Power/Lock button.
- If the issue persists, perform a factory reset (*Note: This will erase all data on the device. Back up important data first.*).

Cannot Connect to Wi-Fi

- Ensure Wi-Fi is enabled in *Settings > Connections > Wi-Fi*
- Restart your Wi-Fi router.
- Forget the network and reconnect by re-entering the password.

Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data in *Settings > Apps > [App Name] > Storage*
- Ensure the app is updated to its latest version from the Google Play Store.

7. Specifications

Feature	Specification
Model Number	SM-T710NZDEXAR
Operating System	Android 5.0 (Lollipop)
Display	8.0" Super AMOLED, 2048x1536 (QXGA)
Processor	Quad 1.9GHz + Quad 1.3GHz Octacore
RAM	3 GB

Internal Storage	32 GB Flash Memory
Expandable Storage	MicroSD (up to 128GB)
Rear Camera	8 MP
Front Camera	Yes
Connectivity	Wi-Fi (802.11abg), Bluetooth, 3G, 4G LTE
Ports	Micro USB, 3.5mm Headphone Jack
Battery Capacity	15.4 Watt Hours (approx. 10 hours average life)
Weight	0.58 pounds (9.28 ounces)
Sensors	Ambient Light Sensor, Accelerometer, Gyroscope, Fingerprint Scanner

8. Warranty and Support

Warranty Information

The Samsung Galaxy Tab S2 8.0 (SM-T710NZDEXAR) comes with the following warranty coverage:

- **Labor:** 1 year coverage
- **Parts:** 1 year coverage
- **Battery:** 6 months coverage

Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

Customer Support

For further assistance, technical support, or warranty service, please visit the official Samsung support website or contact Samsung customer service. Refer to the official Samsung website for the most current contact information and support resources.

© 2026 Samsung. All rights reserved.