Whirlpool WOA105F

Whirlpool WOA105F 60cm (24-inch) Built-in Gas Oven User Manual

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new Whirlpool WOA105F 60cm Built-in Gas Oven. Please read these instructions thoroughly before using the appliance and retain them for future reference. Proper use and care will ensure optimal performance and extend the lifespan of your oven.

2. Safety Information

Your safety and the safety of others are paramount. Always adhere to the following safety precautions:

- **Gas Safety:** This appliance uses gas. Ensure proper ventilation and never store or use flammable materials near the oven. In case of a gas leak, do not operate electrical switches, extinguish any open flame, open windows and doors, and contact your gas supplier immediately.
- **Electrical Safety:** The oven requires a 120 Volt electrical connection. Ensure the appliance is properly grounded. Do not use extension cords. Disconnect power before servicing.
- **Burn Hazard:** The oven and its components become hot during use. Use oven mitts when handling hot items. Do not allow children to touch the oven during or immediately after operation.
- **Installation:** Installation must be performed by a qualified technician in accordance with all local codes and regulations.
- **Cleaning:** Always allow the oven to cool completely before cleaning. Use non-abrasive cleaners.

3. Product Overview

The Whirlpool WOA105F is a 60cm (24-inch) built-in gas oven designed for seamless integration into your kitchen. It features a sleek black finish with a Triple Glass Door for enhanced insulation and visibility.



Image 3.1: Front view of the Whirlpool WOA105F Built-in Gas Oven, showcasing its black finish, control knobs, stainless steel handle, and Triple Glass Door.

Key Features:

- **Triple Glass Door:** Provides superior heat retention and allows for clear viewing of food during cooking.
- **Electronic Ignition:** For convenient and reliable startup of the gas burner.
- **Stainless Steel Knobs:** Durable and easy-to-grip controls for temperature and function selection.
- **Thermostat:** Maintains precise temperature control for consistent cooking results.
- **Interior Light:** Illuminates the oven cavity for better visibility.
- **Grill and Tray:** Included accessories for versatile cooking options.
- **Gas Cut-off Valve:** An integrated safety feature to automatically shut off the gas supply if an issue is detected.

4. Installation

The Whirlpool WOA105F oven is designed for built-in installation. Due to the nature of gas and electrical connections, professional installation is mandatory to ensure safety and compliance with local building codes.

Installation Guidelines:

- **Location:** Choose a location that allows for proper ventilation and access for servicing. Ensure sufficient clearance from combustible materials.
- **Dimensions:** The oven dimensions are approximately 60 x 63 x 85 cm. Ensure the cabinet opening meets these requirements for a proper fit.
- **Gas Connection:** A qualified gas technician must connect the oven to the gas supply line. Ensure all connections are leak-tested.
- **Electrical Connection:** The oven requires a 120 Volt electrical supply. A dedicated, grounded circuit is recommended. The electrical connection should also be performed by a qualified electrician.
- **Leveling:** Ensure the oven is level after installation to prevent uneven cooking and ensure proper door operation.

Refer to the detailed installation instructions provided with the physical product for specific measurements and procedures.

5. Operation

Familiarize yourself with the control panel and functions before first use.

Control Knobs:

- **Temperature Control Knob:** Used to set the desired oven temperature. Rotate to the desired setting.
- **Function Selector Knob:** Used to select cooking modes such as baking or grilling.
- **Timer Knob (if applicable):** Some models may include a mechanical timer.

Starting the Oven:

1. Open the oven door slightly.
2. Push in and turn the Function Selector Knob to the desired cooking mode (e.g., Bake).
3. Push in and turn the Temperature Control Knob to the desired temperature. The electronic ignition will activate, and you will hear a clicking sound.
4. Hold the knob in for a few seconds after the burner ignites to allow the thermocouple to heat up and ensure the flame remains lit. Release the knob slowly.
5. Close the oven door. The interior light can be turned on/off via a separate switch or automatically with door opening/closing, depending on the model.

Using the Grill:

To use the grill function, select the grill mode using the Function Selector Knob. Position food on the grill rack, ensuring adequate distance from the heating element to prevent burning.

Gas Cut-off Valve:

The integrated gas cut-off valve is a safety feature. If the flame extinguishes unexpectedly, the valve will automatically shut off the gas supply. If this occurs, wait a few minutes before attempting to re-ignite the oven.

6. Maintenance and Cleaning

Regular cleaning and maintenance will keep your oven in optimal condition.

General Cleaning:

- Always ensure the oven is cool and disconnected from the power supply before cleaning.
- Use a soft cloth and mild detergent for exterior surfaces. Avoid abrasive cleaners that can scratch the black finish or stainless steel.
- For stubborn stains, use a non-abrasive oven cleaner specifically designed for gas ovens, following the product instructions carefully.

Cleaning the Triple Glass Door:

Clean the glass door with a glass cleaner or a solution of warm water and mild soap. Wipe dry with a soft, lint-free cloth to prevent streaks.

Cleaning Interior, Grill, and Tray:

Remove the grill and tray for easier cleaning. Wash them in warm, soapy water or in a dishwasher if they are dishwasher-safe. For the oven interior, wipe down with a damp cloth and mild detergent. For baked-on food, use an oven cleaner as directed.

7. Troubleshooting

If you encounter issues with your oven, consult the following troubleshooting guide before contacting service.

Problem	Possible Cause	Solution
Oven does not ignite or flame goes out.	No gas supply, ignition issue, or gas cut-off valve activated.	Check gas supply valve. Ensure knob is held in long enough during ignition. Wait a few minutes before re-igniting if gas cut-off activated. If problem persists, contact service.
Interior light not working.	Light bulb is faulty or loose.	Ensure oven is cool and power is disconnected. Check if the bulb is securely screwed in. Replace bulb if necessary (refer to manual for bulb type).
Uneven cooking.	Oven not level, improper rack placement, or door seal issue.	Ensure oven is level. Use appropriate rack positions. Check door seal for damage.
Excessive smoke or odor during cooking.	Food spills, grease buildup, or new oven burn-off.	Clean oven interior thoroughly. For new ovens, run an empty cycle at high temperature for an hour to burn off manufacturing residues. Ensure proper ventilation.

If the problem persists after attempting these solutions, please contact Whirlpool customer service or a qualified technician.

8. Specifications

Feature	Specification
Brand	Whirlpool
Model Number	WOA105F
Type	Built-in Gas Oven
Color	Black

Feature	Specification
Dimensions (W x D x H)	60 x 63 x 85 cm (approximately 24 x 25 x 33 inches)
Weight	25 kg (approximately 55 lbs)
Power	2500.00 (unit not specified, typically Watts for electric components or BTU for gas)
Voltage	120 Volts
Material	Steel

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product at the time of purchase. Whirlpool provides customer support for assistance with product inquiries, troubleshooting, and service requests.

To contact Whirlpool customer service, please visit the official Whirlpool website or refer to the contact information provided in your product documentation.

© 2023 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question