Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HQRP 884667807291506

HQRP Replacement Remote Control User Manual

Model: 884667807291506

1. Overview

This manual provides instructions for the HQRP Replacement Remote Control, designed to work seamlessly with various LG LCD LED HD Smart TVs. This remote is pre-programmed and requires no complex setup, allowing for immediate use.

Compatible LG TV Models include:

- LG 55LB6300
- LG 47LB6350
- LG 55LB6350
- LG 60LB7100
- LG 65LB7100
- LG 70LB7100
- LG 55LB7200



Figure 1.1: HQRP Replacement Remote Control in its retail packaging, accompanied by two AAA batteries.

2. Setup

2.1 Battery Installation

The HQRP Replacement Remote Control operates on two AAA batteries. These batteries are typically included with your purchase.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: This remote control is pre-programmed and does not require any additional programming steps after battery installation. It is ready for immediate use with compatible LG TVs.





Figure 2.1: Rear view of the remote control, illustrating the battery compartment and product information.





Figure 2.2: Packaging detail highlighting the "No Setup Required!" feature of the remote control.

3. Operation

The HQRP Replacement Remote Control functions identically to your original LG TV remote. Point the remote directly at your television and press the desired buttons to control its functions.





Figure 3.1: Front view of the HQRP remote control, displaying the layout of all functional buttons.

3.1 Key Functions

Below is a general guide to the common functions of the remote control buttons. Specific button labels and their exact functions may vary slightly based on your LG TV model.

Button	Function
Power (Red)	Turns the TV On or Off.
Source / Input	Selects the input source (HDMI, AV, Component, etc.).
Number Buttons (0-9)	Direct channel selection.
Volume Up/Down (+/-)	Adjusts the volume level.
Channel Up/Down (CH +/-)	Changes TV channels.
Mute	Mutes or unmutes the TV sound.
Navigation Pad (Up, Down, Left, Right, OK)	Navigates menus and confirms selections.
Home / Smart	Accesses the Smart TV home screen or main menu.
Back / Return	Returns to the previous screen or menu.
Exit	Exits the current menu or application.
Menu / Settings	Opens the TV's settings or options menu.
Play/Pause, Stop, Rewind, Fast Forward	Controls media playback (e.g., USB, streaming apps).
Color Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions within menus or applications.

4. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environment:** Avoid exposing the remote control to extreme temperatures, direct sunlight, high humidity, or water.

5. Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

1. **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new AAA batteries.
2. **Line of Sight:** Make sure there are no obstructions between the remote control and the TV's infrared sensor. Point the remote directly at the TV.
3. **Infrared Interference:** Bright lights, especially fluorescent or LED lighting, can sometimes interfere with the remote's signal. Try turning off or dimming such lights.
4. **TV Power Cycle:** Turn off your TV at the main power outlet, wait for 30 seconds, then plug it back in and try the remote again.
5. **Remote Reset (if applicable):** While this remote is pre-programmed, if you suspect an issue, some remotes can be reset by removing batteries for a few minutes and then reinserting them.

If the problem persists after trying these steps, please refer to the warranty and support information.

6. Specifications

Feature	Detail
Brand	HQRP
Model Number	884667807291506
Compatible Devices	LG LCD LED HD Smart Televisions (specific models listed in Overview)
Connectivity Technology	Infrared (IR)
Special Features	Pre-programmed, No setup required
Power Source	2 x AAA Batteries (included)
Max Supported Devices	1 (Television)

7. Warranty and Support

This HQRP Replacement Remote Control comes with a**100 Days Warranty** from the date of purchase.

For warranty claims or technical support, please contact HQRP customer service through the retailer where the product was purchased or refer to the contact information provided with your product packaging.

© 2023 HQRP. All rights reserved.

LG is a registered trademark of LG Corp. This product is a compatible replacement and not an original LG product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B013C8BA50

More documents and user manuals: **https://manuals.plus/**