MEDION MSN40033400

Original MEDION Remote Control User Manual

Model: MSN40033400, RC1231

Introduction

This user manual provides comprehensive instructions for the original MEDION Remote Control, model MSN40033400 (RC1231). This remote is designed for use with compatible Medion televisions and offers infrared connectivity for reliable operation. Please read this manual carefully to ensure proper use and maintenance of your remote control.

Product Overview



Figure 1: Original MEDION Remote Control (MSN40033400)
This image displays the full layout of the remote control, highlighting its dual-tone design and the arrangement of its various function buttons, including power, input selection, numeric keypad, navigation, volume, channel, and playback controls.

Setup

Battery Installation

The MEDION remote control requires batteries for operation. Follow these steps to install or replace the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert the required number of batteries (typically AAA or AA, refer to the compartment for specific type) ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

Note: Always use new batteries of the specified type. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote control will not be used for an extended period.

Operating Instructions

This section details the functions of the various buttons on your MEDION remote control.

Power and Input Selection Buttons

- **Power ( )**: Turns the connected Medion television on or off.
- **TV**: Selects the TV input source.
- **SAT**: Selects the Satellite input source.
- **DVD**: Selects the DVD input source.
- **VCR**: Selects the VCR input source.
- **AUX**: Selects the Auxiliary input source.

Numeric Keypad and Channel Navigation

- **0-9 (Numeric Buttons)**: Used to directly enter channel numbers or menu options.
- **AV**: Switches between available Audio/Video input sources.
- **-/--**: Used for entering two-digit channel numbers or for specific menu functions.
- **EPG**: Displays the Electronic Program Guide (if supported by the TV).
- **P+ / P- (Channel Up/Down)**: Changes the television channel up or down.

Navigation and Confirmation Buttons

- **Directional Arrows (▲, ▼, ◄, ►)**: Navigates through menus and options.
- **OK**: Confirms a selection or enters a menu item.
- **MENU**: Opens the main menu of the television.
- **RETURN**: Returns to the previous menu or screen.
- **EXIT**: Exits the current menu or function.

Volume and Mute Controls

- **Volume + / -**: Increases or decreases the audio volume.
- **Mute ( )**: Mutes or unmutes the television audio.

Special Function Buttons

- **PIP**: Activates Picture-in-Picture mode (if supported).
- **SLEEP**: Sets a sleep timer for the television.
- **SUBTITLE**: Toggles subtitles on or off.

- **SCREEN**: Adjusts screen display modes or aspect ratio.
- **PRESETS**: Accesses preset channels or settings.
- **CODE**: Used for programming or entering codes (if applicable for universal functions).
- **LANG**: Changes the audio language or subtitle language.
- **FAV**: Accesses favorite channels list.
- **TEXT**: Opens Teletext or other text-based services.
- **INFO**: Displays information about the current program or input.
- **SWAP**: Swaps between two previously viewed channels.

Media Playback Controls

- **Rewind ( )**: Rewinds media playback.
- **Play (▶)**: Starts or resumes media playback.
- **Fast Forward ( )**: Fast forwards media playback.
- **Stop ( )**: Stops media playback.
- **Pause ( )**: Pauses media playback.
- **Record ( )**: Initiates recording (if supported by connected device).

Maintenance

Cleaning the Remote Control

To maintain the appearance and functionality of your remote control:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, abrasive cleaners, or solvents as they may damage the remote's finish or internal components.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If not used for a long period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote control range is poor.	Weak batteries; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries; Remove any objects blocking the line of sight; Ensure TV's IR sensor is clear.
Specific buttons not responding.	Remote control is in the wrong mode (e.g., DVD mode for TV functions); Button is stuck or damaged.	Press the correct input selection button (e.g., TV button); Gently clean around the button; If damaged, consider replacement.

Specifications

- **Model Number**: MSN40033400
- **Compatible Devices**: Medion Televisions
- **Connectivity Technology**: Infrared
- **Controller Type**: Button Control
- **Maximum Range**: 10 Meters
- **Battery Description**: Alkali
- **Manufacturer**: Medion

Warranty and Support

This product is an original MEDION accessory. For warranty information and technical support, please refer to the documentation provided with your Medion television or contact MEDION customer service directly. Details can typically be found on the official MEDION website or through their support channels.
Manufacturer: MEDION
ASIN: B013M8UY3Y

© 2024 MEDION. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question