Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi PRO1847X

De'Longhi PRO1847X Continuous Charge Ironing System User Manual

1. Introduction

This manual provides essential instructions for the safe and efficient use of your De'Longhi PRO1847X Continuous Charge Ironing System. Please read all instructions carefully before using the appliance and retain this manual for future reference. This ironing system is designed for domestic use to iron various fabrics using steam and heat.

2. Safety Instructions

- Always ensure the voltage indicated on the rating plate corresponds to your mains voltage.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children and individuals with reduced physical, sensory, or mental capabilities.
- Never leave the iron unattended while it is switched on or connected to the mains.
- Exercise caution when handling hot surfaces and steam. Steam can cause burns.
- Unplug the appliance from the mains socket before filling with water, cleaning, or when not in use.
- Do not operate the appliance with a damaged cord or plug, or if it has been dropped or damaged in any way.
- Place the iron on a stable, heat-resistant surface when resting.
- Only use distilled or demineralized water to prevent limescale buildup.

3. Product Overview

Familiarize yourself with the components of your De'Longhi PRO1847X ironing system.



Figure 1: Overall view of the De'Longhi PRO1847X Continuous Charge Ironing System, showcasing the iron, base unit, and controls.



Figure 2: Side view of the ironing system, highlighting the compact design of the base unit.



Figure 3: Close-up of the Anti-Calc System cap, indicating its location for maintenance.



Figure 4: The iron's soleplate actively emitting steam, demonstrating its powerful steam output.



Figure 5: Illustration of filling the water tank, showing the designated opening for water input.



Figure 6: Detailed view of the iron's soleplate, highlighting the steam holes for even steam distribution.

4. Setup

1. **Unpacking:** Carefully remove the ironing system from its packaging. Retain the packaging for storage or transport.
2. **Positioning:** Place the base unit on a stable, flat, and heat-resistant surface, such as an ironing board designed for steam generators.
3. **Filling the Water Tank:**
    - Ensure the appliance is unplugged.
    - Open the water tank cap (refer to Figure 5).
    - Fill the tank with clean, distilled or demineralized water up to the maximum level indicator. Do not overfill.
    - Close the water tank cap securely.
4. **Initial Use:** For the first use, iron an old piece of fabric to remove any manufacturing residues from the soleplate. Some steam or odor may be emitted initially; this is normal.

5. Operating Instructions

1. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet (220-240V, 50/60Hz).
2. **Power On:** Switch on the appliance using the power button. The indicator light will illuminate.
3. **Temperature and Steam Selection:**
    - Adjust the temperature dial on the iron to the desired setting according to the fabric type.
    - Wait for the temperature indicator light to turn off, signaling that the iron has reached the selected temperature.
    - Press the steam button on the iron handle to activate steam. For continuous steam, engage the steam lock if available.
4. **Continuous Charge Feature:** The continuous charge system allows you to refill the water tank at any time during ironing without waiting for the appliance to cool down. Simply unplug, refill as per Section 4, and resume ironing.
5. **Ironing:** Begin ironing your garments. For stubborn creases, use bursts of steam.
6. **After Use:**
    - Switch off the appliance and unplug it from the mains.
    - Allow the iron to cool down completely before storing.
    - Empty any remaining water from the tank.

6. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your ironing system.

1. **Cleaning the Soleplate:**
    - Ensure the iron is cool and unplugged.
    - Wipe the soleplate with a damp cloth and a non-abrasive liquid cleaner. Do not use abrasive pads or metallic scourers.
2. **Anti-Calc System (Descaling):**
    - The PRO1847X features an Anti-Calc System to reduce limescale buildup (refer to Figure 3).
    - Periodically, when the appliance is cool, unscrew the Anti-Calc cap.
    - Clean any visible limescale deposits from the cap and the opening.
    - Rinse the cap and screw it back on tightly.
    - For thorough descaling, follow the specific instructions provided in the full product manual, which may involve a descaling solution.
3. **Cleaning the Exterior:** Wipe the exterior of the base unit and iron with a soft, damp cloth.
4. **Storage:** Store the cooled appliance in a dry place. Use the retractable cord feature for neat storage.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam produced	Water tank empty; Iron not hot enough; Steam button not pressed.	Refill water tank; Wait for temperature indicator to turn off; Press steam button.

Problem	Possible Cause	Solution
Water leaking from soleplate	Iron temperature too low for steam; Overfilled water tank.	Increase iron temperature; Do not overfill water tank.
White flakes on clothes	Limescale buildup.	Perform descaling procedure (refer to Section 6). Use distilled water.
Iron not heating	Not plugged in; Power switch off; Faulty outlet.	Check power connection; Turn on power switch; Test outlet with another appliance.

8. Specifications

- **Model:** PRO1847X
- **Brand:** De'Longhi
- **Power:** 2200 Watts
- **Voltage:** 220 - 240 Volts AC
- **Frequency:** 50/60 Hz
- **Pressure:** 6 Bars
- **Water Tank Capacity:** 1.1 Litres
- **Dimensions (L x W x H):** 35.2 x 24.3 x 20.8 cm
- **Item Weight:** 5.75 Kilograms
- **Soleplate Material:** Aluminium
- **Special Features:** Retractable cord, Water tank, Continuous charge system
- **Automatic Shut-off:** No

9. Warranty and Support

This De'Longhi PRO1847X ironing system is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. For technical assistance, spare parts, or to report a fault, please contact De'Longhi customer support in your region. Contact information can typically be found on the De'Longhi official website or on your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B014FNI8X8

More documents and user manuals: **https://manuals.plus/**