Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tinkle 1

Tinkle Dermaplaning Tool User Manual

Brand: Tinkle | Model: 1

1. Product Overview

The Tinkle Dermaplaning Tool is a single-blade razor designed for gentle dermaplaning, eyebrow shaping, and fine hair removal. It helps to smooth the skin and prepare it for makeup application, contributing to a younger-looking complexion.



Figure 1: The Tinkle Dermaplaning Tool, available in a 6-count pack, featuring razors in pink, teal, and yellow, each with a protective safety cover.

Key Features:

- **Authentic Tinkle Eyebrow Razor:** Single-blade design for precise shaping and fine hair removal.
- **Smooth and Bright Skin:** Sharp, rust-free blades designed for a clean shave, minimizing nicks and cuts.
- **Refine Your Look:** Effective for removing unwanted hair from eyebrows, face, and neck, aiding in smoother makeup application and promoting even-toned skin.
- **Painless Design:** Features sharp yet safe blades suitable for sensitive skin, removing excess hair without irritation.
- **Easy and Safe to Carry:** Compact and discreet design with an anti-slip soft grip for precise control and portability. Includes a protective cover for safety.

2. Safety Information

This product is for external use only. Exercise caution when handling the sharp blade. Keep out of reach of children.

3. Setup

The Tinkle Dermaplaning Tool comes pre-assembled and ready for use. Simply remove a razor from its packaging and ensure the protective safety cap is in place until ready to use.



Figure 2: The Tinkle Dermaplaning Tool with its safety blade cover and protective cap, designed for safe handling and storage.

4. Operating Instructions

Follow these steps for effective and safe use of your Tinkle Dermaplaning Tool:

1. **Preparation:** Ensure your skin is clean and dry before use. For dermaplaning, some users prefer to apply a facial oil or serum to help the blade glide smoothly.
2. **Remove Safety Cap:** Carefully remove the transparent safety cap from the razor blade.
3. **Positioning:** Hold the dermaplaning tool at a 45-degree angle against your skin.
4. **Gentle Strokes:** Use short, gentle, downward strokes in the direction of hair growth. Avoid applying excessive pressure.
5. **Target Areas:**
    - **Eyebrows:** Gently shape eyebrows by removing stray hairs around the brow line.
    - **Face (Peach Fuzz):** Carefully glide the razor over areas with peach fuzz, such as the cheeks, forehead, and upper lip.
    - **Neck:** Use to remove fine hairs on the neck area for a smoother appearance.
6. **Post-Use:** After use, clean the blade and replace the safety cap. Dispose of the razor responsibly once it becomes dull or after a few uses to maintain hygiene and effectiveness.



Figure 3: Demonstrating the use of the Tinkle Dermaplaning Tool for eyebrow shaping.



Figure 4: The Tinkle Dermaplaning Tool is a versatile multi-function shaving tool suitable for various areas including peach fuzz, arms, legs, and bikini line.

5. Maintenance

To ensure the longevity and hygiene of your Tinkle Dermaplaning Tool:

- **Cleaning:** After each use, gently wipe the blade with a soft cloth or tissue to remove any hair or skin debris. You may also rinse it under running water, ensuring to dry it thoroughly immediately to prevent rust.
- **Storage:** Always replace the protective safety cap after cleaning. Store the razors in a dry, clean place away from humidity to maintain blade sharpness and prevent corrosion.
- **Disposal:** For optimal performance and hygiene, it is recommended to dispose of the razor after 2-3 uses or when the blade feels dull.

6. Troubleshooting

If you encounter any issues while using the Tinkle Dermaplaning Tool, consider the following:

- **Dull Blade:** If the razor is not effectively removing hair or feels like it's pulling, the blade may be dull. Replace it with a new one from the pack.
- **Skin Irritation:** Ensure you are holding the razor at the correct 45-degree angle and using light, gentle strokes. Avoid going over the same area multiple times. If irritation persists, discontinue use.
- **Ineffective Hair Removal:** Make sure your skin is taut and clean. The blade works best on dry skin.

7. Specifications

Feature	Detail
Brand	Tinkle
Model Number	1
Product Dimensions	3.07 x 10.63 x 0.28 inches
Item Weight	1.76 ounces
Number of Blades	1
Unit Count	6.00 Count
Special Feature	Ergonomic
Skin Type	Normal
UPC	748616614418, 089999282239, 087778383900, 741533875986, 880010576975



Figure 5: Dimensions of the Tinkle Dermaplaning Tool, showing its compact and lightweight design.

8. Warranty and Support

For any questions, concerns, or support regarding your Tinkle Dermaplaning Tool, please refer to the product packaging for manufacturer contact information or visit the official Tinkle brand website.

© 2025 Tinkle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B014HNOXZS

More documents and user manuals: **https://manuals.plus/**