Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CorningWare A-1-B

CorningWare Blue Cornflower 1 Quart Casserole Dish Instruction Manual

Model: A-1-B

Introduction

This manual provides essential information for the safe and effective use and care of your Vintage CorningWare Blue Cornflower 1 Quart Casserole Dish, Model A-1-B. This classic bakeware item is designed for versatile use in your kitchen.



Image of the Vintage Corningware Blue Cornflower 1 Quart Casserole Dish, featuring the iconic blue cornflower pattern on a white glass background. This dish is a 1-quart capacity, square shape, and does not include a lid.

Safety Information

- Always handle hot bakeware with oven mitts or pot holders.
- Avoid sudden temperature changes. Do not place a hot dish directly into cold water or onto a cold surface, and vice-versa, as this can cause thermal shock and breakage.
- Inspect the dish for any chips or cracks before each use. Do not use if damaged.
- This dish is designed for oven and microwave use. Refer to the "Operating Instructions" for specific usage guidelines.

Setup and First Use

1. **Unpacking:** Carefully remove the casserole dish from its packaging.

2. **Initial Cleaning:** Before first use, wash the dish thoroughly with warm, soapy water. Rinse completely and dry with a soft cloth.
3. **Inspection:** Check the dish for any manufacturing defects or damage.

Operating Instructions

Oven Use

- The CorningWare casserole dish is oven safe. It can be used in conventional and convection ovens.
- Preheat your oven before placing the dish inside.
- Avoid placing the dish directly under a broiler element, as extreme direct heat can cause damage.

Microwave Use

- This dish is safe for microwave use.
- Ensure there are no metallic elements or accessories attached to the dish when using in a microwave.

Storage and Serving

- The dish can be used for serving directly from the oven to the table.
- Allow the dish to cool down before refrigerating or freezing leftovers.

Maintenance and Care

Cleaning

- **Hand Washing:** For best results and to preserve the finish, hand wash the dish with warm, soapy water and a non-abrasive sponge or cloth.
- **Dishwasher Use:** The dish is dishwasher safe. Place it on the top rack if possible to prevent chipping from other items.
- For stubborn food residue, soak the dish in warm, soapy water before cleaning. Avoid using abrasive cleaners, scouring pads, or metal utensils that could scratch the surface.

Storage

- Store the dish in a dry place.
- When stacking, place a soft cloth or paper towel between dishes to prevent scratching.

Troubleshooting

Issue	Possible Cause	Solution
Dish breaks or cracks during use	Thermal shock (sudden temperature change) or impact damage.	Avoid extreme temperature changes. Do not use if chipped or cracked.
Food sticking to the surface	Insufficient greasing or high cooking temperature.	Ensure adequate greasing before adding food. Soak in warm, soapy water to loosen stuck food.
Stains or discoloration	Prolonged exposure to certain foods or hard water.	Use a non-abrasive cleaner designed for glass bakeware. A paste of baking soda and water can help.

Specifications

Feature	Detail
Model Number	A-1-B
Brand	CorningWare
Collection/Pattern	Blue Cornflower / Centura, Blue Floral On White, Coupe Shape
Material	Glass
Capacity	1 Quart
Shape	Square
Dimensions (L x W x H)	7 x 7 x 2 inches
Item Weight	1.5 pounds
Oven Safe	Yes
Microwave Safe	Yes
Dishwasher Safe	Yes
Lid Included	No
Manufacture Year (Approx.)	1957 - 1988 (Specific item: 1967)

Support Information

For further assistance or inquiries regarding your CorningWare product, please refer to the official CorningWare website or contact their customer service. As this is a vintage item, specific support may vary.

Note: This manual provides general guidelines. Actual performance may vary based on individual usage and care.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B014LN6XOS

More documents and user manuals: **https://manuals.plus/**