Marathon CL030050-GG-00-NA

MARATHON Digital Desktop Clock User Manual

Model: CL030050-GG-00-NA

Introduction

This manual provides instructions for the setup, operation, and maintenance of your MARATHON Digital Desktop Clock. This compact and lightweight clock features a large, easy-to-read display, dual alarm functionality, temperature and date display, and a button-activated backlight. It is designed for use on a desk or nightstand.



Figure 1: MARATHON Digital Desktop Clock in use.

Setup

1. Battery Installation

The clock requires 3 AAA batteries (not included). To install:

1. Locate the battery compartment cover on the back of the clock.
2. Slide the cover open.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover.



Figure 2: Rear view of the clock with battery compartment and control buttons.

2. Initial Power On

Upon battery installation, the clock will power on and display default settings. You will need to set the current time, date, and alarm preferences.

Operating Instructions

1. Setting Time and Date

Use the buttons on the back of the clock (refer to Figure 2 for button layout):

1. Press and hold the **MODE** button until the time display flashes.
2. Use the **UP** (▲) and **DOWN** (▼) buttons to adjust the flashing value.
3. Press **MODE** again to confirm the setting and move to the next adjustable item (e.g., hours, minutes, 12/24 hour format, year, month, day, language).
4. Repeat steps 2 and 3 until all desired settings are configured.
5. The clock supports 12 or 24-hour time format and displays the day of the week in seven languages: English, Dutch, French, Spanish, Italian, Danish, and German.

2. Setting Alarm

The clock features a dual alarm function for weekdays and weekends:

1. Press and hold the **ALARM SET** (bell icon) button until the alarm time flashes.
2. Use the **UP** (▲) and **DOWN** (▼) buttons to set the desired alarm time.
3. Press **ALARM SET** again to confirm and move to the weekday/weekend alarm selection.
4. Use the **UP** (▲) and **DOWN** (▼) buttons to select between weekday (1-5) and weekend (6-7) alarms.
5. Press **ALARM SET** to exit alarm setting mode.
6. To activate/deactivate an alarm, briefly press the **ALARM SET** button. An alarm icon will appear/disappear on the display.

3. Temperature Display

The clock displays indoor temperature. To switch between Fahrenheit (℉) and Celsius (℃):

- Locate the **C/F** button on the back of the clock (refer to Figure 2).
- Press the **C/F** button to toggle between the two temperature units.

4. Backlight Function

The clock features a vibrant blue backlight for enhanced visibility in low light conditions:

- Press the **SNOOZE/LIGHT** button located on the top of the clock.
- The backlight will illuminate for approximately 10 seconds.



Figure 3: Clock display with activated blue backlight.

Maintenance

1. Battery Replacement

When the display becomes dim or the clock functions erratically, it is time to replace the batteries. Follow the battery installation steps in the Setup section.

2. Cleaning

To clean the clock, use a soft, dry cloth. Avoid using abrasive cleaners or chemical solvents, as these may damage the display or casing.

Troubleshooting

- **Blank or Dim Display:** Check if the batteries are correctly installed and have sufficient charge. Replace batteries if necessary.
- **Incorrect Time/Date:** Reset the time and date settings following the Operating Instructions. If the issue persists, try replacing the batteries.
- **Alarm Not Sounding:** Ensure the alarm is activated (alarm icon visible on display) and the alarm time is correctly set.
- **Temperature Reading Inaccurate:** The internal thermometer provides an approximate indoor temperature. Ensure the clock is not placed near heat sources or in direct sunlight, which can affect readings.

Specifications

Feature	Detail
Model Number	CL030050-GG-00-NA
Display Type	Digital
Product Dimensions	3.7"W x 3.7"H (9.4 cm x 9.4 cm)
Power Source	Battery Powered (3 AAA batteries required)
Special Features	Alarm with Snooze, Backlight, Temperature Display (°F/°C), Date Display, 7-Language Day of Week
Mounting Type	Tabletop
Material	Plastic



Figure 4: Product dimensions.

Warranty and Support

This MARATHON Digital Desktop Clock comes with a**1-year limited warranty**. For warranty claims, technical support, or further assistance, please refer to the contact information provided with your product packaging or visit the official Marathon Watch website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question