Bajaj 410175

Bajaj Bravo Dlx Mixer Grinder User Manual

Model: 410175

1. Introduction

Thank you for choosing the Bajaj Bravo Dlx Mixer Grinder. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before using the mixer grinder and retain them for future reference.

2. Safety Instructions

To prevent injury or damage, always follow these basic safety precautions:

- Read all instructions before use.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving blades during operation to prevent personal injury and damage to the mixer grinder.
- Never operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not allow the cord to hang over the edge of a table or counter, or touch hot surfaces.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Initial Use:** It is normal to experience a slight burning smell during the first few uses. This is due to the motor varnish heating up and will dissipate with subsequent use. If the smell persists, contact customer support.

- **Noise Level:** Mixer grinders operate with a powerful motor, which generates some noise. If the noise level seems abnormal or excessive, discontinue use and contact customer support.

3. Product Overview

The Bajaj Bravo Dlx Mixer Grinder is designed for efficient grinding and blending. It includes a powerful motor unit and three versatile stainless steel jars.



Product Overview: Bajaj Bravo Dlx Mixer Grinder with three stainless steel jars.

Components:

- **Motor Unit:** The main power unit with a 500-watt motor and speed control knob.
- **1.3 Litre Liquidizing Jar:** For blending liquids, making purees, and larger quantities.
- **1 Litre Grinding Jar:** For dry and wet grinding tasks.
- **0.3 Litre Chutney Jar:** Ideal for small quantities of spices, chutneys, and pastes.
- **Lids:** Polycarbonate lids for each jar to prevent spillage during operation.

- **Blades:** Durable stainless steel 2-in-1 functional blades for efficient processing.



The three stainless steel jars included with the mixer grinder: liquidizing, grinding, and chutney jars.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Clean:** Before first use, wash the jars, lids, and blades with warm soapy water. Rinse thoroughly and dry. Wipe the motor unit with a damp cloth.
3. **Placement:** Place the motor unit on a clean, dry, stable, and flat surface, away from the edge of the counter. Ensure there is adequate ventilation around the unit.
4. **Attach Jar:** Select the appropriate jar for your task. Place the jar onto the motor unit, aligning the locking grooves. Turn the jar clockwise until it locks securely into place.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet.



The motor unit of the Bajaj Bravo Dlx Mixer Grinder, showing the speed control knob and sturdy base.

5. Operating Instructions

The Bajaj Bravo Dlx Mixer Grinder features a powerful 500-watt motor with an efficiency of 20,000 RPM for quick and effective processing.

1. **Prepare Ingredients:** Cut ingredients into small pieces before placing them into the jar. Do not overload the jar beyond its maximum capacity mark.
2. **Secure Lid:** Place the lid firmly on the jar. Ensure it is properly seated to prevent spillage during operation.
3. **Select Speed:** Turn the control knob to the desired speed setting (1, 2, or 3). Start with a lower speed and gradually increase if needed. For quick bursts, use the pulse function (if available, typically by holding the knob at a specific position).
4. **Operate:** Allow the mixer grinder to run until the desired consistency is achieved. Avoid continuous operation

for more than 3-5 minutes to prevent motor overheating. Allow a cooling period between cycles.

5. **Switch Off:** Once done, turn the control knob to the '0' (off) position and unplug the appliance.
6. **Remove Jar:** Wait for the blades to stop completely before removing the lid and then the jar by turning it counter-clockwise.



The 1.3-liter liquidizing jar with its handle and lid, designed for larger quantities.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your mixer grinder.

- **Unplug:** Always ensure the appliance is unplugged before cleaning.
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
- **Jars and Lids:** The stainless steel jars and polycarbonate lids are washable. Wash them with warm soapy

water immediately after use to prevent food from drying on. Rinse thoroughly and dry completely before storing.

- **Blades:** Handle blades with extreme care as they are sharp. Clean them using a brush or sponge, avoiding direct contact with fingers.
- **Storage:** Store the mixer grinder and its accessories in a clean, dry place.

7. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer grinder does not start.	Not plugged in; power outage; jar not locked correctly; motor overheated.	Check power connection; ensure jar is securely locked; allow motor to cool down for 15-20 minutes if it has been running continuously.
Burning smell during initial use.	Motor varnish heating up for the first time.	This is normal and will subside after a few uses. If it persists, contact service.
Excessive noise during operation.	Normal operation for a powerful motor; jar not seated properly; blades obstructed.	Ensure jar is correctly locked; check for any foreign objects or hard ingredients obstructing blades. If noise is abnormal, contact service.
Jars are difficult to fit or remove.	Residue build-up; improper alignment.	Ensure the base of the jar and the motor unit coupling are clean. Align grooves carefully and apply gentle pressure while turning.
Small leakage from chutney jar.	Lid not sealed properly; overfilling; worn gasket.	Ensure the lid is firmly pressed down. Do not overfill the jar. Check if the gasket is properly seated or needs replacement.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Specification
Brand	Bajaj
Model Number	410175
Wattage	500 watts
Voltage	210 volts
Number of Jars	3
Jar Capacities	1.3 Litre (Liquidizing), 1 Litre (Grinding), 0.3 Litre (Chutney)
Material	Stainless Steel (Jars), Polycarbonate (Lids), Plastic (Body)
RPM	20,000

Feature	Specification
Control Type	Knob (Manual)
Number of Speeds	3
Item Weight	7.7 pounds (approx.)
Color	White/Blue

9. Warranty and Support

Your Bajaj Bravo Dlx Mixer Grinder comes with a limited warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical assistance, service, or to inquire about spare parts, please contact Bajaj customer support. Keep your purchase receipt and model number handy when contacting support.
Customer Support Contact: Please refer to the contact information provided in your product packaging or visit the official Bajaj website for the most up-to-date support details.

© 2026 Bajaj. All rights reserved.