Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool 4172127

Whirlpool 4172127 Seal Kit Instruction Manual

Model: 4172127

1. Introduction

This manual provides essential instructions for the installation, maintenance, and troubleshooting of the Whirlpool 4172127 Seal Kit. This kit is an Original Equipment Manufacturer (OEM) authorized replacement part designed for various Whirlpool and compatible dishwasher models. Proper installation and care ensure optimal performance and prevent water leakage.

2. Product Overview

The Whirlpool 4172127 Seal Kit typically includes the main lower door seal and associated clips or retainers necessary for securing it in place. This component is critical for maintaining a watertight seal around the dishwasher door during operation.





Image 1: Components of the Whirlpool 4172127 Seal Kit. This image displays the long, flexible black rubber seal and several smaller black plastic clips or retainers, which are used to secure the seal to the dishwasher door.

3. Safety Information

Always prioritize safety when performing appliance repairs. Failure to follow these safety guidelines may result in injury or damage to the appliance.

- **Disconnect Power:** Before beginning any repair, always disconnect the dishwasher from its power source by unplugging it or turning off the circuit breaker.
- **Wear Protective Gear:** Use gloves to protect hands from sharp edges and safety glasses to protect eyes.

- **Consult a Professional:** If you are unsure about any step or uncomfortable performing the repair, consult a qualified appliance technician.
- **Handle with Care:** Appliance components can be heavy or have sharp edges. Handle them carefully to avoid injury.

4. Installation Instructions

The following steps outline the general procedure for replacing a dishwasher lower door seal. Specific models may vary, so refer to your dishwasher's service manual for detailed instructions if available.

1. **Preparation:**
    - Ensure the dishwasher is completely disconnected from power.
    - Clear the area around the dishwasher for access.
    - Open the dishwasher door fully.
2. **Remove Old Seal:**
    - Carefully locate the existing lower door seal. It is typically a long rubber strip at the bottom edge of the inner door panel.
    - Gently pull or pry the old seal away from its mounting channel. Note how it was installed, especially if there are clips or specific seating points.
    - Clean the mounting channel thoroughly to remove any debris, old sealant, or residue.
3. **Install New Seal:**
    - Align the new Whirlpool 4172127 seal with the clean mounting channel on the lower edge of the dishwasher door.
    - Begin pressing the seal firmly into the channel, working from one end to the other. Ensure it is seated completely and evenly.
    - If your kit includes new clips or retainers, install them as per the original configuration to secure the seal.
    - Some installations may benefit from a small amount of appliance-safe silicone sealant in the channel to ensure a tight fit, especially if the new seal feels slightly loose. Apply sparingly and allow adequate curing time before use.
4. **Reassembly and Testing:**
    - Close the dishwasher door and ensure it latches properly and the new seal is not pinched or misaligned.
    - Reconnect the dishwasher to its power source.
    - Run a short cycle (e.g., rinse cycle) and carefully observe the lower door area for any signs of leakage.

5. Maintenance

To prolong the life of your dishwasher door seal and prevent future leaks:

- **Regular Cleaning:** Periodically wipe down the door seal with a damp cloth to remove food particles, grease, and detergent residue that can accumulate and degrade the rubber.
- **Inspect for Damage:** Routinely check the seal for cracks, tears, hardening, or signs of wear. Replace the seal if any damage is observed.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals on the seal, as these can cause deterioration.

6. Troubleshooting

If you experience issues after replacing the seal, consider the following:

- **Leakage After Replacement:**
  - **Improper Seating:** Ensure the seal is fully and evenly seated in its channel along the entire length.
  - **Damaged Seal:** Inspect the new seal for any manufacturing defects or damage that may have occurred during installation.
  - **Other Leak Sources:** A leak at the bottom of the door may not always be due to the door seal. Check other components such as the pump cover, spray arm connections, or tub gasket for issues.
  - **Door Alignment:** Verify that the dishwasher door is properly aligned and closing securely.
- **Seal Not Staying in Place:**
  - Ensure all clips or retainers are correctly installed.
  - Consider using a small amount of appliance-safe silicone sealant to help secure the seal, as mentioned in the installation steps.

7. Specifications

Attribute	Detail
Part Number	4172127
Brand	Whirlpool (OEM Authorized Part)
Item Weight	0.798 ounces
Product Dimensions	21.25 x 3.62 x 1.25 inches
Manufacturer	Appliances Parts Co.
Item Package Quantity	1

8. Warranty and Support

As an Original Equipment Manufacturer (OEM) authorized part, the Whirlpool 4172127 Seal Kit is subject to Whirlpool's standard warranty policies for replacement parts. For specific warranty details, coverage, or technical support, please refer to your original appliance documentation or contact Whirlpool customer service directly. Keep your purchase receipt as proof of purchase.
For further assistance, you may visit the official Whirlpool Store on Amazon or their official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0156N9ZYM

More documents and user manuals: **https://manuals.plus/**