Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Recliner-Handles HANDSET007

Tranquil Ease Handset HC UR1B 01 Instruction Manual

For Power Recliners and Lift Chairs with USB Charging

Introduction

This manual provides instructions for the installation, operation, and maintenance of your Tranquil Ease Handset, model HC UR1B 01. This handset is designed to control the reclining and lifting functions of compatible power recliners and lift chairs, and includes a convenient USB port for charging personal electronic devices.

Important Safety Information

Please read all instructions carefully before use. Retain this manual for future reference.

- **Maximum Weight Limit:** The chair controlled by this handset has a maximum weight limit of 100 kg (220 lbs). Do not exceed this limit to ensure safety and product longevity of the chair.
- **Power Source:** Ensure the chair is connected to a stable power source as specified by the chair manufacturer.
- **Cable Management:** Keep all cables clear of moving parts to prevent damage or entanglement.
- **Children and Pets:** Keep children and pets away from the chair's moving parts during operation.

Package Contents

- 1 x Tranquil Ease Handset (Model HC UR1B 01)

Setup Instructions

Follow these steps to connect your new handset to your power recliner or lift chair:

1. **Disconnect Power:** Before beginning, ensure the power recliner or lift chair is unplugged from the wall outlet to prevent accidental operation.
2. **Locate Connection Port:** Identify the existing handset cable connection port on your chair. This is typically located near the motor or control box under the chair.
3. **Remove Old Handset (if applicable):** If replacing an old handset, carefully disconnect its cable from the chair's connection port.

4. **Connect New Handset:** Take the connector end of the Tranquil Ease Handset cable and align it with the chair's connection port. Gently push until it clicks securely into place. Ensure the connection is firm.
5. **Secure Cable:** Route the handset cable safely, ensuring it is not pinched or tangled by any moving parts of the chair.
6. **Restore Power:** Plug the power recliner or lift chair back into the wall outlet.



Figure 1: The 5-pin connector cable of the Tranquil Ease Handset. Ensure this connector is securely plugged into the chair's control box.

Operating Instructions

Once connected, your handset is ready for use. The handset features two primary buttons for chair movement and a USB port for charging.

- **Up Arrow Button (▲):** Press and hold this button to raise the chair's footrest and/or backrest, or to lift the chair to an upright position for easy exit. Release the button to stop movement.
- **Down Arrow Button (▼):** Press and hold this button to lower the chair's footrest and/or backrest, or to recline the

chair to a seated or lying position. Release the button to stop movement.

- **USB Charging Port:** Located on the side of the handset, this port allows you to charge compatible electronic devices such as smartphones or tablets. Simply plug your device's USB charging cable into this port. The USB port draws power from the chair's main power supply.





Figure 2: Front view of the handset, showing the illuminated Up and Down arrow buttons for controlling chair movement.



Figure 3: Side view of the handset, highlighting the integrated USB charging port for electronic devices.

Maintenance

To ensure the longevity and proper function of your handset, follow these simple maintenance guidelines:

- **Cleaning:** Wipe clean with a soft, dry cloth. Do not use abrasive cleaners, solvents, or excessive moisture, as this can damage the electronic components.
- **Cable Inspection:** Periodically inspect the handset cable for any signs of wear, cuts, or damage. If damage is found, discontinue use and replace the handset immediately.
- **Storage:** When not in use, ensure the handset is placed in a position where its cable will not be pinched or stressed.

Troubleshooting

If you experience issues with your Tranquil Ease Handset, refer to the following common problems and solutions:

- **Handset Not Responding:**
  - Ensure the chair's power cord is securely plugged into a working wall outlet.
  - Check that the handset's connector cable is firmly plugged into the chair's control box.
  - Inspect the handset cable for any visible damage. If damaged, replacement is necessary.

- **USB Port Not Charging:**
  - Verify the chair is powered on and connected to an electrical outlet.
  - Ensure your device's USB charging cable is fully inserted into the handset's USB port and your device.
  - Test with a different USB cable or device to rule out issues with the cable or device itself.
- **Intermittent Operation:**
  - Check all cable connections for looseness.
  - Ensure no objects are obstructing the chair's moving mechanisms.

If troubleshooting steps do not resolve the issue, contact the manufacturer or seller for further assistance.

Specifications

Feature	Detail
Brand	Recliner-Handles
Model Number	HANDSET007 (HC UR1B 01)
Product Dimensions	2"D x 2"W x 5"H
Material	Plastic
Item Weight	8 ounces
Special Feature	Reclining control, USB charging
Product Care Instructions	Wipe Clean
UPC	617762076268

Warranty and Support

Specific warranty details for the Tranquil Ease Handset HC UR1B 01 are typically provided at the point of purchase or by the product manufacturer. Please refer to your purchase documentation or contact the seller, Recliner-Handles, for information regarding warranty coverage and customer support.
For technical assistance or inquiries, please reach out to the retailer or manufacturer directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B015NGB1DA

More documents and user manuals: **https://manuals.plus/**