Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cuisinart FP-SPAT

Cuisinart FP-SPAT Replacement Spatula User Manual

Model: FP-SPAT

Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Cuisinart FP-SPAT is an original equipment manufacturer (OEM) replacement spatula designed for use with various Cuisinart food processor models. This BPA-free spatula is engineered for efficient scraping and mixing within your food processor bowl, ensuring thorough processing and easy removal of ingredients.



Image 1.1: The Cuisinart FP-SPAT replacement spatula, a black plastic tool designed for food processors.

1.1. Compatibility

This spatula is specifically designed to fit the following Cuisinart food processor models:

- CFP-24
- CFP-24BCPC
- FP-12
- FP-12BK
- FP-12DC
- FP-14
- FP-14BK
- FP-14DC
- FP-16
- Models: 3066, 3067, 3093, 3094, 3111, 3112, KF140, KF260

While designed for these specific models, the FP-SPAT is generally compatible with most Cuisinart food processors.

2. Setup and First Use

The Cuisinart FP-SPAT replacement spatula requires no assembly. Before first use, it is recommended to wash the spatula thoroughly.

2.1. Cleaning Before Use

1. Wash the spatula with warm, soapy water.
2. Rinse thoroughly under running water.
3. Dry completely before use.

Note: This spatula is not dishwasher safe. Hand washing is recommended to preserve its integrity.

3. Operating Instructions

The FP-SPAT spatula is designed to assist in the preparation and removal of ingredients from your Cuisinart food processor.

3.1. Scraping Ingredients

- **During Processing:** To ensure even processing, periodically stop the food processor and use the spatula to scrape down ingredients from the sides of the work bowl. Always ensure the blade has come to a complete stop before inserting the spatula.
- **After Processing:** Once processing is complete, remove the food processor lid and blade assembly. Use the spatula to scrape all processed ingredients from the work bowl into a separate container.

3.2. Mixing

The spatula can also be used for manual mixing of ingredients within the food processor bowl, especially for delicate items or when the food processor is off.
Important Safety Note: *Never insert the spatula into the food processor work bowl while the motor is running or the blade is spinning. Always ensure the appliance is unplugged and the blade has stopped moving before handling.*

4. Care and Maintenance

Proper care will extend the life of your Cuisinart FP-SPAT spatula.

4.1. Cleaning

- Wash the spatula by hand with warm, soapy water immediately after each use.
- Rinse thoroughly to remove all soap residue.
- Dry completely with a soft cloth.
- **Do not** place the spatula in a dishwasher, as high temperatures can damage the material.

4.2. Storage

Store the spatula in a clean, dry place, away from direct heat sources or sharp objects that could cause damage.

5. Troubleshooting

This section addresses common concerns regarding the FP-SPAT spatula.

Problem	Possible Cause	Solution
Spatula shows signs of wear or nicks.	Contact with spinning blades or abrasive surfaces.	Ensure the food processor is off and blades are stationary before using the spatula. Avoid using the spatula on rough surfaces. Replace if damage affects functionality or hygiene.
Spatula feels less rigid than expected.	Material characteristics.	The FP-SPAT is designed with a specific flexibility for scraping. This is normal. If rigidity is significantly compromised, consider replacement.

6. Product Specifications

Feature	Detail
Model Number	FP-SPAT
Brand	Cuisinart
Material	Plastic
Material Type Free	BPA Free
Color	Black
Shape	Rectangular (blade)
Dishwasher Safe	No (Hand wash recommended)
Item Weight	2.08 ounces
UPC	788958680153
ASIN	B015RDG22O

7. Warranty and Support

As an OEM replacement part, the Cuisinart FP-SPAT spatula is manufactured to Cuisinart's quality standards. Specific warranty information for replacement parts may vary.

7.1. Customer Support

For questions regarding compatibility, replacement, or general inquiries about Cuisinart products, please contact Cuisinart customer service directly. Refer to your food processor's original manual or the official Cuisinart website for contact information.
You can visit the official Cuisinart store on Amazon for more information:Cuisinart Store

© 2024 Cuisinart. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B015RDG22O

More documents and user manuals: **https://manuals.plus/**