Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cuisinart FP-16LCB

Cuisinart FP-16LCB Replacement Large Chopping Blade User Manual

Model: FP-16LCB

Introduction

This manual provides essential information for the safe and effective use, installation, and maintenance of your Cuisinart FP-16LCB Replacement Large Chopping Blade. This blade is an Original Equipment Manufacturer (OEM) authorized part designed specifically for compatible Cuisinart food processor models. Please read these instructions carefully before use.

Important Safety Information

- **Sharp Blades:** The chopping blade is extremely sharp. Handle with extreme care to prevent injury. Always grasp the blade by the plastic hub, not the metal blades.
- **Unplug Appliance:** Always ensure your food processor is unplugged from the power outlet before installing, removing, or cleaning the blade.
- **Proper Installation:** Ensure the blade is correctly seated on the motor shaft before operating the food processor. Improper installation can lead to damage or injury.
- **Children and Pets:** Keep the blade and food processor components out of reach of children and pets.
- **Intended Use:** Use this blade only for its intended purpose within compatible Cuisinart food processors. Do not attempt to use it with other appliances.

Setup and Installation

The Cuisinart FP-16LCB Large Chopping Blade is designed for specific Cuisinart food processor models. Verify your food processor model number for compatibility before installation.

Compatible Models:

- FP-14DCN
- 3066
- 3067
- 3093
- 3094
- 3111

- 3112
- KF140
- KF604

Installation Steps:

1. **Ensure Safety:** Unplug your Cuisinart food processor from the electrical outlet.
2. **Prepare Work Area:** Place the food processor bowl on a stable, flat surface.
3. **Handle Blade Carefully:** Grasp the FP-16LCB chopping blade by its central plastic hub. Avoid touching the sharp metal blades.
4. **Position Blade:** Carefully lower the blade onto the motor shaft inside the food processor bowl. Ensure it slides down completely and sits securely. The blade should rotate freely when gently spun by hand.
5. **Assemble Processor:** Place the food processor cover onto the bowl and lock it into position according to your food processor's specific instructions.
6. **Ready for Use:** Your food processor is now ready for use with the new chopping blade.



Figure 1: Cuisinart FP-16LCB Replacement Large Chopping Blade. This image displays the blade's design, featuring two sharp stainless steel blades securely attached to a central beige plastic hub. The number '414' is visible on one of the blades, indicating a potential manufacturing code or internal identifier. This blade is designed for efficient chopping in compatible Cuisinart food processors.

Operating Instructions

Once the FP-16LCB blade is correctly installed in your Cuisinart food processor, operate the appliance according to the instructions provided in your food processor's main user manual. This blade is designed for general chopping tasks, including vegetables, fruits, nuts, and other ingredients suitable for food processing.

- **Do not overfill:** Adhere to the maximum capacity markings on your food processor bowl.
- **Pulse function:** Use the pulse function for better control over chopping consistency.
- **Liquids:** When processing liquids, ensure the lid is securely locked to prevent splashes.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your replacement chopping blade.

- **Immediate Cleaning:** Clean the blade immediately after each use to prevent food particles from drying onto the surface.
- **Hand Wash Only:** This blade is designed for hand washing. Use warm, soapy water and a brush to carefully clean around the blades. Rinse thoroughly.
- **Avoid Dishwasher:** Do not wash the blade in a dishwasher, as this can dull the blades and potentially damage the plastic hub over time.
- **Drying:** Dry the blade completely before storing to prevent rust on the stainless steel and maintain hygiene.
- **Storage:** Store the blade safely in a drawer or a designated accessory storage area to protect the sharp edges and prevent accidental injury.

Troubleshooting

Blade does not fit or is loose:
Ensure your food processor model is listed under the "Compatible Models" section. This blade is specifically designed for certain Cuisinart models. If your model is not listed, the blade may not be compatible. Double-check that the blade is fully seated on the motor shaft.

Blade appears dull or is not chopping effectively:
While this is a replacement blade, prolonged heavy use can eventually dull any blade. Ensure you are not processing excessively hard ingredients or overfilling the bowl. If the blade is genuinely dull, it may be time for another replacement.

Unusual noise during operation:
Immediately turn off and unplug the food processor. Check if the blade is correctly installed and not obstructed by food or other components. Refer to your food processor's main manual for further troubleshooting related to the appliance itself.

Specifications

Brand:	Cuisinart
Model Number:	FP-16LCB
Part Type:	Replacement Large Chopping Blade
Blade Material:	Stainless Steel

Item Weight:	8.96 ounces
Product Care:	Hand Wash Only
Compatible Food Processor Models:	FP-14DCN, 3066, 3067, 3093, 3094, 3111, 3112, KF140, KF604
UPC:	086279044976

Warranty and Support

As an Original Equipment Manufacturer (OEM) authorized part, this Cuisinart FP-16LCB Replacement Large Chopping Blade is subject to Cuisinart's standard warranty policies for replacement parts. Please refer to the warranty information provided with your original Cuisinart food processor or visit the official Cuisinart website for detailed warranty terms and conditions.
For technical support, questions regarding compatibility, or to purchase additional replacement parts, please contact Cuisinart Customer Service:

- **Cuisinart Official Website:** www.cuisinart.com
- **Customer Service Contact:** Refer to the "Contact Us" section on the Cuisinart website for phone numbers and email support.

© 2023 Cuisinart. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B015RDPKV8

More documents and user manuals: **https://manuals.plus/**