Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Denali Pure WF-4396701-DL186

Denali Pure Replacement Refrigerator Water Filter

Model: WF-4396701-DL186 | Compatible with Whirlpool GR2FHTXVQ00, 4396701

Introduction

This manual provides instructions for the installation, operation, and maintenance of your Denali Pure Replacement Refrigerator Water Filter. This filter is designed to provide clean, great-tasting water by reducing impurities and contaminants. Please read these instructions carefully before installation and keep them for future reference.

Safety Information

- Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.
- Ensure all connections are secure to prevent leaks.
- Flush the filter as instructed before initial use.
- Replace the filter regularly to maintain optimal performance and water quality.

Compatibility

This Denali Pure water filter is a replacement for various refrigerator models. It is compatible with, but not limited to, the following models:

- **Whirlpool:** 4396701, 4396703, 2301705, 2301706, WF-NL120V, WFNL120V, NL120V, WF-L120V, WFL120V, L120V, WF-LC200V, WFLC200V, LC200V, WF-L200V, GR2FHTXVQ00
- **KitchenAid:** 4396702
- **Sears** / **Kenmore:** 46-9915, 469915, 9915, 04609915000



Image: List of compatible refrigerator water filter models.

Setup and Installation

Follow these steps to install your new Denali Pure water filter:

1. **Locate the Filter:** The water filter is typically located in the upper right corner of the fresh food compartment or in the base grille of your refrigerator.
2. **Remove Old Filter:** Turn the old filter counter-clockwise a quarter turn to unlock it. Pull the filter straight out. Some water may drip, so have a towel ready.
3. **Prepare New Filter:** Remove the protective cap from the new Denali Pure filter.
4. **Insert New Filter:** Push the new filter into the filter housing until it stops. Turn it clockwise a quarter turn until it locks into place. You should feel it click.
5. **Flush the System:** Dispense 2-3 gallons of water through the refrigerator's water dispenser to flush out air and loose carbon particles. This ensures optimal filter performance.
6. **Reset Filter Indicator:** Refer to your refrigerator's owner's manual for specific instructions on how to reset the filter change

indicator light. This usually involves pressing and holding a button for a few seconds.



Image: Visual representation of easy, leak-free, perfect fit, and tool-free installation.



Image: The Denali Pure replacement water filter.

Operation

The Denali Pure water filter utilizes a multi-layer filtration system, including coconut charcoal, to effectively reduce various impurities from your drinking water. This process ensures that your water is safe, clean, and has an improved taste and odor.



Image: Diagram illustrating the benefits of a coconut charcoal filter in providing safe, clean, and great-tasting water by removing chemicals and pollutants.



Image: Illustration of the multi-layer filtration system for efficient water purification.

Maintenance

For optimal performance and to ensure continuous access to clean water, it is crucial to replace your Denali Pure water filter regularly.

- **Replacement Frequency:** Replace the water filter every **6 months** or sooner if you notice a decrease in water flow or water quality.
- **Filter Indicator:** Pay attention to your refrigerator's filter change indicator light, which will signal when a replacement is due.



Image: Visual reminder to replace the filter every 6 months for best performance.

Troubleshooting

Problem	Possible Cause	Solution
Slow water flow from dispenser	Clogged filter, air in system	Flush the filter for 2-3 gallons. If issue persists, replace the filter.
Water leaking from filter area	Improperly installed filter, damaged O-rings	Ensure filter is fully inserted and twisted clockwise until locked. Check O-rings for damage.
Bad taste or odor in water	Filter needs replacement, initial flushing incomplete	Flush the filter thoroughly. If taste/odor persists, replace the filter.

Specifications

- **Material:** Carbon Fiber
- **Product Benefits:** Removes impurities and contaminants for cleaner, better-tasting water.
- **NSF Certification:** Tested and Certified by NSF International against NSF/ANSI Standards 42 for the reduction of chlorine, taste, and odor.



Image: Details on NSF certification for chlorine reduction, taste, and odor improvement.

Warranty and Support

For any questions regarding your Denali Pure water filter, including warranty information or technical support, please contact Denali Pure customer service. Refer to the product packaging or the Denali Pure official website for contact details.

Denali Pure is a registered trademark. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B015SOCMB2

More documents and user manuals: **https://manuals.plus/**