Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool HSCX 80421

Whirlpool HSCX 80421 Heat Pump Tumble Dryer User Manual

Model: HSCX 80421

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Whirlpool HSCX 80421 heat pump tumble dryer. Please read these instructions carefully before using the appliance and keep them for future reference.

The Whirlpool HSCX 80421 is a freestanding, front-loading tumble dryer with an 8 kg capacity, featuring a heat pump drying system for energy efficiency.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the dryer is properly grounded.
- Do not dry unwashed items in the tumble dryer.
- Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes, and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.
- Remove all objects from pockets such as lighters and matches.
- Do not allow children to play with the appliance.
- Always unplug the appliance before cleaning or performing maintenance.
- Do not install the dryer behind a lockable door, a sliding door, or a door with a hinge on the opposite side to that of the tumble dryer, in such a way that a full opening of the tumble dryer door is restricted.

3. Product Overview



Figure 1: Front view of the Whirlpool HSCX 80421 Tumble Dryer.

This image displays the front of the Whirlpool HSCX 80421 tumble dryer. Key features visible include the main control panel at the top, the large circular loading door, and a lower access panel for the condenser or water tank. The control panel features a program selector knob, a digital display showing time (e.g., "2:20"), and various indicator lights and buttons for functions like power, start/pause, and program options. Program labels visible on the panel include "Coton" (Cotton), "Laine" (Wool), "Mixte" (Mixed), "Synthétique" (Synthetics), "Délicat" (Delicates), "XXL" (Extra Large), "Air froid" (Cold Air), "Rafraîchir" (Refresh), and "Temps Séchage" (Timed Drying). The dryer has an 8 kg capacity indicated on the right side.

4. Installation

Proper installation is crucial for the safe and efficient operation of your dryer.

4.1 Unpacking

- Remove all packaging materials. Keep packaging out of reach of children.
- Check the appliance for any transport damage. If damaged, do not install or operate it. Contact your retailer.

4.2 Positioning

- Place the dryer on a firm, level floor. Adjust the feet to ensure stability.
- Ensure adequate ventilation around the appliance. Do not block the air intake or exhaust vents.
- Do not install the dryer in rooms where there is a risk of frost.
- Maintain a minimum distance from walls or furniture to allow for proper air circulation.

4.3 Electrical Connection

- Connect the dryer to a properly grounded electrical outlet.
- Ensure the voltage and frequency match the specifications on the rating plate of the appliance.
- Do not use extension cords or multiple socket adapters.

5. Operating Instructions

5.1 Control Panel Overview

The control panel allows you to select drying programs and options. Refer to Figure 1 for visual reference.

- **Program Selector Knob:** Used to choose the desired drying program.
- **Display:** Shows remaining drying time, delayed start time, and other indicators.
- **Start/Pause Button:** Initiates or pauses the drying cycle.
- **Option Buttons:** Allow selection of additional functions such as anti-crease, gentle dry, or specific dryness levels.

5.2 Drying Programs

Select the appropriate program based on the fabric type and desired dryness level.

- **Coton (Cotton):** For cotton items, towels, and bed linen.
- **Laine (Wool):** Specific program for wool items, often with reduced mechanical action.
- **Mixte (Mixed):** For mixed loads of cotton and synthetics.
- **Synthétique (Synthetics):** For synthetic fabrics like shirts, blouses, and sportswear.
- **Délicat (Delicates):** For delicate items requiring gentle drying.
- **XXL:** For large items such as duvets or blankets.
- **Air froid (Cold Air):** For refreshing clothes without heat.
- **Rafraîchir (Refresh):** Short cycle to air out clothes.
- **Temps Séchage (Timed Drying):** Allows manual setting of drying time.

5.3 Starting a Drying Cycle

1. Load the laundry into the drum, ensuring it is not overloaded.
2. Close the dryer door firmly.
3. Turn the **Program Selector Knob** to choose the desired drying program.

4. Select any additional options if required (e.g., delayed start, dryness level).
5. Press the **Start/Pause Button** to begin the cycle.
6. At the end of the cycle, remove the laundry promptly to minimize creasing.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your dryer.

6.1 Cleaning the Lint Filter

- Clean the lint filter after every drying cycle.
- Open the dryer door and locate the filter, usually inside the door opening.
- Remove the filter and gently wipe away accumulated lint.
- Rinse the filter under running water if necessary, and ensure it is completely dry before reinserting.

6.2 Emptying the Water Tank

- Empty the water tank after every drying cycle.
- The water tank is typically located at the top left or bottom right of the appliance (refer to Figure 1 for the lower access panel).
- Pull out the tank and pour the collected water into a sink.
- Reinsert the tank securely.

6.3 Cleaning the Condenser

- Clean the condenser periodically, approximately every 3-6 months, or as indicated by the appliance.
- Open the lower access panel (as shown in Figure 1).
- Follow the instructions in your full product manual for safe removal and cleaning of the condenser unit. This usually involves rinsing it under running water.
- Ensure the condenser is dry and correctly reinstalled before closing the access panel.

7. Troubleshooting

Before contacting service, check the following common issues:

Problem	Possible Cause	Solution
Dryer does not start.	No power; door not closed; Start/Pause button not pressed.	Check power supply; ensure door is firmly closed; press Start/Pause.
Clothes are not drying properly.	Lint filter clogged; water tank full; overloaded; incorrect program.	Clean lint filter; empty water tank; reduce load size; select appropriate program.
Excessive noise.	Unlevel appliance; foreign objects in drum.	Adjust feet to level dryer; check drum for loose items.
Water leaking.	Water tank not properly inserted or damaged.	Ensure water tank is correctly seated; check for cracks.

8. Specifications

- **Model:** HSCX 80421
- **Type:** Freestanding, Front Load Tumble Dryer

- **Drying System:** Heat Pump
- **Capacity:** 8 kg
- **Energy Efficiency Class:** A++
- **Annual Energy Consumption:** 235.5 kWh
- **Cycle Duration (Standard Cotton):** 176 minutes
- **Delayed Start:** Up to 12 hours
- **Dimensions (W x D x H):** 59.6 cm x 65.9 cm x 85.5 cm
- **Weight:** 47 kg

9. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Whirlpool website. For technical support, spare parts, or service requests, please contact Whirlpool customer service in your region. Ensure you have your model number (HSCX 80421) and serial number ready when contacting support.
You can find more information and support on the Whirlpool Brand Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B015Y1O95Q

More documents and user manuals: **https://manuals.plus/**