Calvin Klein K4M27146

Calvin Klein K4M27146 Formality Chronograph Watch User Manual

Model: K4M27146

Introduction

This manual provides instructions for the Calvin Klein K4M27146 Formality Swiss Quartz Chronograph Watch. This timepiece features a 43mm stainless steel case, Swiss Made quartz chronograph movement, and a date display. It is designed for daily wear with a focus on functionality and durability.



Front view of the Calvin Klein K4M27146 watch, displaying the silver dial, chronograph sub-dials, and date window.

Setup

Setting the Time

1. Gently pull the crown (located on the right side of the watch case) out to position 2.
2. Rotate the crown in either direction to move the hour and minute hands to the desired time.
3. Once the time is set, push the crown back firmly to position 0 (normal operating position).

Setting the Date

1. Gently pull the crown out to position 1.
2. Rotate the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this may interfere with the automatic date change mechanism.
3. Once the date is set, push the crown back firmly to position 0.

Bracelet Adjustment

The stainless steel bracelet is designed for a secure fit. For proper sizing and adjustment, it is recommended to consult a professional jeweler or an authorized service center. Incorrect adjustment can damage the bracelet or clasp.

Operating the Chronograph

The Calvin Klein K4M27146 features a chronograph function for measuring elapsed time.



Angled view of the watch, showing the crown and chronograph pushers.

- **Start/Stop:** Press the top pusher (located above the crown) to start the chronograph. Press it again to stop the measurement.
- **Reset:** While the chronograph is stopped, press the bottom pusher (located below the crown) to reset all chronograph hands to their zero positions.

Maintenance

Cleaning

Regular cleaning helps maintain the watch's appearance. Wipe the watch case and bracelet with a soft, dry cloth. For more thorough cleaning, a slightly damp cloth can be used, ensuring the crown is fully pushed in to maintain water resistance. Avoid using harsh chemicals or abrasive materials.

Water Resistance

This watch is water resistant to 50 meters (5 ATM). This rating means it is suitable for short periods of recreational swimming but is not designed for diving, snorkeling, or prolonged water exposure. **Do not operate the crown or pushers while the watch is wet or submerged.**

Battery Replacement

The watch is powered by a Swiss Quartz movement, which requires a battery. Battery life varies depending on usage. When the battery needs replacement, it is recommended to have it replaced by an authorized Calvin Klein service center or a qualified watchmaker to ensure proper sealing and maintain water resistance.

Crystal Care

The watch features a scratch-resistant mineral crystal. While durable, it is not scratch-proof. Avoid impacts and contact with abrasive surfaces to prevent damage.



Back view of the watch, illustrating the stainless steel case back and bracelet.

Troubleshooting

- **Watch Not Running:** Ensure the crown is fully pushed in to position 0. If the watch still does not run, the battery may need replacement.
- **Date Not Changing Correctly:** The date changes automatically at midnight. If the date changes at noon, advance the time by 12 hours. Ensure the crown is fully pushed in after setting.
- **Chronograph Hands Not Resetting to Zero:** If the chronograph hands do not return precisely to the 12 o'clock position after pressing the reset pusher, it may require adjustment by an authorized service center.

Specifications

Feature	Detail
Model Number	K4M27146
Brand	Calvin Klein
Movement	Swiss Quartz Chronograph
Case Material	Stainless Steel
Case Diameter	43 Millimetres
Case Thickness	13 Millimetres
Dial Color	Silver / Black
Crystal	Mineral
Band Material	Stainless Steel
Band Width	22 Millimetres
Clasp Type	Push Button Deployment Clasp

Water Resistance Depth	50 Metres (5 ATM)
Functions	Chronograph, Date Display, Hour, Minute, Second
Batteries	1 Product Specific battery required (included)
Product Dimensions	7.62 x 7.62 x 7.62 cm; 113.39 g

Warranty and Support

The Calvin Klein K4M27146 Formality Chronograph Watch is backed by a **2-year store limited warranty**. This warranty covers manufacturing defects under normal use. For specific terms and conditions, please refer to the warranty card provided with your purchase or contact the retailer.

For technical support, service, or warranty claims, please contact the authorized Calvin Klein retailer where the watch was purchased. They can provide guidance on service procedures and authorized service centers.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question