Emerson 1F85U-42PR

Emerson 1F85U-42PR Programmable Thermostat User Manual

Model: 1F85U-42PR

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Emerson 1F85U-42PR Programmable Thermostat. This thermostat is designed to provide reliable and efficient control over your home's heating and cooling system. It features a large, clear display for easy readability, selectable programming options (7-day / 5-1-1 / off), and advanced features such as keypad lock and temperature limits.




Figure 1: Front view of the Emerson 1F85U-42PR Programmable Thermostat.

2. Setup and Installation

Proper installation is crucial for the optimal performance of your thermostat. It is recommended to consult a qualified HVAC technician if you are unsure about any steps.

2.1. Pre-Installation Checklist

- Ensure power to the HVAC system is turned off at the circuit breaker before beginning installation.
- Gather necessary tools: screwdriver, wire strippers, drill (if needed).
- Take a photograph of your old thermostat's wiring connections for reference.

2.2. Mounting the Thermostat

The Emerson 1F85U-42PR features a built-in level indicator for easy and accurate wall mounting. Choose a central location away from direct sunlight, drafts, or heat sources.

2.3. Wiring

This thermostat supports various HVAC systems, including conventional gas/oil, electric, and heat pump systems. The streamlined configuration menu and pluggable terminals simplify the wiring process. Refer to the wiring diagram provided with your product for specific connections. Ensure all wires are securely connected to the appropriate terminals.




Figure 2: Rear view of the thermostat with wiring terminals and included components.

2.4. Battery Installation

The thermostat requires two AA batteries (included) for operation. Insert the batteries into the designated compartment, ensuring correct polarity. The thermostat also supports hardwiring with a common wire for continuous power.

3. Operating Instructions

Your Emerson 1F85U-42PR thermostat is designed for user-friendly operation.

3.1. Display Overview

The large LCD display shows the current room temperature, the set temperature, and the current time. Indicators for system mode (Heat, Off, Cool) and fan status (Auto, On) are also clearly visible.

3.2. Mode Selection

Press the **Mode** button to cycle through the available system modes: Heat, Off, and Cool. Select the mode appropriate for your desired climate control.

3.3. Fan Control

Press the **Fan** button to switch between Auto and On fan settings. In Auto mode, the fan runs only when the heating or cooling system is active. In On mode, the fan runs continuously.

3.4. Temperature Adjustment

Use the **Up** and **Down** arrow buttons on the right side of the thermostat to adjust the desired set temperature. The new set temperature will be displayed prominently.

3.5. Scheduling

The thermostat offers selectable programming options: 7-day, 5-1-1 day, or non-programmable (off). Press the **Schedule** button to access and modify your desired program settings. Detailed scheduling instructions are available in the full user guide.

3.6. Advanced Features

- **Keypad Lock:** Prevents unauthorized changes to settings.
- **Temperature Limits:** Allows setting minimum and maximum temperature boundaries.
- **Backlight Button:** Activates the display backlight for improved visibility in low light conditions.

4. Maintenance

Regular maintenance ensures the longevity and efficiency of your thermostat.

4.1. Battery Replacement

When the low battery indicator appears on the display, replace the two AA batteries promptly to ensure continuous operation. Always use fresh alkaline batteries.

4.2. Cleaning

Clean the thermostat's exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or internal components.

5. Troubleshooting

If you encounter issues with your thermostat, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Display is blank or dim	Low or dead batteries; no power from C-wire.	Replace batteries. Check C-wire connection if applicable.
System not responding to temperature changes	Incorrect mode selected; wiring issue; system lockout.	Verify Heat/Cool mode. Check wiring connections. Consult HVAC technician if system is locked out.
Thermostat makes an audible click	Normal operation of internal relays.	This is a normal operational sound and does not indicate a malfunction.
Temperature reading inaccurate	Thermostat location; calibration needed.	Ensure thermostat is not in direct sunlight or near heat sources. Refer to advanced settings for calibration options.

For more complex issues, refer to the comprehensive troubleshooting guide in the full product manual or contact customer support.

6. Specifications

Feature	Detail
Brand	Emerson
Model Number	1F85U-42PR
Product Dimensions	6 x 1.13 x 3.75 inches
Item Weight	9.2 ounces
Power Source	AC/DC (2 AA batteries required, included)
Voltage	100-240 Volts
Display Type	LCD
Screen Size	5 Inches
Control Type	Button Control
Special Features	Lockable, Low Battery Indicator, Low Voltage, Programmable, Temperature Display, Backlight
Compatible Systems	Air Conditioner, Boiler, Furnace, Heat Pump
UPC	786710551871

7. Warranty Information

Warranty information for the Emerson 1F85U-42PR Programmable Thermostat is typically provided with the product packaging or can be found on the official Emerson website. Please retain your proof of purchase for warranty claims.

8. Support

For additional support, technical assistance, or to view frequently asked questions, please visit the official Emerson website or contact their customer service department. You can also visit the Emerson Store on Amazon for more product

information.

© 2024 Emerson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question