Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HomeSpot S005AYU0500100

HomeSpot UL Certified USB Wall Charger User Manual

Model: S005AYU0500100

Brand: HomeSpot

Introduction

This user manual provides essential information for the safe and efficient operation of your HomeSpot UL Certified USB Wall Charger. Please read this manual thoroughly before using the product and retain it for future reference. The HomeSpot USB Wall Charger is designed to provide reliable and fast charging for a wide range of USB-powered devices, including smartphones, tablets, MP3 players, and digital cameras. Its compact design makes it ideal for both home and travel use.

Safety Information

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the charger to liquids, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the charger. Refer all servicing to qualified personnel.
- Ensure the wall outlet voltage is within the specified input range (AC 100-240V).
- Avoid using damaged cables or adapters with the charger.
- Unplug the charger from the wall outlet when not in use or during electrical storms.
- Keep out of reach of children.

Image: The UL (Underwriters Laboratories) certification logo, indicating the product meets safety standards for use in the US and Canada. This ensures the charger has been tested and found compliant with safety requirements.

Setup

Setting up your HomeSpot USB Wall Charger is straightforward:

1. **Unpack the Charger:** Carefully remove the charger from its packaging.

2. **Locate a Power Outlet:** Find a standard AC wall outlet (100-240V) that is easily accessible.
3. **Plug in the Charger:** Insert the charger's prongs into the wall outlet. Ensure it is firmly seated.



Image: The HomeSpot USB Wall Charger positioned next to a standard electrical wall outlet, illustrating its compact size and readiness for connection.

Operating Instructions

Follow these steps to charge your devices:

1. **Connect USB Cable:** Plug one end of your device's USB charging cable into the USB-A port on the HomeSpot wall charger.
2. **Connect to Device:** Plug the other end of the USB cable into your electronic device (e.g., smartphone, tablet).
3. **Begin Charging:** The device should automatically begin charging. The charger's internal IC chip is designed to identify full charging and stop to prevent overcharging.
4. **Disconnect After Charging:** Once your device is fully charged, disconnect the USB cable from both the device and the charger. Unplug the charger from the wall outlet.



Image: The HomeSpot USB Wall Charger is shown plugged directly into a wall outlet, with a black USB cable extending from its port, ready to connect to a device for charging.



Image: The HomeSpot USB Wall Charger is plugged into the top socket of a wall outlet, demonstrating its compact design that allows space for another larger power adapter (like a laptop charger) to be plugged into the bottom socket without obstruction.

Maintenance

Proper maintenance ensures the longevity and performance of your charger:

- **Cleaning:** Disconnect the charger from the power outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Inspection:** Periodically inspect the charger and connected cables for any signs of damage, such as frayed wires or cracked casings. Discontinue use if damage is found.

Troubleshooting

If you encounter issues with your HomeSpot USB Wall Charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not charging.	Loose connection, faulty cable, or incompatible device.	Ensure cable is securely plugged into both charger and device. Try a different USB cable. Verify device compatibility.

Problem	Possible Cause	Solution
Slow charging.	Device drawing more power than supplied, or background apps consuming power.	Close unnecessary apps on your device. Ensure the device is compatible with 1A charging. Note: This charger does not support Qualcomm Quick Charge.
Charger feels warm.	Normal operation during charging.	A slight warmth is normal. If it becomes excessively hot or emits smoke/odor, unplug immediately and discontinue use.

If the problem persists after trying these solutions, please contact HomeSpot customer support.

Specifications

Detailed technical specifications for the HomeSpot UL Certified USB Wall Charger:

Feature	Detail
Model Number	S005AYU0500100
Input	AC 100-240V, 50/60Hz, 200mA
Output	DC 5V / 1A (1000mA)
Dimensions	1.2 x 0.6 x 2.2 inches
Item Weight	0.071 ounces
UL Listed Number	E178074
Energy Efficiency	Level VI (DOE and CEC compliant)
Compatibility	Most USB-powered devices (smartphones, tablets, MP3 players, digital cameras, etc.)
Special Features	Fast Charging (for 1A devices), Travel-friendly, Over-charging/current/heating protection



Image: A detailed view of the HomeSpot UL Certified USB Wall Charger, showcasing its compact black design and the printed specifications on its side, including model number and electrical ratings.

Warranty and Support

Warranty Information: HomeSpot products are manufactured with quality and reliability in mind. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official HomeSpot website.

Customer Support: If you have any questions, require technical assistance, or need to report an issue with your HomeSpot USB Wall Charger, please contact HomeSpot customer support. Contact information can typically be found on the product packaging or the official HomeSpot website.

For more information, visit the HomeSpot Store on Amazon.

© 2024 HomeSpot. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B017TXGM4I

More documents and user manuals: **https://manuals.plus/**