Button Maker B017XE5VJK

Instruction Manual for 2-1/4" (58mm) Flashing Light Button Parts

Model: B017XE5VJK

Introduction

This manual provides detailed instructions for the proper use and assembly of the 2-1/4" (58mm) Flashing Light Button Parts. These parts are designed for use with compatible button maker machines to create custom flashing light badges.

Important Compatibility Note



Image: A red text box with "IMPORTANT NOTE:" followed by text stating that these button supplies only fit button maker machines purchased from the same store and do not work with other brands. It advises users to be aware of this before ordering.

Crucial Information: These 2-1/4" (58mm) button supplies are specifically designed to fit button maker machines purchased from our store. They are not guaranteed to be compatible with button maker machines from other brands. Please verify the compatibility with your existing machine before attempting assembly or use. Returns based on incompatibility with non-matching machines may not be accepted.
The supplies are intended for use with our Pro Button Maker series.

Parts Included



Image: Four distinct components laid out on a white background. These include a metal shell, a clear plastic mylar film, a metal ring back, and a small circuit board with wires, representing the light part.

Each set of 2-1/4" (58mm) Flashing Button Parts includes the following components:

- **1 Shell:** The front metal casing of the button.
- **1 Mylar:** A clear protective film that covers the design.
- **1 Ring Back:** The back component of the button, typically with a pin or clip attachment point.

- **1 Light Part:** The electronic component responsible for the flashing light effect.

This package contains 100 complete sets of these parts.

Setup and Assembly (General Guidelines)

The assembly of these button parts requires a compatible 2-1/4" (58mm) button maker machine. The exact steps may vary slightly depending on your specific machine model. Refer to your button maker machine's instruction manual for precise assembly steps.
General Assembly Sequence:

1. Place the metal shell into the appropriate die on your button maker machine.
2. Place your printed design (artwork) on top of the shell.
3. Place the clear Mylar film on top of your design.
4. Operate the machine to press these layers together, forming the front of the button.
5. Place the ring back and the light part into the second die of your machine. Ensure the light part is correctly oriented.
6. Operate the machine again to press the front of the button onto the back components, securing all parts together.

Ensure all components are aligned correctly before pressing to prevent damage to the parts or the machine.

Operating Instructions

Once assembled, the flashing light button is ready for use. The light part typically activates via a small switch or by pressing the button itself. Refer to the specific instructions for the light part's activation mechanism.
These parts are designed to integrate seamlessly with the button maker machine to produce a finished product. The operation primarily involves the button maker machine's pressing mechanism.

Maintenance

These button parts are consumable items and do not require maintenance themselves. For the longevity of your button maker machine, ensure it is kept clean and free of debris. Store unused button parts in a dry, cool place to prevent corrosion or damage to the electronic light components.

Troubleshooting

Most issues encountered with these button parts relate to improper assembly or incompatibility with the button maker machine.

- **Button Not Forming Correctly:**
    - Ensure all parts (shell, design, mylar, ring back, light part) are correctly oriented and seated in the machine's dies.
    - Verify that your button maker machine is properly calibrated and applying sufficient pressure.
    - Confirm that the parts are the correct size (2-1/4" or 58mm) for your machine.
- **Light Part Not Flashing:**
    - Check if the light part is correctly inserted and connected within the button assembly.
    - Ensure the activation mechanism (e.g., switch, press) is functioning.
    - The light part may be defective. Replace with a new part if necessary.

- **Parts Not Fitting Machine:**
    - **This is the most common issue.** As stated in the "Important Compatibility Note," these parts are designed for specific button maker machines from our brand. If your machine is from a different manufacturer, these parts may not fit or function correctly.

Specifications

Attribute	Detail
Product Type	Flashing Light Button Parts
Button Size	2-1/4 inches (58mm)
Quantity per Package	100 Sets
Components per Set	Shell, Mylar, Ring Back, Light Part
Compatibility	Specifically designed for Button Maker brand Pro Button Maker machines of the same size.
ASIN	B017XE5VJK
Manufacturer	CN
Date First Available	November 13, 2015

Customer Support

For further assistance or inquiries regarding these button parts, please contact the seller directly through the platform where the purchase was made. Ensure you provide your order details for prompt support.

© 2024 Button Maker. All rights reserved.