Disney MBT3714SR

Disney Minnie Mouse Kids Flashing Musical Watch

Model: MBT3714SR | Brand: Disney

Your guide to fun and functionality with your new Minnie Mouse watch.

1. Product Overview

The Disney Minnie Mouse Kids Flashing Musical Watch is designed for young users, featuring a vibrant Minnie Mouse theme, sound effects, and colorful LED lights. It displays time digitally and comes with an adjustable strap for comfortable wear.



Front view of the Disney Minnie Mouse Kids Flashing Musical Watch, showcasing its vibrant pink color and Minnie Mouse character design.



A closer look at the watch face, featuring Minnie Mouse and Figaro, with the digital time display visible.



Side profile of the watch, highlighting the flip-cover mechanism and the adjustable strap.



Rear view of the watch, showing the battery compartment and manufacturer details.

2. Setup and Initial Use

Your Minnie Mouse watch comes with one Lithium Ion battery pre-installed. Follow these steps for initial setup:

1. **Unboxing:** Carefully remove the watch from its packaging.
2. **Time Setting:** The digital time display is typically pre-set. If adjustment is needed, locate the small buttons on the side of the watch face. Use a pointed object (like a pen tip) to press and hold the 'SET' button until the time flashes. Use the 'MODE' button to adjust hours and minutes, then press 'SET' again to confirm.
3. **Strap Adjustment:** The pink polka dot strap is adjustable to fit wrists from 5.5" to 8". Adjust the buckle to ensure a comfortable and secure fit.



The Minnie Mouse watch as it appears in its retail packaging, ready for unboxing.

3. Operating Instructions

This watch features interactive elements for an engaging experience:

- **Flashing LED Lights:** To activate the colorful LED lights, press the flip cover down. The lights will illuminate around the watch face.
- **Musical Sound Effects:** Press the designated button (often labeled "Push Here for Sound" or similar) to play the Minnie Boutique Theme Song.
- **Digital Time Display:** The time is displayed clearly on the LCD screen beneath the flip cover.




10:10
MINNIE



The watch with its flip cover open, showing the vibrant flashing lights around the watch face.





An image illustrating the musical feature of the watch, with musical notes emanating from the watch.



A close-up of the watch highlighting the 'Press Here' button for activating sound and lights.



A child wearing the Minnie Mouse watch, demonstrating its use and appeal to young users.

Your browser does not support the video tag.

Official product video demonstrating the musical and flashing light features of the Minnie Mouse watch (Model: MBT3714SR).

4. Maintenance

To ensure the longevity of your Minnie Mouse watch, please follow these maintenance guidelines:

- **Water Resistance:** This watch is **NOT** water resistant. Keep it away from water, including baths, showers, swimming pools, and heavy rain, to prevent damage.
- **Cleaning:** Gently wipe the watch with a soft, dry cloth to remove dust and smudges. Avoid using harsh chemicals or abrasive materials.

- **Battery Replacement:** The watch requires 1 Lithium Ion battery. When the lights dim or sound effects weaken, it may be time to replace the battery. Battery replacement should be performed by an adult.

5. Troubleshooting

If you encounter any issues with your watch, refer to the common solutions below:

Problem	Possible Cause / Solution
Lights not flashing / Sound not playing	• Battery may be low or depleted. Replace the Lithium Ion battery. • Ensure the flip cover is fully closed and pressed down to activate lights. • Ensure the sound button is pressed firmly.
Digital time display is blank or incorrect	• Battery may be low or depleted. Replace the Lithium Ion battery. • Time may need to be reset. Refer to "Setup and Initial Use" section for time setting instructions.
Flip cover does not close properly	• Check for any obstructions preventing the cover from closing. • Ensure the hinge mechanism is not damaged.

6. Product Specifications

- **Model Number:** MBT3714SR
- **Brand:** Disney
- **Manufacturer:** Accutime Watch Corp.
- **Material:** Plastic (strap and casing)
- **Case Size:** 32mm
- **Recommended Age:** 6 years and up
- **Batteries:** 1 Lithium Ion battery (included)
- **Package Dimensions:** 6.1 x 2.91 x 2.6 inches
- **Item Weight:** 1.6 ounces
- **Water Resistance:** Not water resistant

7. Warranty and Support

Your Disney Minnie Mouse Kids Flashing Musical Watch comes with a **ONE-year warranty** from the manufacturer, Accutime Watch Corp. We also offer a **30-day return or exchange policy**.
If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact our customer service team. We are committed to providing high-quality support.
For support, please refer to the contact information provided on the product packaging or the official Disney/Accutime Watch Corp.

website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question