Lovehoney Desire

Lovehoney Desire Luxury G-Spot Vibrator User Manual

Model: Desire

Introduction

The Lovehoney Desire Luxury G-Spot Vibrator is a personal massager designed for internal stimulation. Crafted from luxurious silicone, it features a curved tip, 8 vibration patterns, and 12 intensity levels, offering a total of 20 settings. This device is USB rechargeable and fully submersible for versatile use.



Image: The Lovehoney Desire Luxury G-Spot Vibrator in purple, shown upright. It features a smooth silicone body with a control panel at the base.

Safety Information

- **Material Compatibility:** This vibrator is made of silicone. For optimal care and to prevent material degradation, use only water-based lubricants. Avoid silicone-based lubricants, as they can damage the product's surface.
- **Cleaning:** Always clean the vibrator before and after each use with a toy cleaner or mild soap and warm water.
- **Storage:** Store in a clean, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Discontinue Use:** If you experience any discomfort or irritation, discontinue use immediately.

Package Contents

Your Lovehoney Desire Luxury G-Spot Vibrator package includes:

- Lovehoney Desire Luxury G-Spot Vibrator (Purple)
- USB Charging Cable
- Instruction Manual

Setup

Initial Charging

Before first use, fully charge your vibrator. Locate the charging port, typically at the base of the device. Insert the small end of the provided USB charging cable into the port and the larger end into a standard USB power source (e.g., computer, USB wall adapter). The indicator light will show charging status and turn solid when fully charged. A full charge typically takes 2-3 hours.



Image: The Lovehoney Desire Luxury G-Spot Vibrator in purple, with its USB charging cable connected to the base, illustrating the charging process.

Preparation for First Use

After charging, clean the vibrator thoroughly as described in the Maintenance section before its initial use.

Operating Instructions

Power On/Off

- To turn on: Press and hold the '+' button for approximately 2 seconds. The vibrator will start at a moderate intensity.
- To turn off: Press and hold the '-' button for approximately 2 seconds. Be careful not to hold it too long if you intend to only decrease intensity.

Adjusting Vibration Modes and Intensity

- **Changing Patterns:** Press the central power button (circle icon) to cycle through the 8 distinct vibration patterns.
- **Increasing Intensity:** Press the '+' button to increase the vibration intensity. There are 12 levels of intensity.
- **Decreasing Intensity:** Press the '-' button to decrease the vibration intensity.



Image: The Lovehoney Desire Luxury G-Spot Vibrator, highlighting its control panel and the variety of 8 patterns and 12 intensity levels available.

Usage Tips

Apply a generous amount of water-based lubricant to the vibrator and the desired area before use. Experiment with different patterns and intensity levels to find what is most pleasurable. The curved tip is specifically designed for G-spot stimulation.



Image: A close-up view of the Lovehoney Desire Luxury G-Spot Vibrator's curved tip, designed for targeted stimulation.

Maintenance

Cleaning

Clean your vibrator thoroughly before and after each use. Wash with warm water and a mild, antibacterial soap or a specialized toy cleaner. Rinse thoroughly and pat dry with a lint-free cloth. Ensure no water enters the charging port if it is not fully sealed when open.

Storage

Store the vibrator in a clean, dry, and dust-free environment. Keep it away from extreme temperatures, direct sunlight, and other toys made of different materials to prevent potential reactions or damage.



Image: A hand holding the Lovehoney Desire Luxury G-Spot Vibrator, with text confirming its waterproof and submersible design, making it easy to clean.

Troubleshooting

- **Device not turning on:** Ensure the device is fully charged. If the battery is depleted, connect it to the USB charger and allow it to charge for at least 2 hours.
- **Vibrations are weak:** The battery might be low. Recharge the device.
- **Controls unresponsive:** Ensure the device is not locked (if applicable, though not specified for this model).

Try turning it off and on again. If issues persist, contact customer support.

- **Charging issues:** Check the USB cable and power source. Try a different cable or adapter. Ensure the charging port is clean and free of debris.

Specifications

Brand	Lovehoney
Model Name	Desire
Material	Silicone
Color	Purple
Vibration Modes	8 Patterns, 12 Intensity Levels (20 settings total)
Power Source	USB Rechargeable (1 Product Specific battery included)
Waterproof	Yes, submersible
Insertable Length	5.5 inches
Product Dimensions	12.2 x 5.51 x 3.15 inches
Weight	1.46 pounds



Image: The Lovehoney Desire Luxury G-Spot Vibrator shown alongside a graphic illustrating its 5.5-inch insertable length.

Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and use of the Lovehoney Desire Luxury G-Spot Vibrator. This video provides a visual guide to the product's design and functionality.

Warranty and Support

For warranty information or customer support, please refer to the packaging or contact Lovehoney directly through their official website. Keep your proof of purchase for any warranty claims.