Zeppelin 76801

Zeppelin 100 Years of ED. 1 Analog Silver Dial Men's Watch

Model: 76801

Introduction Setup Guide Operating Your Watch Care & Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Welcome to the user manual for your Zeppelin 100 Years of ED. 1 Analog Silver Dial Men's Watch, Model 76801. This timepiece embodies the technical sophistication and timeless beauty inspired by the legendary Zeppelin airships. Crafted with precision in Germany, this watch offers a distinctive design and high-quality performance.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your watch to ensure its longevity and optimal performance.



Front view of the Zeppelin 100 Years ED. 1 Analog Silver Dial Men's Watch, showcasing its elegant design and chronograph features.

2. Setup Guide

2.1. Unboxing

Upon receiving your watch, carefully remove it from its packaging. Inspect the watch for any visible damage. Keep the original packaging and any included documents, such as the warranty card, in a safe place.

2.2. Setting the Time and Date

1. **Setting the Date:** Gently pull the crown (the knob on the side of the watch) out to the first click position. Rotate the crown either clockwise or counter-clockwise (depending on the movement) until the correct date is displayed in the date window.
2. **Setting the Time:** Pull the crown out further to the second click position. The second hand will stop. Rotate the crown to move the hour and minute hands to the desired time. Ensure you set the correct AM/PM for the date change mechanism.
3. **Finalizing:** Once the time and date are set, push the crown back in completely to its original position. The second hand will resume movement.

2.3. Adjusting the Leather Strap

The watch features a high-quality leather strap with a buckle clasp. To adjust the fit, simply thread the strap through the buckle and secure the pin into the appropriate hole that provides a comfortable and secure fit on your wrist. Ensure the watch is not too tight or too loose.



Rear view of the watch, highlighting the case back, crown, and pushers for time and chronograph adjustments.

3. Operating Your Watch

3.1. Basic Timekeeping

Your Zeppelin watch displays hours, minutes, and seconds using its main hands. The silver dial provides clear legibility for accurate time reading.

3.2. Chronograph Function

This watch is equipped with a chronograph, allowing you to measure elapsed time. The chronograph features three sub-dials and two pushers located on either side of the crown.

- **Start/Stop:** Press the top pusher (usually at 2 o'clock position) to start the chronograph. Press it again to stop the measurement.
- **Reset:** After stopping the chronograph, press the bottom pusher (usually at 4 o'clock position) to reset all chronograph hands back to their zero positions.
- **Sub-dials:** The sub-dials typically measure elapsed seconds, minutes, and hours (e.g., 60-second counter, 60-minute counter, 12-hour counter). Refer to the specific markings on your watch's dial for precise readings.

3.3. Date Display

The watch features a date window, typically located at the 4 o'clock position. The date automatically advances every 24 hours. If manual adjustment is needed (e.g., after months with fewer than 31 days), follow the steps in section 2.2.

4. Care and Maintenance

4.1. Cleaning

To maintain the appearance of your watch, clean it regularly with a soft, dry cotton cloth. For the case and crystal, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.

4.2. Water Resistance

Your watch has a water resistance rating of 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes or brief immersion in water, such as rain or hand washing. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in to maintain water resistance.

4.3. Battery Replacement

This quartz watch requires 1 Lithium Metal battery. When the watch stops or the second hand begins to jump erratically (an End-of-Life indicator), it's time for a battery replacement. We recommend having the battery replaced by a qualified watchmaker to ensure proper sealing and maintain water resistance.

4.4. Leather Strap Care

The leather strap is susceptible to wear and tear from moisture, sweat, and direct sunlight. To prolong its life, avoid prolonged exposure to water and extreme temperatures. Clean the strap with a soft, damp cloth and allow it to air dry naturally. Consider replacing the strap if it shows significant signs of wear or damage.

5. Troubleshooting Common Issues

Problem	Possible Cause	Solution
Watch not running	Depleted battery; Crown not pushed in; Internal movement issue.	Check if the crown is fully pushed in. If not, push it in. If the watch still doesn't run, the battery may need replacement. Consult a professional watchmaker.
Time is incorrect	Time was not set correctly; Crown accidentally pulled out; Impact.	Reset the time following the instructions in section 2.2. Ensure the crown is fully pushed in. If the problem persists after an impact, seek professional service.
Date not changing	Incorrect AM/PM setting; Date mechanism issue.	Manually advance the date using the crown (section 2.2). Ensure the time is set correctly for AM/PM. If the date still does not change, professional inspection may be required.
Chronograph hands not resetting to zero	Chronograph not stopped before reset; Internal mechanism issue.	Ensure the chronograph is stopped before pressing the reset pusher. If hands are misaligned, some quartz chronographs allow for manual calibration (refer to a watch specialist if unsure).

6. Product Specifications

Feature	Detail
Model Number	76801
Dial Color	Silver
Dial Style	Analog
Case Material	Stainless Steel
Case Diameter	36 mm
Strap Material	Leather (Brown)
Clasp Type	Buckle
Movement Type	Quartz

Feature	Detail
Glass Type	Sapphire Crystal
Water Resistance	30 meters (3 ATM)
Battery Type	1 Lithium Metal battery
Item Weight	200 g
Country of Origin	Germany

7. Warranty and Customer Support

7.1. International Guarantee

Your Zeppelin watch comes with an International Guarantee of 2 years. To activate and utilize your warranty, please fill out the guarantee card provided with your watch and send it in the service case as instructed. This warranty covers manufacturing defects under normal use.
For detailed guarantee terms and maintenance information, please refer to the user's manual provided with your purchase or visit the manufacturer's website.



International Guarantee card for Zeppelin watches, detailing warranty period and manufacturer information.

7.2. Manufacturer and Importer Information

- **Manufacturer:** Electronic GmbH Steinheilstraße 6, 85737 Ismaning/München, Germany
- **Importer/Packer (India):** ETHOS Ltd, C-2, Upper Basement, Square One Mall, Delhi-110017

For further assistance, service inquiries, or to learn more about Zeppelin watches, please visit the official website: www.pointtec.de

© 2023 Zeppelin. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question