Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PATONA 1947

PATONA Dual USB Charger Instruction Manual

Model: 1947

Introduction

Thank you for choosing the PATONA Dual USB Charger. This manual provides essential information for the safe and efficient use of your charger. Please read these instructions carefully before use and retain them for future reference.

Product Overview

The PATONA Dual USB Charger is designed to charge two compatible camera batteries simultaneously. Its compact and lightweight design makes it ideal for travel. The charger features an automatic shutdown system to protect batteries from overcharging.

Compatibility:

- **Batteries:** EN-EL20, EN-EL20a
- **Cameras:** Nikon 1 AW1, Nikon 1 J1, Nikon 1 J2, Nikon 1 J3, Nikon 1 S1, Nikon 1 V3, Nikon Coolpix A, Nikon P950, Nikon P1000, Nikon P1100, Blackmagic Pocket



Figure 1: Front view of the PATONA Dual USB Charger.



Figure 2: Back view of the charger with technical specifications.

Safety Instructions

- Use only with compatible batteries as listed in the Product Overview section.
- Do not disassemble the unit. Disassembly may cause electric shock or fire.
- Keep the charger in a dry location. Avoid exposure to moisture or extreme temperatures.
- The integrated automatic shutdown system protects against overcurrent. However, always monitor the charging process.
- Do not use the charger if it is damaged.
- Keep out of reach of children.

Setup

1. Connect the provided USB cable to the charger's Micro USB port.
2. Connect the other end of the USB cable to a compatible USB power source (e.g., a USB wall adapter, power bank, or

computer USB port) with an output of DC 5V / 2.1A.

3. The charger's indicator lights will illuminate briefly, indicating it is ready for use.



Figure 3: Charger connected to a USB cable.

Operating Instructions

1. Ensure the charger is connected to a power source as described in the Setup section.
2. Insert one or two compatible batteries into the charging slots (CH1 and CH2). Ensure the battery contacts align correctly with the charger's pins.
3. The indicator light for each slot will turn red, indicating that charging has begun.
4. When a battery is fully charged, its corresponding indicator light will turn green.
5. Once charging is complete, remove the batteries from the charger.
6. Disconnect the charger from the power source when not in use.



Figure 4: Charger with charging slots and indicator lights.

Maintenance

- Clean the charger with a soft, dry cloth. Do not use liquid cleaners or solvents.
- Ensure the charging contacts are free from dust and debris.
- Store the charger in a cool, dry place when not in use.
- Avoid dropping or subjecting the charger to strong impacts.

Troubleshooting

Problem	Possible Cause	Solution
Charger indicator lights do not turn on.	No power supply or faulty connection.	Check USB cable connection and power source. Ensure the power source provides DC 5V / 2.1A.
Battery not charging (indicator remains green or off).	Battery not inserted correctly, battery is already fully charged, or battery is faulty.	Re-insert the battery, ensuring proper contact. Test with a different battery if available.
Slow charging.	Insufficient power from the USB source.	Ensure the USB power source provides at least DC 5V / 2.1A.

Specifications

- **Model:** 1947
- **Brand:** PATONA
- **Color:** Yellow
- **Product Dimensions:** 11.5 cm (Depth) x 7 cm (Width) x 2 cm (Height)
- **Input:** DC 5V / 2.1A
- **Output:** DC 8.4V / 700mA (for 1 battery) / 500mA (for 2 batteries)
- **Output Voltage:** 7.4 Volt (DC)

- **Compliance:** CE

Warranty and Support

PATONA products are manufactured to high-quality standards. For warranty information or technical support, please refer to the official PATONA website or contact your retailer. You can also visit the PATONA Store on Amazon for more information.

© 2023 PATONA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B018UFJ7FA

More documents and user manuals: **https://manuals.plus/**