Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DAEWOO DWF-DG362ARR1

DAEWOO DWF-DG362ARR1 18 Kg Automatic Washing Machine User Manual

Model: DWF-DG362ARR1

1. Introduction

Thank you for purchasing the DAEWOO DWF-DG362ARR1 18 Kg Automatic Washing Machine. This manual provides essential information for the safe and efficient operation, installation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before using the washing machine and retain it for future reference.

2. Safety Information

To prevent personal injury or property damage, observe all safety precautions listed below. Failure to follow these instructions may result in electric shock, fire, explosion, or other hazards.

- **Electrical Safety:** Ensure the washing machine is connected to a properly grounded 127 Volt electrical outlet. Do not use extension cords or adapters. Disconnect power before cleaning or servicing.
- **Water Supply:** Connect the water inlet hoses securely to prevent leaks. Ensure water pressure is within the recommended range.
- **Installation:** Install the washing machine on a firm, level surface. Ensure adequate clearance around the appliance for ventilation and service.
- **Children and Pets:** Keep children and pets away from the washing machine during operation. Do not allow them to play with the appliance.
- **Flammable Materials:** Do not wash items that have been soiled with flammable substances (e.g., gasoline, solvents). Keep flammable materials away from the appliance.
- **Maintenance:** Only perform maintenance as described in this manual. For complex repairs, contact qualified service personnel.

3. Product Overview

The DAEWOO DWF-DG362ARR1 is an 18 Kg capacity automatic top-load washing machine designed for efficient and convenient laundry care. It features a durable iron drum and a user-friendly digital control panel.

Key Features:

- **Capacity:** 18 Kilograms
- **Control Panel:** EZ PAD Digital Touch Control
- **Dispenser:** Two compartments for detergent and softener
- **Wash System:** Pulsator for effective cleaning
- **Access:** Top-load design
- **Cycles:** 6 standard wash programs (Normal, Heavy, Delicate, Quick, etc.)
- **Spin Speed:** Maximum 800 RPM
- **Drum Material:** Iron
- **Color:** Red finish

Components:



Figure 3.1: Top-front view of the DAEWOO DWF-DG362ARR1 washing machine, showcasing the red exterior, transparent top lid, and the EZ PAD digital control panel.



Figure 3.2: Angled top view of the DAEWOO DWF-DG362ARR1 washing machine, highlighting the top-load access and the layout of the control panel.

- **Control Panel:** Located at the top rear, featuring touch controls and an LED/LCD display for program selection and status.
- **Lid:** Transparent top lid for easy viewing of the wash process.
- **Wash Tub/Drum:** Inner iron drum where laundry is placed.
- **Detergent/Softener Dispenser:** Compartments for adding washing agents.
- **Pulsator:** Located at the bottom of the wash tub, responsible for agitating clothes.

4. Setup and Installation

Proper installation is crucial for the performance and longevity of your washing machine. Follow these steps carefully.

1. **Unpacking:** Remove all packaging materials, including the base packaging and any internal packing from the drum. Keep packaging materials away from children.
2. **Location:** Place the washing machine on a solid, level floor. Avoid direct sunlight or areas with high humidity. Ensure there is sufficient space for opening the lid and for water/drain connections.
3. **Leveling:** Adjust the leveling feet at the bottom of the machine until it is perfectly stable and level. An unlevel machine can cause excessive vibration and noise during operation.
4. **Water Connection:** Connect the cold water inlet hose to the cold water tap and the corresponding inlet on the back of the washing machine. Ensure connections are tight to prevent leaks.
5. **Drain Hose:** Position the drain hose into a standpipe or over the edge of a sink. Ensure the drain hose is securely fixed to prevent it from dislodging during draining. The end of the drain hose should be between 60 cm and 90 cm from the floor.
6. **Power Connection:** Plug the power cord into a grounded 127 Volt, 60 Hz electrical outlet. Do not share the outlet with other high-power appliances.
7. **First Use:** Before washing clothes, run a short cycle without laundry and detergent to flush out any manufacturing residues.

5. Operating Instructions

Follow these steps for effective and safe operation of your DAEWOO washing machine.

1. **Prepare Laundry:** Sort clothes by fabric type, color, and soil level. Close zippers, fasten hooks, and tie strings to prevent damage.
2. **Load Laundry:** Open the top lid and load clothes loosely into the wash tub. Do not overload the machine; ensure there is enough space for clothes to move freely. The maximum capacity is 18 Kg.
3. **Add Detergent and Softener:**
    - **Detergent:** Pour the recommended amount of liquid or powder detergent into the designated detergent compartment of the dispenser.
    - **Softener:** Pour liquid fabric softener into the designated softener compartment. Do not exceed the maximum fill line.
4. **Select Wash Cycle:** Close the lid. Turn on the washing machine using the power button on the EZ PAD digital control panel. Use the touch controls to select the desired wash cycle. Available cycles include:
    - **Normal:** For everyday cottons and mixed fabrics.
    - **Heavy (Pesada):** For heavily soiled or durable items.
    - **Delicate (Delicada):** For fragile items requiring gentle washing.
    - **Quick (Rápido):** For lightly soiled items needing a fast wash.
    - And other standard cycles as indicated on the control panel.
5. **Adjust Settings (if applicable):** Depending on the selected cycle, you may be able to adjust water level, temperature, or spin speed using the control panel.
6. **Start Wash:** Press the Start/Pause button to begin the wash cycle. The machine will automatically fill with water and proceed through the selected program.
7. **End of Cycle:** The machine will signal when the cycle is complete. Remove laundry promptly to prevent wrinkles.

6. Maintenance and Care

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Dispenser Cleaning:** Periodically remove and clean the detergent and softener dispenser compartments to prevent residue buildup. Rinse with warm water and dry thoroughly before reinserting.
- **Wash Tub Cleaning:** Run a "Tub Clean" cycle (if available) or a hot wash cycle with a washing machine cleaner or a cup of white vinegar to remove detergent residue and odors.
- **Water Inlet Filters:** Check and clean the mesh filters in the water inlet hoses periodically to prevent blockages. Turn off the water supply and disconnect the hoses before cleaning.
- **Drain Filter (if applicable):** Some models have a drain pump filter. Refer to the specific diagram in your full manual for its location and cleaning instructions.
- **Lid Gasket:** Wipe the lid gasket after each wash to remove moisture and lint, preventing mold and mildew growth.
- **Long-Term Storage:** If the machine will not be used for an extended period, disconnect it from power and water supply, drain all water, and leave the lid slightly ajar to prevent odors.

7. Troubleshooting

Before contacting service, refer to the following common issues and their solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed properly; Power outage; Cycle not selected.	Check power connection; Ensure lid is fully closed; Check household circuit breaker; Select a wash cycle and press Start.
No water filling	Water tap off; Water inlet hose kinked; Water inlet filter clogged.	Open water tap; Straighten hose; Clean water inlet filter.
Machine does not drain	Drain hose kinked or blocked; Drain pump filter clogged (if applicable).	Straighten or clear drain hose; Clean drain pump filter (refer to full manual for location).
Excessive vibration/noise	Machine not level; Shipping bolts not removed; Overloaded or unbalanced load.	Adjust leveling feet; Ensure all shipping bolts are removed; Redistribute laundry evenly; Reduce load size.
Water leaks	Loose hose connections; Damaged hose; Overfilling.	Tighten hose connections; Replace damaged hose; Ensure drain hose is at correct height.

If the problem persists after attempting these solutions, please contact DAEWOO customer service.

8. Specifications

Feature	Detail
Model Name	DWF-DG362ARR1
Brand	DAEWOO
Capacity	18 Kilograms
Access Type	Top Load
Control Type	Digital EZ PAD (Touch)
Wash System	Pulsator
Number of Standard Cycles	6 (Normal, Heavy, Delicate, Quick, etc.)
Maximum Spin Speed	800 RPM
Voltage	127 Volts
Noise Level	55 Decibels
Drum Material	Iron
Color	Red
Product Weight	46000 Grams (46 Kg)
Installation Method	Freestanding (Built-In refers to design, not cabinetry integration for this top-loader)

9. Warranty and Support

Your DAEWOO DWF-DG362ARR1 washing machine comes with a **3-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.
For warranty claims, technical assistance, or to purchase genuine spare parts, please contact DAEWOO customer service. Have your model number (DWF-DG362ARR1) and proof of purchase ready when contacting support.
Please refer to the warranty card included with your product for full terms and conditions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question