QUICK CONNECT DWF-110

QUICK CONNECT Lawn Mower Deck Wash Two Hose Attachment Instruction Manual

Model: DWF-110

1. Product Overview

The QUICK CONNECT Lawn Mower Deck Wash Adapter is designed to simplify the cleaning process of your mower deck. This attachment connects to your mower's deck wash port and a standard garden hose, allowing water to spray underneath the deck to remove grass clippings, dirt, and debris. Regular use helps maintain blade performance and prevents corrosion.

Key Features:

- Includes: (2) Green Lawn Mower Deck Wash Adapters.
- Compatible with a wide range of popular riding mower brands, including Cub Cadet, MTD, and Troy-Bilt.
- Constructed from durable, weather-resistant plastic for longevity.
- Facilitates quick and efficient cleaning of mower decks.



Figure 1: Two QUICK CONNECT Lawn Mower Deck Wash Adapters. These adapters are green and black, designed for connecting a garden hose to a mower deck wash port.

2. Safety Information

Always prioritize safety when operating or maintaining lawn care equipment. Read and understand all instructions before using the deck wash attachment.

- **Engine Off:** Ensure the lawn mower engine is completely off, the spark plug wire is disconnected, and the blades are disengaged before attaching or detaching the adapter.
- **Stable Surface:** Position the mower on a flat, stable surface to prevent accidental movement during cleaning.
- **Water Pressure:** Use moderate water pressure. Excessive pressure may damage the mower deck or the attachment.
- **Personal Protective Equipment:** Consider wearing appropriate personal protective equipment, such as gloves and eye protection, to prevent contact with debris or water spray.
- **Children and Pets:** Keep children and pets away from the work area during cleaning operations.
- **Inspect Before Use:** Before each use, inspect the adapter for any signs of damage or wear. Do not use if damaged.

3. Setup

Follow these steps to properly set up your Lawn Mower Deck Wash Attachment.

1. **Prepare the Mower:**
    - Park the lawn mower on a level, stable surface.
    - Turn off the engine and remove the ignition key.
    - Disconnect the spark plug wire to prevent accidental starting.
    - Ensure the mower deck is cool to the touch.
2. **Locate the Deck Wash Port:**

    Identify the deck wash port on your lawn mower deck. This is typically a small nozzle or fitting designed for hose connection.



Figure 2: A single QUICK CONNECT Lawn Mower Deck Wash Adapter. This image shows the adapter's design, featuring a green body and a black threaded connector.

3. **Attach the Adapter to the Mower:**

Thread the black end of the QUICK CONNECT adapter onto the mower's deck wash port. Tighten by hand until snug. Do not overtighten.



Figure 3: Side view of the QUICK CONNECT adapter, highlighting the connection points. The green part is the main body, and the black part is the threaded connector.

4. **Connect the Garden Hose:**

   Attach a standard garden hose to the green quick-connect end of the adapter. Ensure a secure connection to prevent leaks.





Figure 4: Top-down view of the adapter, showing the opening where the garden hose connects. The internal threading is visible.

4. Operating Instructions

Once the adapter is securely attached and the hose is connected, you can proceed with cleaning the mower deck.

1. **Turn on Water:** Slowly turn on the water supply to the garden hose. Water will begin to spray underneath the mower deck.
2. **Start Mower (if applicable):** For some mower models, it may be necessary to briefly start the mower engine (with

blades engaged) to allow the rotating blades to help distribute the water and dislodge debris. Consult your mower's instruction manual for specific recommendations. *Ensure all safety precautions are followed if the engine is started.*

3. **Run Water:** Allow the water to run for 1-2 minutes, or until the water draining from under the deck runs clear. This indicates that most of the grass clippings and debris have been flushed out.
4. **Turn off Water and Engine:** Turn off the water supply to the hose. If the mower engine was running, turn it off and disconnect the spark plug wire again.
5. **Disconnect Adapter:** Disconnect the garden hose from the adapter, then unthread the adapter from the mower deck wash port.





Figure 5: An angled view of the adapter, showing its compact design. This perspective highlights the ease of handling and connection.

5. Maintenance

Proper maintenance will extend the life of your QUICK CONNECT Deck Wash Attachment.

- **Rinse After Use:** After each use, rinse the adapter with clean water to remove any remaining debris or chemical residue.
- **Inspect for Damage:** Periodically inspect the adapter for cracks, wear, or damage to the threads or quick-connect mechanism. Replace if damaged.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Prevent Freezing:** If storing in freezing conditions, ensure all water is drained from the adapter to prevent ice damage.

6. Troubleshooting

This section addresses common issues you might encounter with the deck wash attachment.

Problem	Possible Cause	Solution
Water leaking from connection points.	Loose connection, damaged O-ring/washer, or damaged threads.	Ensure connections are hand-tight. Check for and replace any worn or damaged O-rings or washers. Inspect threads for damage.
Insufficient water spray under deck.	Low water pressure, clogged adapter, or clogged mower deck port.	Increase water pressure from the hose. Disconnect and inspect the adapter for blockages. Check the mower's deck wash port for obstructions.
Adapter does not fit mower deck port.	Incompatible mower model.	Verify that your mower model is listed as compatible with this adapter. While designed for a wide range, some specific models may vary.

7. Specifications

- **Part Number:** DWF-110
- **Item Weight:** 1.6 ounces
- **Package Dimensions:** 2.76 x 2.64 x 1.34 inches
- **Item Model Number:** DWF-110

- **Style:** Two Hose Attachment
- **Item Package Quantity:** 2
- **Material:** Durable, weather-resistant plastic

8. Warranty Information

Specific warranty details for the QUICK CONNECT Lawn Mower Deck Wash Two Hose Attachment are typically provided by the manufacturer or the retailer at the time of purchase. Please refer to your purchase documentation or contact the seller directly for information regarding warranty coverage, terms, and conditions.

9. Support

For further assistance or inquiries regarding your QUICK CONNECT Lawn Mower Deck Wash Two Hose Attachment, please consider the following resources:

- **Manufacturer's Website:** Visit the official QUICK CONNECT website for product information, FAQs, and contact details.
- **Retailer Support:** Contact the customer service department of the retailer from whom you purchased the product.
- **Online Resources:** Search for instructional videos or community forums related to lawn mower deck wash attachments for additional tips and troubleshooting advice.

© 2024 QUICK CONNECT. All rights reserved.