Faber MIRR36BK

Faber Mirror Stainless Steel Wall Range Hood

Model: **MIRR36BK**

Brand: **Faber**

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Faber Mirror Stainless Steel Wall Range Hood, Model MIRR36BK. Please read this manual thoroughly before installation and use, and keep it for future reference.



Image: The Faber Mirror Stainless Steel Wall Range Hood, Model MIRR36BK, shown with its sleek black finish and angled design, featuring the control panel and halogen lights visible beneath the upper panel.

Safety Information

Always adhere to basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury to persons.

- Ensure proper installation by a qualified technician in accordance with all local codes and ordinances.
- Do not operate the range hood if the power cord is damaged.
- Clean grease filters regularly to prevent grease accumulation and potential fire hazards.
- Never flambé under the range hood.
- This appliance is for domestic use only.

Product Features

- **Powerful Ventilation:** 600 CFM PRO extraction capacity for efficient removal of smoke and odors.
- **Electronic Soft Touch Controls:** Intuitive and easy-to-use control panel for fan speed and lighting.
- **Halogen Lighting:** Two five-level halogen lights provide ample illumination for your cooking surface.
- **Dishwasher Safe Mesh Filters:** Easy to remove and clean, ensuring optimal performance and hygiene.
- **Durable Construction:** Made from high-quality stainless steel with a brushed finish.

Setup and Installation

The Faber Mirror Stainless Steel Wall Range Hood is designed for wall-mount installation. Professional installation is highly recommended to ensure proper function and safety.

Pre-Installation Checklist:

1. Verify all components are present and undamaged.
2. Ensure adequate electrical supply (refer to specifications).
3. Confirm proper ducting is available and correctly sized.
4. Measure and mark mounting points accurately on the wall.

Installation Steps (Summary):

1. Mount the wall bracket securely to the wall studs.
2. Attach the range hood body to the wall bracket.
3. Connect the ductwork to the exhaust outlet.
4. Connect the electrical wiring according to local codes.
5. Install the decorative chimney sections (if applicable).
6. Insert the mesh filters.

For detailed installation instructions, refer to the separate installation guide provided with your product or consult a certified installer.

Operating Instructions

Your Faber range hood features electronic soft touch controls for ease of use.

Control Panel Functions:

- **Power Button:** Press to turn the hood on or off.
- **Fan Speed Buttons:** Use '+' and '-' buttons to adjust fan speed (multiple levels available).
- **Light Button:** Press to turn the halogen lights on or off.
- **Timer Button:** Activates the delayed shut-off function (if available).

Always turn on the range hood a few minutes before cooking to establish airflow and turn it off a few minutes after cooking to clear residual odors.

Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your range hood.

Cleaning the Mesh Filters:

- The mesh filters should be cleaned regularly, ideally every 3-4 weeks depending on usage.

- Remove the filters by pulling the release latch.
- Filters are dishwasher safe; place them in the dishwasher on a normal cycle.
- Alternatively, wash by hand with hot water and a mild detergent.
- Ensure filters are completely dry before re-installing.

Cleaning the Exterior:

- Wipe the stainless steel surfaces with a soft cloth dampened with warm water and a mild, non-abrasive cleaner.
- For stubborn stains, use a stainless steel cleaner, always wiping in the direction of the grain.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals.

Replacing Halogen Bulbs:

- Ensure the power to the hood is off and the bulbs are cool before attempting replacement.
- Carefully remove the old bulb.
- Replace with a new halogen bulb of the same wattage and type (refer to specifications).

Troubleshooting

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Hood does not turn on.	No power supply; tripped circuit breaker.	Check power connection; reset circuit breaker.
Poor suction.	Clogged filters; obstructed ductwork; incorrect fan speed.	Clean or replace filters; check ducting for obstructions; increase fan speed.
Excessive noise.	Loose components; motor issue; ducting issue.	Check for loose parts; ensure proper installation; consult a technician if motor noise persists.
Lights not working.	Burnt out bulbs; loose connection.	Replace bulbs; check light connections.

If the problem persists after attempting these solutions, please contact Faber customer support.

Specifications

Attribute	Value
Model	MIRR36BK
Brand	Faber
Mounting Type	Wall Mount
Controls Type	Touch
Light Source Type	Halogen (2 lights, five level)
Filter Type	Mesh (Dishwasher Safe)
Noise Level	50 dB

Attribute	Value
Material	Stainless Steel
Finish Type	Brushed
Color	Multicolour (primarily black and stainless steel)
Extraction Capacity	600 CFM PRO
Specification Met	ETL

Warranty and Support

Faber products are manufactured to high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official Faber website. Keep your proof of purchase for warranty claims.

For technical assistance, spare parts, or service inquiries, please contact Faber customer support. Contact information can typically be found on the manufacturer's website or in the product packaging.

Online Resources: For additional support, FAQs, and product registration, visit the official Faber website.

© 2024 Faber. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question