Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wahl Professional Magic Clip 5 Stars Series, Type STX

Wahl Magic Clip 5 Stars Series Type STX Professional Hair Clipper User Manual

Model: Magic Clip 5 Stars Series, Type STX

Introduction

Thank you for choosing the Wahl Magic Clip 5 Stars Series Type STX Professional Hair Clipper. This powerful corded hair clipper is designed for high performance and continuous use, making it an excellent tool for professional barbers and home users alike. It is specifically engineered for close cuts and precise fading, featuring a fine blade head adjustable to achieve a '0' level cut.

This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your new clipper. Please read it thoroughly before first use and keep it for future reference.

Safety Information

Warning: For adult use only. Keep away from water. Do not use on infants or children. Always unplug the trimmer before cleaning or replacing parts. Always follow the manufacturer's instructions for use and maintenance.

Product packaging may contain different information than shown on our site. Please always read the label, warnings, and instructions provided with the product before use or consumption.

What's in the Box

Your Wahl Magic Clip 5 Stars Series Type STX Professional Hair Clipper package includes:

- Wahl Magic Clip Hair Clipper
- Power Cord (2.4 m length)
- 8 Guide Combs (1.5 mm, 3 mm, 4.5 mm, 6 mm, 10 mm, 13 mm, 19 mm, and 25 mm)
- Flat-top Comb
- Blade Guard
- Clipper Oil
- Cleaning Brush



Image: The Wahl Magic Clip hair clipper displayed with its complete set of accessories, including multiple guide combs, a flat-top comb, blade guard, oil, and cleaning brush.

Setup

1. **Unpack the Clipper:** Carefully remove the clipper and all accessories from the packaging.
2. **Inspect for Damage:** Check the clipper and its components for any signs of damage. Do not use if damaged.
3. **Initial Blade Oiling:** Before first use, apply a few drops of the included clipper oil to the blades. Turn the clipper on for a few seconds to distribute the oil. Wipe off any excess oil.
4. **Connect to Power:** Ensure the clipper is securely plugged into a suitable 230V AC power outlet. This is a corded clipper and does not require batteries.
5. **Attach Guide Comb (Optional):** Select the desired guide comb for your preferred hair length. Align the comb with the clipper blade and snap it securely into place. Ensure it is firmly attached before use.



Image: A selection of Wahl guide combs, illustrating the different sizes available for varying hair cutting lengths.

Operating Instructions

1. **Prepare Hair:** Ensure hair is clean, dry, and free of tangles.
2. **Select Cutting Length:** If using a guide comb, ensure it is securely attached. For closer cuts and fading, the clipper features an adjustable blade lever. Move the lever to adjust the cutting height between 0.8 mm and 2.5 mm, or manually adjust to '0' for the closest cut.
3. **Turn On:** Flip the power switch to the 'ON' position. The clipper will start operating.
4. **Begin Cutting:** Hold the clipper firmly and move it gently against the direction of hair growth. Use smooth, overlapping strokes for an even cut.
5. **Fading and Blending:** Utilize the adjustable blade lever to seamlessly blend different hair lengths. Start with a longer setting and gradually move to shorter settings for a smooth fade.
6. **Detailing:** For precise outlining and detailing, remove the guide comb and use the clipper's bare blade, adjusting the lever for the desired closeness.
7. **Turn Off:** Once finished, flip the power switch to the 'OFF' position and unplug the clipper from the power outlet.



Image: A detailed view of the Wahl Magic Clip's adjustable blade lever, which allows for precise control over cutting length, and its chrome-plated blade.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your clipper.

- **Cleaning Blades:** After each use, turn off and unplug the clipper. Use the included cleaning brush to remove loose hair from the blades. For a more thorough cleaning, the blade head can be carefully removed (refer to manufacturer's instructions for specific removal steps).
- **Oiling Blades:** Apply 2-3 drops of Wahl clipper oil to the teeth and heel of the blades after every few uses or as needed. Turn the clipper on for a few seconds to allow the oil to penetrate. This lubricates the blades and prevents rust.
- **Blade Alignment:** Periodically check blade alignment. If blades become misaligned, refer to the manufacturer's detailed instructions for proper adjustment to ensure a smooth cut and prevent pulling.
- **Storage:** Store the clipper in a dry, safe place, out of reach of children. Use the blade guard to protect the blades when not in use.

Troubleshooting

If you encounter issues with your Wahl Magic Clip, refer to the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Clipper does not turn on	Not plugged in; power outlet issue; damaged cord	Ensure clipper is securely plugged in. Test the outlet with another device. Inspect the power cord for damage; if damaged, discontinue use and contact support.
Clipper pulls hair or cuts unevenly	Blades are dull, dirty, or misaligned; insufficient oiling; hair is not clean/dry	Clean and oil the blades. Check blade alignment and adjust if necessary. Ensure hair is clean and dry before cutting. Consider blade replacement if blades are dull.
Clipper gets hot during use	Extended continuous use; blades are dirty or not oiled	Allow the clipper to cool down. Clean and oil the blades thoroughly. Ensure proper ventilation around the motor.
Excessive vibration or noise	Loose screws; motor issue; blade alignment	Check and tighten any loose screws. Ensure blades are properly aligned. If the issue persists, contact customer support.

Specifications

Feature	Specification
Model Name	Magic Clip 5 Stars Series, Type STX
Cutting Height	0.8 - 2.5 mm (manually adjustable to 0)
Cutting Width	40 mm
Blade Material	Stainless Steel (Chrome-plated)
Motor	Professional Vibratory Motor, V 5000, 6000 rpm
Power Source	AC (Corded)
Voltage	230 V
Cable Length	2.4 m
Weight	590 g
Product Dimensions (LxWxH)	27 x 6 x 4 cm
Color	Red
Special Feature	Adjustable guide combs and precision detailing accessory included
UPC	043917027258
Model Number	4015110078456



Image: The Wahl Magic Clip 5 Stars Series Type STX professional hair clipper, highlighting its design and corded connection.

Warranty and Support

Wahl Professional products are manufactured to high standards and are warranted against defects in materials and workmanship. Please refer to the warranty card included with your product for specific terms, conditions, and duration of the warranty.
For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Wahl Professional customer support. Contact information can typically be found on the product packaging or the official Wahl Professional website.

- **Online Support:** Visit the official Wahl Professional website for FAQs, product registration, and additional resources.
- **Customer Service:** Refer to your product documentation for regional customer service contact details.

© 2023 Wahl Professional. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01AJYLTCO

More documents and user manuals: **https://manuals.plus/**