GPX PC332B

GPX PC332B Personal Compact Disc Player User Manual

Model: PC332B

Introduction

Welcome to your new GPX PC332B Personal Compact Disc Player. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

Important Safety Information

- Do not expose the unit to rain or moisture.
- Do not block any ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.
- Dispose of batteries properly.

Product Overview

Familiarize yourself with the components of your GPX PC332B.



Image: GPX PC332B Personal Compact Disc Player. The image shows the black, circular CD player with a digital display showing "12:02:49" and "FM RADIO". Various control buttons are visible on the top surface, including ON/OFF, SOURCE, ESP, PROG, STOP, MODE, SKIP/TUN-, SKIP/TUN+, and BBS. A volume dial and a 3.5mm headphone jack labeled "PHONES" are on the side. Two black wired earbuds are connected to the player.

Controls and Features

- **ON/OFF Button:** Powers the unit on or off.
- **SOURCE Button:** Switches between CD and FM Radio modes.
- **Digital Display:** Shows track number, time, radio frequency, and mode.
- **ESP (Electronic Skip Protection) Button:** Activates or deactivates skip protection for CD playback.
- **PROG (Program) Button:** Used to program CD tracks for custom playback order.
- **STOP Button:** Stops CD playback or radio tuning.
- **MODE Button:** Selects playback modes (e.g., Repeat, Random).
- **SKIP/TUN- / SKIP/TUN+ Buttons:** Skips tracks on CD or tunes radio frequency.
- **Play/Pause Button:** Starts or pauses CD playback.
- **BBS (Bass Boost System) Button:** Enhances bass output.
- **Volume Dial:** Adjusts the audio output level.
- **PHONES Jack:** 3.5mm stereo output for headphones.

Setup

Powering the Unit

The GPX PC332B can be powered by batteries or an optional AC adapter (not included).

Battery Installation

1. Open the battery compartment cover on the bottom of the unit.
2. Insert 2 x AA batteries (not included), ensuring correct polarity (+/-).
3. Close the battery compartment cover securely.

Connecting Headphones

Insert the 3.5mm plug of your headphones into the PHONES jack on the side of the unit.

Operating Instructions

CD Playback

1. Press the **ON/OFF** button to turn on the player.
2. Open the CD compartment cover by sliding the **OPEN** switch.
3. Place a CD with the label side facing up onto the spindle.
4. Close the CD compartment cover firmly until it clicks.
5. The player will begin reading the disc. The track number and playback time will appear on the display.
6. Press the **Play/Pause** button to start or pause playback.
7. Use the **SKIP/TUN-** or **SKIP/TUN+** buttons to skip tracks.
8. Adjust the volume using the **VOLUME** dial.
9. Press the **STOP** button to stop playback.

Using Electronic Skip Protection (ESP)

The ESP feature helps prevent audio skipping during minor shocks or vibrations. Press the **ESP** button to activate or deactivate this function.

Programming CD Tracks

1. In STOP mode, press the **PROG** button.
2. Use **SKIP/TUN-** or **SKIP/TUN+** to select the desired track.
3. Press **PROG** again to confirm and add the track to the program list.
4. Repeat for up to 20 tracks.
5. Press **Play** to start programmed playback.

FM Radio Operation

1. Press the **ON/OFF** button to turn on the player.
2. Press the **SOURCE** button until "FM RADIO" appears on the display.
3. Press and hold **SKIP/TUN-** or **SKIP/TUN+** to auto-scan for the next available station.
4. Press briefly to fine-tune the frequency.
5. Adjust the volume using the **VOLUME** dial.

Using Bass Boost System (BBS)

Press the **BBS** button to activate or deactivate the bass boost feature for enhanced low-frequency sound.

Maintenance and Care

- Clean the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the CD compartment clean and free of dust.
- Avoid exposing the unit to extreme temperatures, direct sunlight, or high humidity.
- Remove batteries if the unit will not be used for an extended period.

Troubleshooting

Problem	Possible Cause	Solution
No power	Batteries are dead or incorrectly inserted.	Replace batteries or check polarity.
CD skips or does not play	CD is dirty, scratched, or inserted incorrectly. ESP is off.	Clean or replace CD. Ensure CD is inserted label-side up. Activate ESP.
Poor radio reception	Weak signal or interference.	Adjust unit position. Extend headphone cable (acts as antenna).
No sound from headphones	Headphones not fully plugged in or volume too low.	Ensure headphones are securely connected. Increase volume.

Specifications

- **Model:** PC332B
- **Brand:** GPX
- **Item Weight:** 444.52 grams
- **Connectivity Technology:** Auxiliary
- **Special Feature:** Volume Control
- **Number of Discs:** 1
- **Supported Audio Format:** MP3
- **Media Format Type:** Digital
- **MP3 Player Included:** Yes
- **UPC:** 031112428635

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official GPX website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question