UGREEN 30333

UGREEN USB 3.0 Card Reader Instruction Manual

Model: 30333
Brand: UGREEN

1. Introduction

The UGREEN USB 3.0 Card Reader is a versatile 4-in-1 adapter designed for high-speed data transfer. It supports simultaneous reading and writing of various memory card types including SD, Micro SD, CF, and MS cards, offering speeds up to 5Gbps. This plug-and-play device is compatible with Windows, Mac OS, Linux, and Chrome OS, making it an ideal companion for photographers and users on the go.



Image: The UGREEN USB 3.0 Card Reader shown with different types of memory cards, including SD, Micro SD, CF, and MS, highlighting its multi-card compatibility.

2. Key Features

- **All in One Design:** Equipped with SD/Micro SD/CF/MS slots, supporting a wide range of standard memory cards including SD/SDXC/SDHC/Micro SD(TF)/Micro SDXC/Micro SDHC/UHS-I/Compact Flash/Memory Stick.
- **High-Speed Data Transfer:** USB 3.0 interface provides data transfer speeds up to 5Gbps, allowing for rapid transfer of large files.



Image: The UGREEN card reader with a visual representation of 5Gbps data transfer speed, emphasizing its efficiency.

- **Simultaneous Read and Write:** Supports reading and writing to four different memory cards concurrently, eliminating the need to swap cards. Compatible with cards up to 2TB capacity.



Image: The UGREEN card reader connected to a laptop, demonstrating multiple memory cards inserted and being read simultaneously.

- **Plug and Play:** Driver-free operation across various operating systems for immediate use.



Image: The UGREEN card reader with icons representing Windows, macOS, Chrome OS, and Linux, indicating its plug-and-play compatibility across these operating systems.

- **Compact and Portable Design:** Measuring 2.17*2.68*0.59 inches (L*W*H) with a 1.7 ft cable, it is easy to carry and designed to avoid blocking adjacent USB ports.



Image: The compact UGREEN card reader being placed into a backpack, illustrating its portability for users on the go.

3. Compatibility

Supported Memory Card Types:

- SD Card: SD, SDXC, SDHC, RS-MMC, MMC Micro
- TF Card: Micro SD, Micro SDXC, Micro SDHC
- MS Card: MS PRO, MS PRO-HG, MS XC DUO
- CF Card: Compact Flash, Toshiba, Transcend



Image: A visual diagram illustrating the different types of SD, TF, MS, and CF cards compatible with the UGREEN 4-in-1 card reader.

Supported Operating Systems:

- Windows (Windows 10 and earlier)
- Mac OS
- Linux
- Chrome OS

4. Setup Guide

The UGREEN USB 3.0 Card Reader is designed for simple plug-and-play operation, requiring no additional drivers for most operating systems.

1. **Connect the Card Reader:** Insert the USB 3.0 connector of the card reader into an available USB 3.0 port on your computer (desktop, laptop, etc.). For optimal performance, use a USB 3.0 port.
2. **Insert Memory Card:** Carefully insert your desired memory card into the corresponding slot on the card reader. Ensure the card is inserted correctly according to the slot's orientation.
3. **Access Data:** Your computer should automatically detect the card reader and the inserted memory card. You can then access the card's contents through 'My Computer' (Windows) or 'Finder' (Mac OS).

5. Operating Instructions

Once connected, the UGREEN USB 3.0 Card Reader functions like any standard drive connected to your computer. You can perform the following operations:

- **Reading Files:** Open the detected drive (e.g., 'Removable Disk' or the card's name) to view and copy files from the memory card to your computer.
- **Writing Files:** Drag and drop files from your computer to the detected drive to transfer them onto the memory card.
- **Simultaneous Access:** You can insert multiple compatible memory cards into their respective slots and access them all at the same time. Each inserted card will appear as a separate drive.
- **Safe Removal:** Always safely eject the memory card or the card reader from your operating system before physically disconnecting it to prevent data corruption.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the card reader. Avoid using liquid cleaners or solvents.
- **Storage:** Store the card reader in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the device or subjecting it to strong impacts. Do not force memory cards into slots.
- **Cable Care:** Do not bend or crimp the USB cable excessively to prevent internal damage.

7. Troubleshooting

Card Reader Not Detected:

- Ensure the USB connector is fully inserted into a working USB port.
- Try connecting to a different USB port on your computer.
- If using a USB hub, try connecting the card reader directly to the computer.
- Restart your computer.

Slow Data Transfer Speed:

- Ensure you are connected to a USB 3.0 port (usually blue inside). USB 2.0 ports will operate at slower speeds.

- Verify that your memory card supports high-speed transfer (e.g., UHS-I for SD cards).
- Close any unnecessary applications running in the background that might be consuming system resources.

Memory Card Not Recognized:

- Ensure the memory card is inserted correctly and fully into its designated slot.
- Try a different memory card to determine if the issue is with the card or the reader.
- Check if the memory card is locked (some SD cards have a small lock switch).
- Format the memory card (**Note:** This will erase all data on the card. Back up important files first).

8. Specifications

Attribute	Detail
Brand	UGREEN
Model Number	30333
Connectivity Technology	USB 3.0
Data Transfer Rate	Up to 5Gbps
Media Type Supported	SD Card, microSD, CompactFlash, Memory Stick
Max Capacity Supported	2TB
Operating System	Windows, MacOS, Linux, ChromeOS
Hardware Platform	PC, Mac
Color	Black
Item Weight	2.82 ounces
Product Dimensions	0.39 x 0.39 x 0.39 inches

9. What's in the Box

- 1 x UGREEN USB 3.0 SD/TF Card Reader

10. Warranty and Support

UGREEN products are designed for reliability and performance. For specific warranty information and technical support, please refer to the official UGREEN website or contact their customer service directly. Keep your purchase receipt for

warranty claims.

For further assistance, visit the UGREEN Store on Amazon.

© 2025 UGREEN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question