Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Catnapper Preston

Catnapper Preston Power Lift Recliner User Manual

Model: Preston

1. Important Safety Instructions

Please read all instructions carefully before assembling and operating your Catnapper Preston Power Lift Recliner. Retain this manual for future reference.

- **Electrical Safety:** Ensure the power cord is not pinched or damaged. Do not operate the recliner with a damaged cord or plug. Connect to a properly grounded outlet.
- **Weight Limit:** The maximum weight capacity for this recliner is 350 pounds (158 kg). Exceeding this limit may cause damage to the recliner and could result in injury.
- **Child and Pet Safety:** Keep children and pets away from the moving parts of the recliner, especially during operation. Do not allow children to play on or with the recliner.
- **Clearance:** Ensure adequate space around the recliner for full reclining and lifting motion. Avoid placing objects behind or under the recliner that could obstruct its movement.
- **Stability:** Do not stand on the footrest or armrests. Always sit properly in the recliner.
- **Liquid Exposure:** Avoid spilling liquids on the recliner, especially near electrical components.

2. Package Contents

Verify that all components are present before beginning assembly:

- Recliner Base (1)
- Backrest (1)
- Power Cord (1)
- Remote Control (1)

3. Setup and Assembly

Follow these steps to assemble your recliner:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place the recliner base on a soft, clean surface to prevent damage.
2. **Attach Backrest:** Align the metal receivers on the backrest with the posts on the recliner base. Slide the backrest down firmly until it locks into place. You should hear a click.
3. **Connect Power:** Locate the power cord connection point at the rear of the recliner base. Plug the power cord into the recliner, then plug the other end into a standard 120V AC wall outlet.
4. **Connect Remote Control:** Plug the remote control cable into the designated port on the side or back of the recliner.
5. **Test Functionality:** Before use, test all functions (lift, recline) using the remote control to ensure proper operation.

4. Operating Instructions

Your Catnapper Preston Power Lift Recliner is designed for ease of use with a simple remote control.

Using the Remote Control

The remote control typically features two main buttons or a directional pad:

- **Lift Function:** Press and hold the 'UP' or 'LIFT' button to gently raise the recliner to an assisting standing position. Release the button to stop at your desired height.
- **Recline Function:** Press and hold the 'DOWN' or 'RECLINE' button to smoothly recline the chair to various positions, including a full lay-flat position. Release the button to stop at your desired angle.
- **Return to Upright:** To return to the standard seated position, press and hold the 'DOWN' or 'RECLINE' button until the chair is fully upright.

Note: Always ensure the area around the recliner is clear before operating to prevent obstruction or injury.

5. Maintenance

Proper care will extend the life and appearance of your recliner.

Cleaning the Fabric

- **Regular Cleaning:** Vacuum the fabric regularly using a soft brush attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub. For stubborn stains, use a mild, water-free solvent or dry-cleaning product. Always test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use harsh detergents, bleach, or abrasive cleaners, as these can damage the fabric.

Electrical and Mechanical Care

- **Power Cord:** Periodically inspect the power cord for any signs of wear or damage. If damaged, discontinue use and contact customer support.
- **Moving Parts:** The mechanical components are designed to be maintenance-free. Do not attempt to lubricate or disassemble them.
- **General Inspection:** Periodically check all connections and fasteners to ensure they are secure.

6. Troubleshooting

If you encounter issues with your recliner, refer to the following common problems and solutions:

- **Recliner Not Operating:**
  - Ensure the power cord is securely plugged into both the recliner and the wall outlet.
  - Check if the wall outlet is functional by plugging in another appliance.
  - Verify the remote control cable is firmly connected to the recliner.
- **Recliner Stops Mid-Movement:**
  - Release the remote button and press it again.
  - Check for any obstructions under or behind the recliner.
- **Unusual Noises:**
  - Minor noises during initial use are normal.
  - If noises persist or become louder, ensure all assembly connections are tight.

If these steps do not resolve the issue, please contact Catnapper customer support.

7. Specifications

Detailed specifications for the Catnapper Preston Power Lift Recliner:

Feature	Detail
Brand	Catnapper
Model Name	Preston
Model Number	Catnapper Preston 4850214804
Color	Berry
Material Type	Textile (Polyester)
Product Dimensions (D x W x H)	35.04"D x 32.5"W x 40"H
Item Weight	131 pounds
Maximum Weight Recommendation	350 pounds
Seat Depth	20.5 inches
Arm Height	27.5 inches
Additional Features	Arm Rest, Power Lift Function, Pillowtop Seat, Full Lay Flat Recline



Image: Catnapper Preston Power Lift Recliner showing overall dimensions. The recliner measures approximately 46 inches in height, 39 inches in width, and 39 inches in depth.

8. Warranty and Support

For warranty information or technical assistance, please contact Catnapper customer support directly. Keep your purchase receipt and model number handy when contacting support.

Catnapper Customer Support: Refer to the official Catnapper website or your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01B1XL3MI

More documents and user manuals: **https://manuals.plus/**