Nettech NTR-001

Nettech NTR-001 Replacement Remote Control for Panasonic TVs

User Instruction Manual

Introduction

This manual provides detailed instructions for the Nettech NTR-001 Replacement Remote Control, designed for use with most Panasonic TV models. It covers setup, operation, and maintenance to ensure optimal performance. This remote is compatible with various Panasonic TV models, including TC46PGT24, TCP42G25, TCP46G25, TCP50G20, TCP50G25, N2QAYB000485, N2QAYB000100, N2QAYB000221, N2QAYB00048, and many others. Please note, this remote is not designed for Panasonic DVD players.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring correct polarity (+ and - terminals match the indicators inside the compartment).
4. Slide the battery compartment cover back into place until it clicks securely.

Initial Use

The Nettech NTR-001 remote control is designed to work immediately with most Panasonic TVs right out of the box after inserting the batteries. No additional programming is typically required for basic TV functions.

Operating Instructions

Familiarize yourself with the buttons and their functions:




INPUT
TV
AV
APPS
VIERA Link
VIERA TOOLS
GUIDE
HOME
EXIT
INTERNET
MENU
SD/USB
OK
OPTION
RETURN
CH
WAKEUP
FAV
OFF-TIMER
CC
I/II
1
2
3
4
5
6
7
8
9
0
LAST
ASPECT
i
N.
3D



Figure 1: Front view of the Nettech NTR-001 remote control.

- **Power Button (●)**: Turns the TV on or off.
- **INPUT** / **TV** / **AV**: Selects the input source (e.g., HDMI 1, AV, TV).
- **APPS** / **HOME** / **INTERNET** / **MENU** / **OPTION** / **GUIDE** / **EXIT**: Accesses various smart TV features, menus, and navigation options.
- **Directional Pad (Up, Down, Left, Right) & OK Button**: Navigates through menus and confirms selections.
- **RETURN**: Goes back to the previous screen or menu.
- **Volume Up/Down (+/-)**: Adjusts the TV volume.
- **Channel Up/Down (CH ▲/▼)**: Changes TV channels.
- **Number Pad (0-9)**: Directly enters channel numbers.
- **LAST**: Returns to the previously viewed channel.
- **Playback Controls (Rewind, Play/Pause, Fast Forward)**: Controls media playback.
- **3D**: Activates or deactivates 3D mode on compatible TVs.
- **VIERA Link**: Accesses Panasonic's VIERA Link functions for connected devices.
- **WAKEUP** / **CC** / **FAV** / **OFF-TIMER** / **CD/V** / **I/II**: Provides access to specific functions like Closed Captioning, Favorite channels, Off-timer, and other specialized controls.
- **LCD LED** / **LEARN**: These buttons may offer advanced functions or learning capabilities for specific TV models. Refer to your TV's manual for details on 'LEARN' functionality if applicable.

Features

- **Broad Compatibility**: Designed for most Panasonic TV models, including Viera Link, HDTV, 3D, LCD, and LED TVs.
- **Instant Operation**: Works immediately out of the box with most Panasonic TVs after battery insertion.
- **Convenient Hotkeys**: Includes dedicated buttons for 3D, VIERA Link, and customizable options for quick access to popular Panasonic Smart TV functions.

Product Overview





The front of the remote control, displaying all primary function buttons and navigation pad.



An angled perspective of the remote, highlighting its ergonomic design and button layout.





The rear side of the remote, showing the battery compartment cover.



A different angled view, providing a comprehensive look at the remote's profile.

Troubleshooting

Remote Not Responding

- **Check Batteries**: Ensure fresh AAA batteries are inserted with correct polarity.
- **Line of Sight**: Make sure there is a clear line of sight between the remote and the TV's infrared sensor. Obstructions can block the signal.
- **Remote Reset**: Remove batteries, press all buttons a few times to discharge any residual power, then reinsert batteries.
- **TV Sensor**: Verify that the TV's infrared sensor is not blocked or dirty.

Specifications

Brand	Nettech
Model Number	NTR-001
Product Dimensions	3 x 3 x 3 inches
Item Weight	3.04 ounces
Compatible Devices	Television
Special Feature	No Programming Required
Color	Black

Warranty and Support

Nettech provides a 1-year warranty for this replacement remote control. If you encounter any issues or are not satisfied with your purchase, please refer to the seller's contact information for support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question