Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

acer Mouse

Acer Wireless Optical Mouse Charcoal User Manual

Model: Mouse (B01B64O67Q)

Product Overview

The Acer Wireless Optical Mouse (Model: Mouse) is designed for comfortable and efficient navigation. It utilizes 2.4GHz wireless technology, providing a reliable connection with an operating range of over 32.8 feet (10 meters) in an interference-free environment. Its ergonomic design ensures comfortable use for both left and right-handed users.



Image: Top-down view of the Acer Wireless Optical Mouse, showcasing its charcoal color and ergonomic shape.

Package Contents

- Acer Wireless Optical Mouse
- USB Receiver (typically stored inside the mouse or battery compartment)
- 1 AA Battery (included)

Setup Guide

1. Installing the Battery

1. Locate the battery compartment on the underside of the mouse.
2. Slide open the battery compartment cover.
3. Insert the included AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.



Image: Side view of the Acer Wireless Optical Mouse, illustrating its ergonomic design.

2. Connecting the USB Receiver

1. The USB receiver is typically stored inside the mouse, often within the battery compartment, for safe keeping during transport. Carefully remove it.
2. Plug the USB receiver into an available USB port on your computer (desktop, laptop, etc.).

3. Your computer should automatically detect and install the necessary drivers. This process may take a few moments.

3. Powering On the Mouse

Locate the power switch on the underside of the mouse. Slide it to the "ON" position. The mouse is now ready for use.

Operating Instructions

Basic Functions

- **Left Button:** Primary click function, used for selecting items, opening files, etc.
- **Right Button:** Secondary click function, typically opens context menus.
- **Scroll Wheel:** Scroll up or down through documents and web pages. The scroll wheel can also be pressed for a middle-click function, depending on software configuration.

Wireless Range

The mouse operates effectively within a range of up to 32.8 feet (10 meters) from the USB receiver. Performance may vary depending on environmental factors and obstacles.



Image: Angled view of the Acer Wireless Optical Mouse, showcasing its ergonomic contours and charcoal finish.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.
- **Battery Replacement:** When the mouse performance degrades or it stops responding, replace the AA battery. Follow the battery installation steps outlined in the Setup Guide.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. For transport, store the USB receiver inside the mouse's battery compartment.

Troubleshooting

Problem	Solution
Mouse not responding	Ensure the mouse is turned ON. Check if the battery is correctly installed and has sufficient charge. Replace if necessary. Ensure the USB receiver is securely plugged into a working USB port on your computer. Try a different USB port. Move the mouse closer to the USB receiver to rule out range issues.
Erratic cursor movement	Clean the optical sensor on the underside of the mouse. Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). Check for potential wireless interference from other 2.4GHz devices.
Connection drops frequently	Reduce the distance between the mouse and the USB receiver. Avoid placing the receiver near large metal objects or other electronic devices that may cause interference. Replace the battery.

Specifications

- **Model:** Mouse (ASIN: B01B64O67Q)
- **Connectivity:** 2.4 GHz Wireless Technology
- **Wireless Type:** 2.4 GHz Radio Frequency, 802.11a/b/g/n
- **Operating Range:** > 32.8 feet (10 meters)
- **Movement Detection:** Optical
- **Power Source:** Battery Powered
- **Battery Type:** 1 x AA battery (included)
- **Average Battery Life:** Approximately 12 months
- **Dimensions (LxWxH):** 3.9 x 2.6 x 1.1 inches (9.9 x 6.6 x 2.8 cm)
- **Weight:** 1.28 ounces (36.3 grams)
- **Color:** Charcoal
- **Manufacturer:** Acer Computer

Warranty Information

For detailed warranty information, please refer to the warranty card included with your product or visit the official Acer support website. Keep your proof of purchase for warranty claims.

Support

For further assistance, technical support, or to download the latest drivers (if applicable), please visit the official Acer support website:

www.acer.com/support

You may also contact Acer customer service through the contact information provided on their website.

© 2024 Acer Inc. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01B64O67Q

More documents and user manuals: **https://manuals.plus/**