RYOBI R18MT-0

Ryobi ONE+ R18MT-0 18V Cordless Multi Tool Instruction Manual

Model: R18MT-0 | Brand: RYOBI

1. Introduction

The Ryobi ONE+ R18MT-0 18V Cordless Multi Tool is a versatile power tool designed for a wide range of applications in home and garden projects. Its compact and ergonomic design allows for efficient operation in various tasks, including cutting, sanding, and scraping. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your multi-tool.

2. Safety Information

WARNING: Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

- Always wear appropriate personal protective equipment (PPE), including safety glasses, gloves, and hearing protection.
- Ensure the work area is well-lit and free from obstructions.
- Keep children and bystanders away while operating the tool.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.
- Disconnect the battery pack before making any adjustments, changing accessories, or storing the tool.
- Use the correct accessory for the task.
- Maintain a firm grip on the tool during operation.
- Do not force the tool. Let the tool do the work at its intended speed.
- Store the tool in a secure, dry place out of reach of children.

3. Package Contents

Upon opening the package, verify that all items listed below are present and in good condition:

- 1 x Ryobi ONE+ R18MT-0 18V Cordless Multi Tool (Zero Tool)
- 1 x Plunge cutting blade
- 1 x Flush cutting blade
- 1 x Sanding pad
- 5 x Sanding sheets
- 1 x Universal accessory adaptor
- Instruction Manual

Note: This R18MT-0 is sold as a zero tool and does not include a battery or charger. It is compatible with all 18V ONE+ batteries and chargers from the Ryobi system.

4. Setup

4.1. Battery Installation

1. Ensure the multi-tool is turned off and the variable speed dial is set to '0'.
2. Align the battery pack with the battery port on the base of the tool.
3. Slide the battery pack into the tool until it clicks securely into place.
4. To remove the battery, press the release latches on the sides of the battery pack and pull it out.

This tool requires an 18V Lithium Ion battery (not included).



Figure 4.1: Ryobi ONE+ R18MT-0 Multi Tool with its various attachments, including a plunge cutting blade, sanding pad, and sanding sheets.

4.2. Accessory Attachment

The Ryobi R18MT-0 features a tool-less accessory change system for quick and easy switching between different

applications.

1. Ensure the tool is off and the battery is removed.
2. Locate the accessory clamp lever on the tool head.
3. Open the clamp lever.
4. Align the desired accessory (e.g., cutting blade, sanding pad) with the tool's spindle, ensuring the accessory fits securely onto the mounting pins.
5. Close the clamp lever firmly to secure the accessory.
6. Verify the accessory is properly seated and cannot be easily removed before operation.

5. Operating Instructions

5.1. Powering On/Off

1. To turn on the tool, press and hold the trigger switch located on the handle.
2. To turn off the tool, release the trigger switch.
3. The tool also features a lock-on switch to reduce fatigue during extended use. Engage the lock-on switch after pressing the trigger, and press the trigger again to release it.

5.2. Variable Speed Control

The multi-tool is equipped with a 6-position variable speed dial for ultimate control across a range of applications.

1. Rotate the variable speed dial (located near the tool head) to select the desired speed setting. Lower numbers indicate slower speeds, while higher numbers indicate faster speeds.
2. Adjust the speed according to the material and the specific task to achieve optimal results and prevent damage to the workpiece or accessory.

5.3. LED Work Light

An integrated LED light illuminates the work area, providing improved visibility, especially in dimly lit conditions.

- The LED light automatically activates when the tool is powered on.
- Position the tool to ensure the light effectively illuminates your working surface.

5.4. General Applications

The Ryobi R18MT-0 is suitable for various tasks:

- **Cutting:** Use appropriate cutting blades for materials like drywall, metal, wood, plastic, and composites. The 4-position articulating head allows for plunge cuts and flush cuts in hard-to-reach areas.
- **Sanding:** Attach the sanding pad and sanding sheets for detailed sanding tasks.
- **Scraping:** Utilize a scraping accessory for removing old paint, adhesive, or other materials.



Figure 5.1: Sanding wood with the multi-tool.



Figure 5.2: Detailed sanding on furniture.



Figure 5.3: Scraping old material from a surface.



Figure 5.4: Cutting a pipe with the multi-tool.



Figure 5.5: Making precise cuts in drywall.

6. Maintenance

- **Cleaning:** Regularly clean the tool's ventilation openings to prevent overheating. Use a soft, damp cloth and mild soap. Do not use solvents.
- **Accessory Inspection:** Inspect accessories (blades, sanding sheets) before each use for wear or damage. Replace worn or damaged accessories immediately.
- **Lubrication:** The tool's internal components are factory-lubricated and do not require additional lubrication.
- **Storage:** Store the tool and accessories in a dry, secure location, away from direct sunlight and extreme temperatures. Remove the battery pack before storage.

7. Troubleshooting

Problem	Possible Cause	Solution
Tool does not start	Battery not installed correctly; Battery discharged; Tool malfunction	Ensure battery is fully seated; Charge battery; Contact customer support
Reduced performance	Worn or dull accessory; Incorrect speed setting; Overheating	Replace accessory; Adjust speed dial; Allow tool to cool down
Excessive vibration	Accessory not properly secured; Damaged accessory	Re-secure accessory; Replace damaged accessory

8. Specifications

Feature	Detail
Brand	RYOBI
Model Number	R18MT-0
Voltage	18 Volts
Power Source	DC (Cordless)
Recommended Uses	Cutting, Sanding
Color	Hyper Green
Included Components	1 x Multi-tool; 6 x accessories (Plunge cutting blade, flush cutting blade, sanding pad, 5 sanding sheets, universal accessory adaptor)
Item Weight	1 Kilogram (2.2 pounds)
Maximum Rotational Speed	20000 RPM
Dimensions (L x W x H)	13.39 x 59.06 x 37.4 inches
Material	Wood and metal (for cutting applications)

9. Warranty and Support

Ryobi offers a **3-year warranty** on their battery-powered or electric tools, excluding accessories and components subject to natural and normal wear and tear. Registration is required for extension from 2 to 3 years for battery-powered and electric tools.
For complete warranty conditions and customer support, please refer to the official Ryobi website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 RYOBI. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question