Nine West NW1892SVRG

Nine West NW1892SVRG Analog Women's Watch User Manual

Model: NW1892SVRG | Brand: Nine West

Introduction

Welcome to your Nine West NW1892SVRG Analog Women's Watch. This manual provides essential information for the proper setup, operation, maintenance, and troubleshooting of your new timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

Product Overview

The Nine West NW1892SVRG is an elegant analog watch designed for women, featuring a classic round dial and a durable metal bracelet. It is powered by a precise Japanese Quartz movement, ensuring accurate timekeeping.





Image: Front view of the Nine West NW1892SVRG Analog Women's Watch, showcasing its silver-tone case, silver dial, and metal bracelet.

Key Features:

- Analog Display
- 36mm Case Diameter
- Round Case Shape
- Japanese Quartz Movement
- Metal Bracelet with Double Push-Button Fold-Over Clasp
- Mineral Crystal

Setup

1. Setting the Time

1. Gently pull the crown (the small knob on the side of the watch case) outwards to the time-setting position.
2. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. Once the time is set, push the crown back into its original position against the watch case.

2. Adjusting the Bracelet

The metal bracelet of your Nine West watch may require adjustment to fit your wrist comfortably. For precise and safe adjustment, it is recommended to take your watch to a qualified jeweler or watch repair professional. They can add or remove links as needed without damaging the bracelet or clasp mechanism.



Image: The Nine West NW1892SVRG watch displayed on a wrist, illustrating how it appears when worn.

3. Battery Information

Your watch comes with one product-specific battery already installed. The Japanese Quartz movement is powered by this battery. If the watch stops running, the battery may need replacement.

Operating

Your Nine West NW1892SVRG watch is designed for simple and reliable timekeeping. Once the time is set as described in the 'Setup' section, the watch will continuously display the current time.

- **Time Display:** The watch features an analog display with hour, minute, and second hands.
- **Accuracy:** The Japanese Quartz movement provides accurate timekeeping.

Maintenance

1. Cleaning Your Watch

To maintain the appearance of your watch, wipe the case and bracelet regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

2. Water Resistance

This watch is not specified as water-resistant. To prevent damage, avoid exposing your watch to water, moisture, or extreme humidity. Remove the watch before showering, swimming, or engaging in water-related activities.

3. Battery Replacement

When the watch battery runs out, it is recommended to have it replaced by a professional watch technician. This ensures the correct battery type is used and the watch case is properly sealed to prevent dust or moisture intrusion.

4. Storage

When not wearing your watch, store it in a dry, safe place, preferably in its original box or a watch case, to protect it from dust and scratches.





Image: The Nine West watch box, suitable for storage and protection of the timepiece.

Troubleshooting

If you encounter any issues with your Nine West watch, please refer to the following common troubleshooting steps:

- **Watch Not Running:**
  - Ensure the crown is fully pushed in against the watch case.
  - The battery may be depleted. Consider professional battery replacement.
- **Incorrect Time:**
  - Reset the time as described in the 'Setting the Time' section.
- **Bracelet Discomfort:**
  - If the bracelet is too tight or too loose, seek professional adjustment.

For issues not resolved by these steps, please contact customer support.

Specifications

Feature	Detail
Brand	Nine West
Model Number	NW/1893SVRT
ASIN	B01BHQN4VC
UPC	086702581474
Department	Women's
Display Type	Analog
Watch Movement Type	Japanese Quartz
Power Source Type	Battery (1 product-specific battery included)
Case Material	Stainless Steel
Case Diameter	36 Millimeters
Case Thickness	8 Millimeters

Feature	Detail
Case Shape	Round
Crystal Material	Mineral
Band Material	Metal
Band Width	16 Millimeters
Band Color	Silver
Dial Color	Silver
Clasp Type	Double Push-Button Fold-Over Clasp
Embellishment Feature	Crystal
Package Dimensions	9.91 x 7.87 x 7.62 cm; 113.4 g
Manufacturer	Nine West

Warranty Information

This product comes with a warranty type specified as "amazon.com". For detailed information regarding the warranty period, coverage, and claims process, please refer to the specific warranty terms provided at the time of purchase or visit the amazon.com website for further details.

Support

If you require further assistance or have questions not covered in this manual, please contact Nine West customer support or the retailer from whom you purchased the watch. When contacting support, please have your watch model number (NW1892SVRG or NW/1893SVRT) and proof of purchase readily available.

© 2026 Nine West. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question