Ozark Trail TA-447

Ozark Trail Deluxe Portable Grilling Camp Table Instruction Manual

Introduction

Thank you for choosing the Ozark Trail Deluxe Portable Grilling Camp Table. This versatile and durable camp kitchen stand is designed to enhance your outdoor cooking experience, providing a stable work area for food preparation and grilling. Its portable design allows for easy setup and compact storage, making it an ideal companion for camping, picnics, and other outdoor adventures.

Important Safety Information

- **Stability Check:** Always ensure the table is fully unfolded and stable on a level surface before use. Do not use if any parts are damaged or missing.
- **Pinch Points:** Keep fingers and other body parts away from hinges and moving parts during setup and folding to prevent injury.
- **Lifting:** Always lift with care, as the table can be heavy (approximately 26 pounds). Use proper lifting techniques.
- **Securing:** For enhanced stability, especially in windy conditions, consider securing the table to a heavy object or the ground when in use.
- **Supervision:** Do not leave the table unattended while in use, especially with hot cooking equipment.
- **Heat Resistance:** The main aluminum slat top is designed for camp stoves or portable grills. Ensure heat sources are placed centrally and do not exceed the table's capacity.

Package Contents

Please verify that all components are present before assembly:

- Main Folding Frame with Aluminum Slat Top
- Two (2) Side Tables (easy-to-clean tabletop material)
- One (1) Wire Shelf
- One (1) Paper Towel Rack

- Set of Utensil Hooks
- Carrying Bag (for storage and transport)

Setup Instructions

1. **Unpack:** Remove the camp table from its carrying bag and place it on a flat, stable surface.
2. **Unfold Main Frame:** Gently pull the main frame apart. The legs should extend and lock into place. Ensure all four legs are fully extended and stable.
3. **Attach Side Tables:** Locate the attachment points on either side of the main aluminum slat top. Slide and secure the two side tables into their designated slots. Ensure they are firmly attached.
4. **Install Wire Shelf:** Position the wire shelf underneath the main table frame. Hook or clip it into the designated supports on the legs or frame. This provides additional storage.
5. **Attach Accessories:**
    - **Paper Towel Rack:** Attach the paper towel rack to the designated side of the table. Insert a standard paper towel roll.
    - **Utensil Hooks:** Attach the utensil hooks to the opposite side of the table. These are for hanging grilling and cooking tools.
6. **Final Check:** Before placing any items on the table, gently shake it to confirm stability. Ensure all connections are secure.

(Image: Diagram showing the table unfolding and components being attached. Alt text: Step-by-step assembly diagram of the Ozark Trail Deluxe Portable Grilling Camp Table.)

Operating Instructions

The Ozark Trail Deluxe Portable Grilling Camp Table is designed for versatile outdoor cooking and food preparation.

Using the Main Tabletop:

- The central aluminum slat top is suitable for placing camp stoves, portable grills, or other cooking appliances. Ensure the appliance fits within the dimensions of the slat top and does not exceed the table's weight capacity.
- Always follow the safety instructions provided with your cooking appliance.

Using the Side Tables:

- The two side tables provide convenient surfaces for food preparation, holding ingredients, condiments, plates, and utensils.
- Avoid placing excessively hot items directly on the side tables, as they may not be as heat-resistant as the central aluminum slat.

Using the Wire Shelf:

- The bottom wire shelf is ideal for storing pots, pans, dishes, or other accessories, keeping them within easy reach and off the ground.

Using Accessories:

- The paper towel rack keeps paper towels readily accessible for spills and cleaning.
- The utensil hooks allow you to hang grilling tools, keeping your workspace organized.

Maintenance and Care

Proper care will extend the life of your camp table.

- **Cleaning:** Wipe down all surfaces with a damp cloth and mild soap after each use. For stubborn stains, a non-abrasive cleaner can be used. Rinse thoroughly and dry completely before storage.
- **Corrosion Prevention:** The steel frame is designed to be corrosion-resistant, but prolonged exposure to moisture can still cause issues. Ensure the table is dry before folding and storing.
- **Inspection:** Periodically inspect all parts for wear, damage, or loose connections. Tighten any loose fasteners. Replace damaged parts if necessary.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or bleach, as these can damage the finish and materials.

Storage

To fold and store your camp table:

1. **Remove Accessories:** Detach the paper towel rack and utensil hooks.
2. **Remove Wire Shelf:** Unhook and remove the bottom wire shelf.
3. **Remove Side Tables:** Carefully slide the side tables out of their attachment points.
4. **Fold Main Frame:** Release any locking mechanisms on the main frame and gently push the legs inward until the table folds flat.
5. **Pack:** Place all components, including the folded table, side tables, wire shelf, and accessories, into the provided carrying bag.
6. **Store:** Store the packed table in a cool, dry place, away from direct sunlight and extreme temperatures.

(Image: Photo of the Ozark Trail Deluxe Portable Grilling Camp Table folded and packed in its carrying bag. Alt text: The camp table folded flat and stored in its carrying bag.)

Troubleshooting

Table is wobbly after setup:

- Ensure all legs are fully extended and locked into place.
- Verify that the table is on a level surface. Adjust leg positions if necessary.
- Check for any loose connections on the frame or side tables.

Side tables are not attaching securely:

- Ensure the side tables are aligned correctly with the attachment points and fully slid into place.
- Inspect attachment points for any obstructions or damage.

Difficulty folding the table:

- Ensure all accessories, side tables, and the wire shelf have been removed.
- Check that any locking mechanisms on the frame are disengaged before attempting to fold.

Specifications

Feature	Detail
Model Name	Trail Deluxe (TA-447)
Brand	Ozark Trail
Product Dimensions (Unfolded)	56.7"W x 16.1"D x 32.1"H
Item Weight	26 Pounds
Material	Alloy Steel (Frame), Aluminum (Main Slat Top)
Color	White (Side Tables), Silver (Main Top)
Special Feature	Portable, Folding Design, Integrated Accessories
Included Components	Side Tables, Wire Shelf, Paper Towel Rack, Utensil Hooks
Indoor/Outdoor Usage	Outdoor
UPC	744745164473

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Ozark Trail customer service directly. Keep your purchase receipt for warranty claims.
For further assistance, visit the official Ozark Trail website or contact their customer support line.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question