Disney Princess B8311

Disney Princess B8311 Royal Dreams Castle

INSTRUCTION MANUAL

Introduction

Welcome to the magical world of the Disney Princess Royal Dreams Castle! This playset is designed to provide hours of imaginative play for children aged 3 and up. Standing over 1 meter tall, this multi-level castle features various themed rooms inspired by beloved Disney Princesses, complete with furniture and accessories. Please read this manual carefully before assembly and play to ensure proper use and enjoyment of your new castle.



Image: The fully assembled Disney Princess Royal Dreams Castle. This grand playset features multiple levels, turrets, and detailed interior rooms, ready for imaginative play with Disney Princess dolls.

Safety Information

No specific safety warnings are applicable beyond general toy safety guidelines. This product is intended for children aged 3 years and older. Adult supervision is recommended during assembly and initial play. Keep small parts away from younger children to prevent choking hazards.

Package Contents

Before beginning assembly, please ensure all components are present. The package typically includes:

- Main castle structure pieces
- Over 15 accessories, including furniture scaled for Disney Princess dolls
- Decorative stickers (if applicable)

- Instruction sheet



Image: The product packaging for the Disney Princess Royal Dreams Castle. It highlights the castle's impressive height and includes a visual of a child engaging with the playset, along with key features.

Assembly Instructions

Assembly of the Royal Dreams Castle is straightforward but may require adult assistance. Follow these general steps:

1. **Unpack Components:** Carefully remove all pieces from the packaging. Lay them out and identify each part using the included diagram (if any).
2. **Assemble Base Structure:** Connect the main floor panels and vertical supports. Ensure all connections click securely into place.
3. **Build Upper Levels:** Attach the second and third floor sections, aligning them with the designated slots on the lower structure.
4. **Install Turrets and Roof:** Secure the decorative turrets and roof pieces to the top of the castle.
5. **Add Features:** Install the magic carpet elevator, doors, and any other structural elements.
6. **Place Furniture and Accessories:** Arrange the included furniture (bed, vanity, bathtub, kitchen items) in their respective rooms.
7. **Apply Stickers:** Carefully apply any decorative stickers to enhance the castle's appearance, following the placement guide.



Image: A child demonstrates the magic carpet elevator feature, which allows dolls to move between the castle's levels.

Features and Play

The Royal Dreams Castle offers a variety of interactive features and themed areas for endless storytelling:

- **Multi-Level Design:** Explore three stories of royal living, including a bedroom, bathroom, kitchen, and living areas.
- **Themed Rooms:** Discover rooms inspired by different Disney Princesses, such as Ariel's bathroom with a seashell tub, Belle's library/living room, and a bedroom for Aurora.
- **Magic Carpet Elevator:** Use the manual elevator, designed as Jasmine's magic carpet, to transport dolls between floors.
- **Interactive Accessories:** Engage with over 15 accessories, including a bed, vanity, bathtub, kitchen appliances, and more, all scaled for Disney Princess fashion dolls.



Image: A child plays with a Snow White doll in the castle's kitchen, complete with miniature oven and teapot.



Image: An Aurora doll rests in the castle's bedroom, featuring a bed with a canopy and a vanity table.



Image: An Ariel doll is positioned near the castle's bathroom, which includes a distinctive seashell-shaped bathtub.

Care and Maintenance

To keep your Royal Dreams Castle in excellent condition:

- **Cleaning:** Wipe the castle and accessories with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the castle in a dry, cool place away from direct sunlight to prevent fading or damage to plastic components.
- **Inspection:** Periodically check for any loose or damaged parts. Replace or repair as necessary.

Troubleshooting

Problem	Solution
Parts do not fit together or are loose.	Ensure you are using the correct parts for each step. Apply gentle, firm pressure until parts click into place. If a part remains loose, check for any obstructions or manufacturing defects.
Decorative stickers do not adhere well.	Ensure the surface is clean and dry before applying stickers. Press firmly to remove air bubbles. If stickers peel, a small amount of non-toxic, child-safe adhesive can be used.
Magic carpet elevator is stuck.	Check for any dolls or accessories obstructing the elevator's path. Ensure the mechanism is clean and free of debris.

Product Specifications

Feature	Detail
Brand	Disney Princess

Feature	Detail
Model Number	B8311
Material	Plastic
Assembled Dimensions	Over 1 meter (3.3 feet) tall
Package Dimensions	19.1 x 68.6 x 39.4 cm (7.5 x 27 x 15.5 inches)
Item Weight	4.16 Kilograms (9.17 lbs)
Color	Varied
Theme	Disney Princesses
Age Range	3 to 99 years
Manufacturer	Hasbro

Warranty and Support

For information regarding product warranty or customer support, please refer to the contact details provided on the product packaging or visit the official Hasbro website. Keep your proof of purchase for any warranty claims.

© 2026 Disney Princess. All rights reserved. Hasbro.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question