Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

QC5550 QC5570 QC5580 QC5550 QC5570 QC5580

Philips Shaver Replacement Head Parts User Manual

Models: QC5550, QC5570, QC5580

1. Introduction

This manual provides instructions for the installation, operation, and maintenance of your new replacement cutter blades and foil screen for Philips shavers. These parts are compatible with Philips models QC5550, QC5570, and QC5580. Regular replacement of these components ensures optimal shaving performance and comfort.

2. Package Contents

Your package should contain the following items:

- 2x Cutter Blades
- 1x Foil Shaver Screen



Image 1: Foil Shaver Screen. This image displays the metallic foil screen component, featuring a textured surface with numerous small perforations designed to capture hairs for cutting.



Image 2: Cutter Blades. This image shows two individual cutter blades, each with a series of sharp teeth designed to move beneath the foil screen to cut hair.

3. Installation (Setup)

Follow these steps to safely replace the cutter blades and foil screen on your Philips shaver:

1. **Power Off and Unplug:** Ensure your shaver is turned off and unplugged from any power source before beginning the replacement process.

2. **Remove Old Components:**
    - Gently press the release buttons (if present) or pull the shaving head assembly upwards to detach it from the shaver body.
    - Carefully remove the old foil screen and cutter blades. Dispose of them responsibly.
3. **Clean the Shaver:** Use a small brush to remove any hair clippings or debris from the shaver head area.
4. **Install New Cutter Blades:**
    - Place the new cutter blades onto the oscillating drive shafts of the shaver. Ensure they are seated correctly and securely.
    - *Note:* Some models may have small springs associated with the blades. Ensure these are correctly positioned if your model requires them.
5. **Install New Foil Screen:**
    - Align the new foil screen with the shaver head assembly.
    - Gently press down until it clicks into place, ensuring it is securely fastened. Do not force it.
6. **Reattach Shaving Head:** Reattach the complete shaving head assembly to the shaver body, ensuring it locks securely.



Image 3: Assembled Shaver Head Parts. This image shows the foil screen and cutter blades correctly installed together, ready for attachment to the shaver body.

4. Operating Your Shaver with New Parts

After installing the new replacement parts, your Philips shaver is ready for use. For optimal performance:

- Ensure your skin is clean and dry before shaving.
- Move the shaver in small, circular motions against the direction of hair growth.
- Apply gentle pressure; excessive force is not necessary and can cause skin irritation or damage to the blades.
- Allow the shaver to run for a few seconds before making contact with your skin to ensure the blades are at full

speed.

5. Maintenance

Proper maintenance extends the life of your replacement parts and ensures consistent performance:

- **Daily Cleaning:** After each use, turn off and unplug the shaver. Remove the shaving head and tap out any loose hair clippings. You may rinse the foil screen and cutter blades under warm running water if your shaver model is waterproof. Allow parts to air dry completely before reassembling.
- **Deep Cleaning:** Periodically, perform a more thorough cleaning. Refer to your original shaver manual for specific deep cleaning instructions.
- **Lubrication:** Some shaver models benefit from a drop of lubricating oil on the cutter blades after cleaning. Consult your shaver's original manual.
- **Replacement Schedule:** For best results, it is recommended to replace the cutter blades and foil screen every 12-18 months, or sooner if you notice reduced performance, discomfort, or visible wear.

6. Troubleshooting

If you encounter issues after installing your new replacement parts, consider the following:

- **Poor Shaving Performance / Pulling Hairs:**
  - Ensure the cutter blades are correctly seated and the foil screen is securely attached.
  - Check for any debris or hair trapped between the blades and foil.
  - Confirm that the replacement parts are compatible with your specific Philips shaver model (QC5550, QC5570, QC5580).
- **Parts Not Fitting Securely:**
  - Double-check that you have the correct replacement parts for your shaver model.
  - Inspect for any damage to the shaver's head assembly or the new replacement parts.
  - Ensure all components are aligned correctly before applying pressure to snap them into place.
- **Blades Detaching / Springs Missing:**
  - Some shaver models utilize small springs to hold the blades in place. Ensure these are present and correctly positioned during installation.
  - If blades repeatedly detach, inspect the shaver's internal mechanism for wear or damage.

If problems persist, contact customer support for further assistance.

7. Specifications

Feature	Detail
Compatible Models	Philips QC5550, QC5570, QC5580
Blade Material	Stainless Steel
Head Type	Foil
Number of Blades	2 (per set)

Package Dimensions	5.16 x 4.21 x 0.71 inches
Package Weight	0.56 ounces

8. Warranty and Support

This product comes with a **30-day refund policy** and a **3-month replacement satisfaction guarantee warranty** from the date of purchase. If you encounter any issues or have questions regarding your replacement parts, please do not hesitate to contact customer support.
Our customer service team is available to assist you with any problems or concerns you may have. Please refer to your purchase documentation for specific contact information.

© 2023 Philips Replacement Parts. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01CNKZXWY

More documents and user manuals: **https://manuals.plus/**