## DOSS SoundBox

# DOSS SoundBox Touch Bluetooth Speaker User Manual

Model: SoundBox | Brand: DOSS

## Introduction

Thank you for choosing the DOSS SoundBox Touch Wireless Bluetooth Speaker. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your device. Please read it thoroughly to ensure optimal performance and longevity of your speaker.




Figure 1: DOSS SoundBox Touch Bluetooth Speaker. This image displays the speaker's sleek black design, highlighting its top-mounted touch controls and the front mesh grille.

## Key Features

- **Superior Sound Quality:** Equipped with dual high-performance drivers and enhanced bass for 12W full-bodied stereo sound.
- **Capacitive Touch Control:** Intuitive touch-sensitive controls for easy track changes, volume adjustment, and pairing.
- **IPX5 Water-resistant:** Designed to withstand gentle splashes of water, making it suitable for various environments.
- **Portable and Versatile:** Compact design for easy transport, ideal for indoor and outdoor use.
- **Extended Playtime:** Built-in rechargeable Li-Ion battery provides up to 20 hours of continuous playback at 50% volume.
- **Enhanced Wireless Connectivity:** Features Bluetooth 5.0 technology for stable and quick pairing with devices.
- **Hands-free Calling:** Integrated microphone allows for convenient hands-free phone calls.




Figure 2: Internal components of the DOSS SoundBox Touch, illustrating the dual full-range drivers and passive radiator responsible for its 12W superior sound output.




Figure 3: Demonstrating the sensitive touch controls on the speaker's top panel. The illuminated ring indicates active touch functionality for volume and playback.




Figure 4: The DOSS SoundBox Touch speaker positioned by a pool, showcasing its IPX5 water-resistant design, suitable for outdoor use and protection against splashes.

## Setup Guide

### What's in the Box

- 1 x DOSS SoundBox Wireless Speaker
- 1 x User Manual
- 1 x USB charging cable

### Charging the Speaker

Before first use, fully charge the speaker. Connect the included micro USB cable to the charging port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light (located under the charging port) will illuminate during charging and turn off when fully charged. A full charge typically takes 3-4 hours.

### Initial Bluetooth Pairing

1. Ensure the speaker is fully charged.
2. Press and hold the Power button on the speaker until you hear an audible prompt and the Bluetooth indicator light begins to flash rapidly, indicating it is in pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.

4. Select "DOSS SoundBox Touch" from the list of devices.
5. Once paired, you will hear a confirmation sound, and the Bluetooth indicator light will turn solid blue.

The speaker will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.




Figure 5: Seamless connectivity with Bluetooth 5.0. A user is shown effortlessly pairing their mobile device with the DOSS SoundBox Touch speaker for wireless audio streaming.

## Operating Instructions

### Power On/Off

- To Power On: Press and hold the Power button until the indicator lights illuminate.
- To Power Off: Press and hold the Power button until the indicator lights turn off.

### Touch Controls

The DOSS SoundBox Touch features intuitive touch controls on its top panel:

- **Volume Control:** Rotate your finger clockwise along the illuminated ring to increase volume. Rotate counter-clockwise to decrease volume. Ensure your fingertips are dry for optimal responsiveness.
- **Play/Pause:** Tap the center of the illuminated ring to play or pause audio.
- **Next Track:** Tap the ">>|" icon to skip to the next track.
- **Previous Track:** Tap the "|<<" icon to go to the previous track.
- **Mode Button:** Tap the "MODE" button to switch between Bluetooth, AUX, and TF Card modes.

## Hands-free Calling

- **Answer Call:** Tap the phone icon button to answer an incoming call.
- **End Call:** Tap the phone icon button again to end an active call.
- **Reject Call:** Press and hold the phone icon button to reject an incoming call.

## AUX-in Mode

Connect an external audio device using a 3.5mm audio cable (not included) to the AUX-in port on the speaker. The speaker will automatically switch to AUX mode, or you can select it using the Mode button. In AUX mode, playback controls (play/pause, track skip) must be managed from the connected device.

## TF Card Mode

Insert a Micro SD (TF) card loaded with MP3 audio files into the TF card slot. The speaker will automatically switch to TF Card mode, or you can select it using the Mode button. The speaker will begin playing audio files from the card. Use the track skip buttons to navigate through your music.




Figure 6: The compact size of the DOSS SoundBox Touch allows for easy portability, fitting conveniently into bags for music on the go.




Figure 7: The DOSS SoundBox Touch offers an impressive 20 hours of playtime, ensuring extended music enjoyment from dusk till dawn, as depicted by multiple speakers in an outdoor setting.

## Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's surface. Do not use abrasive cleaners, alcohol, or other chemical solvents, as they may damage the finish.
- **Water Resistance Care:** While the speaker is IPX5 water-resistant, it is not fully waterproof. Do not submerge it in water. Ensure the charging port and AUX-in port covers are securely closed when near water to prevent damage.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery at least once every three months to maintain battery health.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Recharge it when the low battery indicator is active.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Speaker does not turn on. | Battery is depleted. | Charge the speaker fully. |
| Cannot pair with Bluetooth device. | Speaker is not in pairing mode; Bluetooth is off on device; Device is too far. | Ensure speaker is in pairing mode (flashing blue light). Turn on Bluetooth on your device. Move device closer to speaker (within 10 meters). |
| No sound or low volume. | Volume too low on speaker or device; Incorrect mode selected; Device not connected. | Increase volume on both speaker and connected device. Ensure correct mode (Bluetooth, AUX, TF Card) is selected. Reconnect Bluetooth or check AUX cable connection. |
| Touch controls are unresponsive. | Fingertips are wet or dirty; Software glitch. | Ensure fingertips are clean and dry. Try restarting the speaker. |
| Sound distortion. | Volume too high; Low battery; Interference. | Lower the volume. Charge the speaker. Move speaker away from other electronic devices. |

## Specifications

| Feature | Detail |
|---|---|
| Model Name | SoundBox |
| Speaker Type | Single Speaker |
| Speaker Maximum Output Power | 12 Watts |
| Connectivity Technology | Bluetooth 5.0, Micro SD, Auxilliary |
| Bluetooth Range | Up to 10 meters (33 feet) |
| Battery Life | Up to 20 Hours (at 50% volume) |
| Charging Time | 3-4 Hours |
| Battery Capacity | 2200 Milliamp Hours |
| Water Resistance Level | IPX5 Water-resistant |
| Product Dimensions | 6.6"D x 2.7"W x 2.9"H |
| Item Weight | 1.23 Pounds |
| Material | Plastic, Metal |
| Included Components | Speaker, User Manual, USB charging cable |

## Warranty and Support

### Warranty Information

The DOSS SoundBox Touch Wireless Bluetooth Speaker comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and quality-related concerns. Please retain your proof of purchase for warranty claims.

## Customer Support

For any issues, questions, or support needs regarding your DOSS SoundBox Touch speaker, please do not hesitate to contact our customer service team. We are committed to providing prompt assistance.



Figure 8: DOSS Customer Support details. Contact us via phone at 1-833-275-3677 or email at support@dossav.com for assistance.

You can also visit the official DOSS website for FAQs and additional resources:www.dossav.com

© 2024 DOSS. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question