Disney Moana's Magic Shell Heart Light Up Necklace

Instruction Manual

Disney Moana's Magic Shell Heart Light Up Necklace

Model: Moana's Magic Shell Heart Light Up Necklace | Brand: Disney (Manufactured by Jakks Pacific)

Introduction

This manual provides essential information for the safe and proper use of your Disney Moana's Magic Shell Heart Light Up Necklace. Please read these instructions carefully before use and retain them for future reference.
The necklace is designed to replicate Moana's iconic shell from the Disney film, featuring light-up capabilities and a hidden "Heart of Te Fiti" element.

Package Contents

- 1 x Disney Moana's Magic Shell Heart Light Up Necklace
- 3 x Button Cell Batteries (pre-installed)





Figure 1: Product packaging, illustrating the necklace and its features.

Setup

The Disney Moana's Magic Shell Heart Light Up Necklace comes with batteries pre-installed and is ready for immediate use. No assembly is required.

Battery Information

This product requires 3 button cell batteries. Batteries are included. For battery replacement, refer to the "Maintenance" section.

Warning:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Batteries should be inserted with the correct polarity.

- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the product before being charged.

Operating Instructions

The necklace features two primary light-up functions:

1. Light-Up When Closed

To activate the light-up feature while the shell is closed, locate the small button on the back of the pendant. Press this button to illuminate the shell with a soft green glow.





Figure 2: Necklace with the shell closed and illuminated.





Figure 3: Necklace with the shell closed and not illuminated.

2. Light-Up When Opened (Heart of Te Fiti)

To reveal the "Heart of Te Fiti" and activate its glow, gently open the shell pendant. The inner "Heart of Te Fiti" will automatically illuminate with a soft green light upon opening.



Figure 4: Necklace with the shell open, revealing the glowing Heart of Te Fiti.



Figure 5: Necklace with the shell open, showing the Heart of Te Fiti without illumination.



Figure 6: Child interacting with the open necklace.





Figure 7: Child wearing the necklace.

Product Demonstration Video

Your browser does not support the video tag.

Video 1: Official product demonstration of the Disney Moana's Magical Seashell Necklace, showcasing its light-up features when closed and opened to reveal the Heart of Te Fiti.

Maintenance

To ensure the longevity of your necklace, follow these care instructions:

- **Cleaning:** Wipe the necklace with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the necklace in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** If the light-up feature dims or stops working, it's time to replace the batteries. This process may require careful handling to avoid damaging the necklace. Refer to the battery warnings in the "Setup" section.

Troubleshooting

Problem	Possible Cause	Solution
Light does not illuminate.	Batteries are depleted or incorrectly installed.	Replace batteries, ensuring correct polarity.
Light is dim.	Batteries are low.	Replace batteries.
Shell does not open smoothly.	Debris or minor misalignment.	Gently clear any visible debris. Avoid forcing the shell open.

Specifications

- **Model:** Moana's Magic Shell Heart Light Up Necklace
- **Brand:** Disney (Manufactured by Jakks Pacific)
- **Material:** Plastic
- **Item Width:** Approximately 2.75 inches (pendant)
- **Clasp Type:** Lobster
- **Gem Type:** No gemstone
- **Batteries:** 3 x Button Cell Batteries (included)
- **Recommended Age:** 3 years and up
- **ASIN:** B01CQTWBYK

Warranty and Support

For information regarding warranty coverage or product support, please refer to the manufacturer's official website or contact their customer service department. Contact details are typically found on the product packaging or the manufacturer's website.
Manufacturer: Jakks Pacific

© 2024 Disney / Jakks Pacific. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question