Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Stihl HS45

Stihl HS45 Hedge Trimmer User Manual

Model: HS45 | Brand: Stihl

1. Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Stihl HS45 Hedge Trimmer. Please read these instructions carefully before using the equipment for the first time and keep them for future reference. Proper use and maintenance will ensure optimal performance and extend the lifespan of your hedge trimmer.

2. Safety Instructions

Always prioritize safety when operating power tools. Failure to follow these safety guidelines can result in serious injury or property damage.

- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses or goggles, hearing protection, heavy-duty gloves, long pants, and sturdy, non-slip footwear.
- **Fuel Handling:** Handle fuel with extreme care. Mix and refuel outdoors in a well-ventilated area, away from sparks, open flames, or other ignition sources. Do not smoke while refueling.
- **Work Area:** Ensure the work area is clear of bystanders, children, and pets. Inspect the hedge for hidden objects like wires or fences before cutting.
- **Blade Safety:** The blades are extremely sharp. Never touch the blades while the engine is running. Always turn off the engine and ensure the blades have stopped before performing any adjustments or maintenance.
- **Secure Grip:** Maintain a firm grip on both handles of the hedge trimmer during operation.
- **Weather Conditions:** Do not operate the hedge trimmer in wet conditions or rain, as this increases the risk of electric shock (if applicable to electric models, but generally good practice for gas too due to slippery conditions).
- **Fatigue:** Do not operate the hedge trimmer when tired or under the influence of alcohol or medication.
- **Storage:** Store the hedge trimmer with the blade guard in place, in a dry, secure location out of reach of children.

3. Product Components

The Stihl HS45 Hedge Trimmer is a robust tool designed for efficient hedge maintenance. Familiarize yourself with its key components:

- **Engine Housing:** Contains the 27.2CC gas engine.
- **Fuel Tank:** For holding the fuel mixture.
- **Starter Handle:** Used to manually start the engine.
- **Front Handle:** Provides a secure grip and control during operation.
- **Rear Handle (Throttle Handle):** Contains the throttle trigger and safety lock-out.
- **Blade Guard:** Protects the user from the cutting blades.
- **Cutting Blades:** Double-sided blades, 24 inches (60 cm) in length, for efficient cutting.



Image: The Stihl HS45 Hedge Trimmer, showcasing its orange engine housing, white and black handles, and the extended 24-inch double-sided cutting blade. This view provides a comprehensive look at the tool's design and primary components.

4. Setup

Before starting your hedge trimmer, ensure it is properly prepared for use.

1. **Fuel Mixture:** The Stihl HS45 uses a gasoline-oil mixture. Refer to your Stihl oil container for the correct mixing ratio (typically 50:1 for Stihl 2-stroke oil). Use fresh, high-octane unleaded gasoline.
2. **Fill Fuel Tank:** Carefully pour the mixed fuel into the fuel tank, avoiding spills. Securely close the fuel cap.
3. **Blade Inspection:** Check the cutting blades for any damage, dullness, or debris. Ensure the blade guard is correctly installed.
4. **Handle Adjustment (if applicable):** Ensure handles are securely fastened and adjusted for comfortable operation.

5. Operating Instructions

Follow these steps for safe and effective operation of your hedge trimmer.

5.1. Starting the Engine

1. Place the hedge trimmer on a firm, level surface.
2. Engage the choke lever (if cold start).
3. Press the primer bulb several times until fuel is visible.
4. Hold the hedge trimmer firmly with one hand on the front handle.
5. Pull the starter handle briskly until the engine fires (usually a few pulls).
6. Once the engine fires, disengage the choke.
7. Pull the starter handle again until the engine runs smoothly.
8. Allow the engine to warm up for a few moments before engaging the throttle.

5.2. Operating the Trimmer

- Maintain a balanced stance and firm grip on both handles.
- Keep the blades away from your body and other objects.
- Start cutting from the bottom of the hedge and work your way up for vertical cuts.
- For horizontal cuts, sweep the trimmer in an arc, keeping the blades parallel to the desired cutting line.
- Avoid forcing the blades through thick branches; cut smaller sections or use a different tool for larger diameters.

5.3. Stopping the Engine

- Release the throttle trigger.
- Move the stop switch to the 'OFF' or 'STOP' position.
- Wait for the blades to come to a complete stop before setting the trimmer down or performing any actions.

6. Maintenance

Regular maintenance is crucial for the longevity and safe operation of your Stihl HS45.

- **Blade Cleaning:** After each use, clean the blades of sap and debris using a stiff brush and a suitable cleaning agent. Apply a light coat of rust-preventative oil.
- **Blade Sharpening:** Sharpen blades regularly to maintain cutting efficiency. Refer to a Stihl service center or a qualified technician for proper sharpening techniques.
- **Air Filter:** Check and clean the air filter periodically. A dirty air filter can reduce engine performance. Replace if damaged.
- **Spark Plug:** Inspect the spark plug for wear and proper gap. Clean or replace as needed, typically annually or every 50 operating hours.
- **Fuel Filter:** The fuel filter inside the tank should be checked and replaced periodically to prevent fuel system issues.
- **General Inspection:** Regularly check all nuts, bolts, and screws for tightness. Inspect for any signs of damage or wear.
- **Storage:** For long-term storage, drain the fuel tank or use a fuel stabilizer. Clean the entire unit, apply blade oil, and store in a dry, secure location with the blade guard in place.

7. Troubleshooting

This section addresses common issues you might encounter with your Stihl HS45 Hedge Trimmer.

Problem	Possible Cause	Solution
Engine won't start	No fuel, incorrect choke setting, fouled spark plug, clogged fuel filter.	Check fuel level and mixture, adjust choke, clean/replace spark plug, replace fuel filter.
Engine runs poorly/lacks power	Dirty air filter, stale fuel, incorrect fuel mixture, dull blades.	Clean air filter, use fresh fuel, ensure correct fuel mix, sharpen blades.
Blades jam or cut poorly	Dull blades, debris in blades, bent blades.	Sharpen blades, clean debris, inspect for damage and replace if necessary.

Problem	Possible Cause	Solution
Excessive vibration	Loose components, damaged blades, engine imbalance.	Check all fasteners, inspect blades for damage, consult a service technician for engine issues.

If you are unable to resolve an issue using this guide, please contact an authorized Stihl service dealer.

8. Technical Specifications

- **Model:** HS45
- **Brand:** Stihl
- **Engine Displacement:** 27.2 CC
- **Blade Length:** 24 inches (60 cm)
- **Blade Type:** Double-sided
- **Power Source:** Gas
- **Product Dimensions:** 26L x 112l x 21H cm (10.2 x 44.1 x 8.3 inches)
- **Item Weight:** 5 kg (11 lbs)
- **Color:** Orange

9. Warranty and Support

For information regarding the warranty period and terms for your Stihl HS45 Hedge Trimmer, please refer to the warranty card included with your purchase or visit the official Stihl website. For technical support, spare parts, or professional servicing, contact your local authorized Stihl dealer. Always use genuine Stihl replacement parts to ensure compatibility and maintain product integrity.

© 2025 Stihl. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01CXA58Y2

More documents and user manuals: **https://manuals.plus/**